


# Altivar 38

## 异步电动机变频器

用户手册



## 警告

当变频器通电时，动力元件和某些控制元件与进线电源连接。触碰它们非常危险。变频器盖必须保持紧闭。

在 ALTIVAR 断电，绿色 LED 灯熄灭后，应等待 3 到 10 分钟，电容器放电完毕后才能对设备进行操作。

在运行中可以通过禁止运行命令或速度给定使电机停机，变频器保持通电。如果人员安全要求避免突然的重起动，则该电子锁定系统是不够的：应在动力电路上安装一个断路装置。

## 注意

变频器安装有安全保护装置，在出现故障的情况下，可以切断变频器电源，继而切断电机电源。电机本身可以通过机械阻塞停机。此外，电压变化特别是进线电源故障也会导致停机。

如果停机的原因消失，则有可能存在重新启动的危险性，这会威胁某些机器或设备的安全，特别是那些要求必须遵守安全规范的设备。

在这种情况下用户必须采取措施预防这种可能的重起动，特别是可以在电机出现非正常停机时使用低速检测器来切断变频器电源。

设备应依照 IEC 标准各种规定的技术规范进行设计。

按照规程，在对设备或机器的电气或是机械部分进行任何操作之前，都必须断开变频器电源。

本文档中所述的产品和设备不论从技术角度或是操作方法上都有可能随时进行改变和修改。其说明绝不应视为具有法律效力。

## 注意事项

Altivar 38 必须作为一个部件使用：它不是能够单独使用的符合欧洲条例（设备以及电磁兼容性标准）的机器或设备。最终用户有责任确保所用设备能够满足这些标准。

变频器必须根据国际和国内标准进行安装和设置。使设备符合标准是系统集成人员的责任，在欧盟其他国家中他们必须遵守 EMC 标准。

必须严格遵循本文档中的技术规范，以符合 EMC 标准的基本要求。

准备工作	2
带散热器的变频器的选型	3
适用力矩	4
技术规格	5
尺寸 - 风机通风量	7
安装和温度条件	8
拆除 IP 41 保护盖板	10
壁挂式或落地式机箱的安装	11
端子连接 - 动力端子	12
控制端子	14
电磁兼容性 - 接线	15
接线指南，使用	17
接线图	18
键盘操作	21
访问菜单	22
访问菜单 - 编程原则	23
宏配置	24
Display ( 显示 ) 菜单	25
Adjust ( 调整 ) 菜单	26
Drive ( 传动 ) 菜单	29
Control ( 控制 ) 菜单	32
I/O ( 输入 / 输出 ) 菜单	35
可配置 I/O 的应用功能	39
Fault ( 故障 ) 菜单	48
Files ( 文件 ) 菜单	50
Communication and Application ( 通讯和应用 ) 菜单 / 返回出厂设定	52
操作 - 维护 - 备件及修理	53
故障 - 原因 - 处理办法	54
配置和调整记录	57
菜单汇总	59
索引	62

## 准备工作

### 验收

检查确认标签上印制的型号与购货订单所对应的交货单的型号一致。

将 **Altivar 38** 从包装中取出，检查确认其在运输过程中未受到损坏。

### 搬运和存放


安装之前为保护变频器，应带着包装进行搬运和存放。

#### 搬运

Altivar 38 系列包括 9 种型号的设备，其重量和尺寸各不相同。

小型变频器的包装去除和安装可以不使用搬运设备。

对于大型变频器必须使用吊车，它们配有 4 个吊环。必须遵守如下注意事项：



## 带散热器的变频器的选型

### 3 相电源电压: 380...460 V 50/60 Hz

400 V 时的 线电流	Isc 预期 短路电流	电动机功率 (2)	额定电流 (In)	最大瞬时 电流 (3)	额定负载下 的耗散功率 (4)	型号 (5)	重量
A	kA	kW	A	A	W		kg
3,1	5	0,75	2,1	2,3	55	ATV38HU18N4	3,8
5,4	5	1,5	3,7	4,1	65	ATV38HU29N4	3,8
7,3	5	2,2	5,4	6	105	ATV38HU41N4	3,8
10	5	3	7,1	7,8	145	ATV38HU54N4	6,9
12,3	5	4	9,5	10,5	180	ATV38HU72N4	6,9
16,3	5	5,5	11,8	13	220	ATV38HU90N4	6,9
24,3	22	7,5	16	17,6	230	ATV38HD12N4	13
33,5	22	11	22	24,2	340	ATV38HD16N4	13
43,2	22	15	30	33	410	ATV38HD23N4	15
42	22	18,5	37	41	670	ATV38HD25N4(X)	34
49	22	22	44	49	750	ATV38HD28N4(X)	34
65	22	30	60	66	925	ATV38HD33N4(X)	34
79	22	37	72	80	1040	ATV38HD46N4(X)	34
95	22	45	85	94	1045	ATV38HD54N4(X)	57
118	22	55	105	116	1265	ATV38HD64N4(X)	57
158	22	75	138	152	1730	ATV38HD79N4(X)	57
156 (1)	22	90	173	190	2250	ATV38HC10N4X	49
191 (1)	22	110	211	232	2750	ATV38HC13N4X	75
229 (1)	22	132	253	278	3300	ATV38HC15N4X	77
279 (1)	22	160	300	330	4000	ATV38HC19N4X	77
347 (1)	22	200	370	407	5000	ATV38HC23N4X	159
384 (1)	22	220	407	448	5500	ATV38HC25N4X	166
433 (1)	22	250	450	495	6250	ATV38HC28N4X	168
485 (1)	22	280	503	553	7000	ATV38HC31N4X	168
536 (1)	22	315	564	620	7875	ATV38HC33N4X	168

(1) 所给值为带有附加进线电抗器的电流值。

(2) 功率水平适用于最大开关频率根据额定值选择为 2 或 4kHz 的连续运行中。开关频率在“技术规格”中进行详述。

在更高的开关频率下使用 ATV38:

- 对于连续运行，应降容一个功率等级，例如：  
ATV38HU18N4 为 0.37 kW - ATV38HD12N4 为 5.5 kW。
- 如果未进行功率降容，则不应超过以下的运行条件：  
每 60 秒的工作循环中累积运行时间 36s (负载系数 60%)。

(3) 持续 60 秒。

(4) 给出的这些功率水平对应于连续运行中的最大允许开关频率 (2 或 4kHz，取决于额定值)。

(5) 对于 ATV38HU18N4 至 D79N4: Altivar 38 内置 EMC 滤波器。


对于 ATV38HD25N4 (X) 至 D79N4 (X): 型号后加 X 代表无内置 EMC 滤波器的 Altivar 38。

对于 ATV38HC10N4X 至 C33N4X: Altivar 38 没有内置 EMC 滤波器。可以使用外部滤波器选项。

## 适用力矩

力矩特性：

- 变力矩应用场合：



- 1 自冷却电机：持续有用力矩
- 2 强制冷却电机：持续有用力矩
- 3 最长 60 秒的瞬时过力矩。
- 4 恒功率超速时的力矩。

可用过力矩：

变力矩应用场合：

- 电动机额定力矩的 110% 持续 60 秒。

### 连续运行

对于自冷却电动机，冷却是与电动机速度相联系的。速度低于额定速度一半时需降容使用。

### 超速运行

随着电压不再随频率变化，电动机中的感应降低，这将导致力矩降低。请与制造商检查确认电机可以在超速下运行。

注意：对于专用电动机，额定和最大频率可以使用操作盘或 PowerSuite 工具在 10 到 500Hz 之间进行调整。

## 技术规格

### 环境


	ATV38 HU18N4 至 ATV38HD23N4	ATV38HD25N4 (X) 至 ATV38HC33N4X
防护等级	IP21, 上部为 IP41 (符合 EN 50178 标准)	ATV38HD25N4(X) 至 ATV38HD79N4(X) 变频器: IP21, 上部为 IP41 (符合 EN 50178 标准)  ATV38HC10N4X 至 ATV38HC33N4X 变频器: - 下侧为 IP00 (要求增加防止人员直接接触的防护) - 其他侧面为 IP20
抗震能力	符合 IEC 68-2-6 标准: 2 到 13 Hz, 峰值为 1.5 mm 13 到 200 Hz, 为 1 gn	ATV38HD25N4 (X) 至 ATV38HD79N4(X) 变频器: 符合 IEC 68-2-6 标准: 2 到 13 Hz, 峰值为 1.5 mm 13 至 200 Hz, 为 1 gn  ATV38HC10N4X 至 ATV38HC33N4X 变频器: 10 到 55 Hz 为 0.6 gn
最大环境污染等级	ATV38HU18N4 至 ATV38 HD23N4 变频器: 2 级, 符合 IEC 664-1 和 EN 50718 标准	ATV38HD25N4 (X) 至 ATV38HD79N4(X) 变频器: - 3 级, 符合 UL508C 标准 ATV38HC10N4X 至 ATV38 HC33N4X 变频器: 2 级, 符合 IEC 664-1 和 EN 50718 标准
最大相对湿度	93% 无结露或滴水, 符合 IEC 68-2-3 标准	
变频器周围的环境温度	存放: -25°C 至 +65°C  运行: ATV38HU18N4 至 ATV38HU90N4 变频器: • -10°C 至 +50°C 无降容 • 最高 +60°C, 50°C 以上每升高 1°C 电流降容 2.2%  ATV38HD12N4 至 ATV38HD23N4 变频器: • -10°C 至 +40°C 无降容 • 最高 +50°C, 40°C 以上每升高 1°C 电流降容 2.2%	存放: -25°C 至 +65°C  运行: ATV38HD25N4 (X) 至 ATV38HD79N4 (X) 变频器: • -10°C 至 +40°C 无降容 • 最高 +60°C, 40°C 以上每升高 1°C 电流降容 2.2%  ATV38HC10N4X 至 ATV38HC33N4X 变频器: • -10°C 至 +40°C 无降容 • 最高 +50°C, 40°C 以上每升高 1°C 电流降容 2.2%
最大工作高度	1000 米以内不降容 (1000 米以上, 每升高 100 米电流降容 1%)	
工作位置	垂直	



## 技术规格

### 电气特性


电源	电压	• 380 V - 10% 至 460 V + 10%, 3 相
	频率	• 50/60 Hz ± 5%
输出电压	最大电压等于进线电源电压	
电气隔离	动力和控制电路 ( 输入端、输出端、电源 ) 间进行电气隔离	
输出频率范围	0,1 至 500 Hz	
开关频率	可配置： <ul style="list-style-type: none"><li>• 无降容：<ul style="list-style-type: none"><li>对于 ATV38HU18N4 至 D46N4 (X) 变频器， 0.5 - 1 - 2 - 4 kHz</li><li>对于 ATV38HD54N4 (X) 至 C33N4X 变频器， 0.5 - 1 - 2 kHz</li></ul></li><li>• 间歇工作循环无降容或在连续运行中降容 1 个功率等级：<ul style="list-style-type: none"><li>对于 ATV38HU18N4 至 D23N4 变频器， 8 - 12 - 16 kHz</li><li>对于 ATV38HD25N4 (X) 至 D46N4 (X) 变频器， 8 - 12 kHz</li><li>对于 ATV38HD54N4 (X) 至 D79N4 (X) 变频器， 4 - 8 kHz</li><li>对于 ATV38HC10N4X 至 C33N4X 变频器， 4 kHz</li></ul></li></ul>	
速度范围	1 至 10	
制动力矩	对于低功率额定值，为电动机额定力矩的 30%，无制动电阻 ( 典型值 )	
瞬时过力矩	电动机额定力矩的 110% ( 典型值 ± 10% 之间 ) 持续 60 秒	
变频器的防护和安全功能	<ul style="list-style-type: none"><li>• 短路保护：<ul style="list-style-type: none"><li>- 输出相之间</li><li>- 输出相和地之间</li><li>- 内部电源输出</li></ul></li><li>• 热保护防止过热和过电流</li><li>• 电源欠压和过压安全保护电路</li><li>• 输入相缺失安全保护电路 ( 避免单相运行，所有三相变频器上均有此保护 )</li></ul>	
电动机保护	<ul style="list-style-type: none"><li>• 考虑变频器的速度，通过连续计算 <math>I^2t</math> 进行的热保护。变频器关闭时电动机热状态被保存。根据电动机的冷却类型，此功能可进行修改 ( 通过操作盘或编程终端或通过 PC 软件 )。</li><li>• 防止电机相线断路的保护</li><li>• 带选件卡使用 PTC 传感器给出的保护</li></ul>	





## 尺寸 - 风机通风量

### 尺寸



EMC 安装板

ATV38H	a	b	c	G	H	ø1	Δb	ø2
U18N4, U29N4, U41N4	150	230	184	133	210	5	64,5	4
U54N4, U72N4, U90N4	175	286	184	155	270	5,5	64,5	4
D12N4, D16N4	230	325	210	200	310	5,5	76	4
D23N4	230	415	210	200	400	5,5	76	4
D25N4 (X), D28N4 (X), D33N4 (X), D46N4 (X)	240	550	283	205	530	7	80	5
D54N4 (X), D64N4 (X), D79N4 (X)	350	650	304	300	619	9	110	5
C10N4X	370	630	360	317,5	609	12		
C13N4X, C15N4X, C19N4X	480	680	400	426	652	12		
C23N4X, C25N4X, C28N4X, C31N4X, C33N4X	660	950	440	598	920	15		


### 风机通风量

ATV38HU18N4	无冷却
ATV38HU29N4, U41N4, U54N4	36 m <sup>3</sup> / 小时
ATV38HU72N4, U90N4, D12N4, D16N4, D23N4	72 m <sup>3</sup> / 小时
ATV38HD25N4(X), HD28N4(X), D33N4(X), D46N4(X)	292 m <sup>3</sup> / 小时
ATV38HD54N4(X), D64N4(X), D79N4(X)	492 m <sup>3</sup> / 小时
ATV38HC10N4X	600 m <sup>3</sup> / 小时
ATV38HC13N4X, C15N4X, C19N4X	900 m <sup>3</sup> / 小时
ATV38HC23N4X, C25N4X, C28N4X, C31N4X, C33N4X	900 m <sup>3</sup> / 小时

## 安装和温度条件

变频器应垂直安装，允差范围  $\pm 10^\circ$ 。  
不要靠近发热元件放置。  
留出足够的自由空间以保证冷却所需的空气能够从变频器底部向顶部循环。

### ATV38HU18N4 至 D23N4



变频器前方的自由空间：最小 10mm。

### ATV38HU18N4 至 U90N4:

从  $-10^\circ\text{C}$  到  $40^\circ\text{C}$ :  $d \geq 50\text{mm}$ : 无特别注意事项。  
 $d = 0$ : 如下页所示，从变频器顶部拆除保护盖板（此时防护等级变为 IP 20）。

从  $40^\circ\text{C}$  到  $50^\circ\text{C}$ :  $d \geq 50\text{ mm}$ : 如下页所示，从变频器顶部拆除保护盖板（此时防护等级变为 IP 20）。  
 $d = 0$ : 加装控制通风套件 VW3A5882 •（见 ATV38 产品目录）。

从  $50^\circ\text{C}$  到  $60^\circ\text{C}$ :  $d \geq 50\text{ mm}$ : 加装控制通风套件 VW3A5882 •（见 ATV38 产品目录）。  
 $50^\circ\text{C}$  以上每升高  $1^\circ\text{C}$  工作电流降容 2.2%。

### ATV38HD12N4 至 D23N4:


从  $-10^\circ\text{C}$  到  $40^\circ\text{C}$ :  $d \geq 50\text{m}$ : 无特别注意事项。  
 $d = 0$ : 如下页所示，从变频器顶部拆除保护盖板（此时防护等级变为 IP 20）。

从  $40^\circ\text{C}$  到  $50^\circ\text{C}$ :  $d \geq 50\text{ mm}$ : 如下页所示，从变频器顶部拆除保护盖板（此时防护等级为 IP 20）。  
 $40^\circ\text{C}$  以上每升高  $1^\circ\text{C}$  电流降容 2.2%。

$d = 0$ : 加装控制通风套件 VW3A5882（见 ATV38 产品目录）。 $40^\circ\text{C}$  以上每升高  $1^\circ\text{C}$  电流降容 2.2%。

## 安装和温度条件


### ATV38HD25N4 (X) 至 D79N4 (X)



- 变频器前方的自由空间：最小 50mm。
- 从 -10°C 到 40°C: 无特别注意事项。
- 从 40°C 到 60°C: 加装控制通风套件 VW3A588 • • • (见 ATV38 产品目录)。40°C 以上每升高 1°C 工作电流降容 2.2%。

中文

### ATV38HC10N4X 至 C23N4X




- 变频器前方的自由空间：最小 50mm。
- 从 -10°C 到 40°C: 无特别注意事项。
- 最高 50°C，40°C 以上每升高 1°C 工作电流降容 2.2%。




## 拆除 IP 41 保护盖板

ATV38HU18N4 至 U90N4


中 文



ATV38HD12N4 至 D23N4



ATV38HD25N4 (X) 至 D79N4 (X)




## 壁挂式或落地式机箱的安装

遵守前页所给出的安装建议。

为确保变频器中正常的空气流通，应该：

- 安装通风格栅
- 确保足够通风：如果没有，则应安装带有过滤器的强制通风
- 使用专用的 **IP 54** 过滤器



中文

### 防尘防潮的壁挂式或落地式的金属机箱 (IP 54 防护等级)

在特定环境条件，例如有灰尘、腐蚀性气体、容易引起结露或滴水的高湿度、泼溅液体等环境下，变频器必须安装在防尘且防潮的机箱中。

为避免变频器中出现热点，应在机箱中加装风扇使空气循环，型号为 VW3A5882 • (见 ATV38 产品目录)。

这使得变频器能够在最高内部温度达到 60°C 的机箱中使用。

#### 计算机箱的大小

最大热阻 Rth (°C/W):

$$R_{th} = \frac{\theta^{\circ} - \theta^{\circ}e}{P}$$

$\theta^{\circ}$  = 机箱内部最高温度，单位 °C  
 $\theta^{\circ}e$  = 最高外部温度，单位 °C  
 $P$  = 机箱中的耗散总功率，单位 W

变频器耗散的功率：见“选择变频器”一节。

加上其他设备元件耗散的功率。

机箱的有效散热面积 S (m<sup>2</sup>):

(侧面 + 顶面 + 前面板，如果为壁挂式)

$$S = \frac{K}{R_{th}}$$

K = 机箱每 m<sup>2</sup> 的热阻

对于金属机箱：  
有内部风扇，K=0.12  
无风扇 K=0.15

注意：不要使用绝缘机箱，因为它们的导热性能很差。

## 端子连接 - 动力端子


### 端子连接

切断变频器电源。

ATV38HU18N4 至 ATV38HD79N4 (X):

- 控制端子：开锁并打开绞接的盖板
- 动力端子：在 Altivar 38 的下侧

端子位置：在 **Altivar** 下侧。



1 控制端子

2 动力端子

3 用于保护导线连接的端子，横截面积 10mm<sup>2</sup>，符合 EN50178 标准（接地漏电流）

ATV38HC10N4X 至 HC33N4X:

- 拆除前盖板即可连接控制和动力端子

### 动力端子

端子特性

Altivar ATV38H	端子	最大连接能力		紧固力矩， 单位 Nm
		AWG	mm <sup>2</sup>	
U18N4, U29N4, U41N4	所有端子	AWG 8	6	0,75
U54N4, U72N4, U90N4	所有端子	AWG 8	6	0,75
D12N4, D16N4, D23N4	所有端子	AWG 6	10	2
D25N4 (X), D28N4 (X)	L1, L2, L3, U, V, W, ⏏	AWG 4	16	3
D33N4 (X), D46N4(X)	L1, L2, L3, U, V, W, ⏏	AWG 2	35	4
D54N4 (X), D64N4 (X), D79N4 (X)	L1, L2, L3, U, V, W, ⏏	AWG 2/0	70	10
C10N4X	⏏	AWG 3/0	60	8
	其它端子	AWG 3/0	100	16
C13N4X	⏏	AWG 4/0	60	16
	其它端子	AWG 4/0	100	16
C15N4X	⏏	AWG 1/0 x 2	60	16
	其它端子	AWG 1/0 x 2	100	16
C19N4X	⏏	AWG 3/0 x 2	100	16
	其它端子	AWG 3/0 x 2	150	16
C23N4X	⏏	AWG 4/0 x 2	100	32
	其它端子	AWG 4/0 x 2	200	32

## 动力端子



Altivar ATV38H	端子	最大连接能力		紧固力矩, 单位 Nm
		AWG	mm <sup>2</sup>	
C25N4X		AWG 2/0 x 3 - AWG 300 x 2	100	32
	其它端子	AWG 2/0 x 3 - AWG 300 x 2	200	32
C28N4X		AWG 3/0 x 3 - AWG 350 x 2	150	32
	其它端子	AWG 3/0 x 3 - AWG 350 x 2	150 x 2	32
C31N4X,		AWG 4/0 x 3 - AWG 400 x 2	150	32
	其它端子	AWG 4/0 x 3 - AWG 400 x 2	150 x 2	32
C33N4X		AWG 250 x 3 - AWG 500 x 2	150	32
	其它端子	AWG 250 x 3 - AWG 500 x 2	150 x 2	32

中文



### 端子布置

	L1	L2	L3	PA	PB	U	V	W	
---	----	----	----	----	----	---	---	---	---

ATV38HU18N4 至 D23N4

	L1	L2	L3	+	-	PA	PB	U	V	W	
---	----	----	----	---	---	----	----	---	---	---	---



ATV38HD25N4 (X) 和 D79N4 (X)

				+	+	-	
	L1	L2	L3	U	V	W	


ATV38HC10N4X

L1	L2	L3		
+		-		
			U	V W

ATV38HC13N4X 至 C19N4X

L1	L2	L3		
-			+	+
			U	V W

ATV38HC23N4X 至 C33N4X

 不要使用

### 端子功能


端子	功能	适用于 Altivar ATV38H
	<b>Altivar</b> 接地端子	所有额定值
L1 L2 L3	电源	所有额定值
+	DC 母线输出	所有额定值 除 <b>HU18N4</b> 至 <b>HD23N4</b> 以外
-		
PA PB	未使用	<b>ATV38HU18N4</b> 至 <b>HD79N4 (X)</b>
U V W	输出至电动机	所有额定值

## 控制端子

### 端子特性：

- 屏蔽连接端子：适用金属夹头或线耳接头
- 2 个可拆卸的端子，一个用于继电器触点，另一个用于低电平 I/O
- 最大连接能力：1.5mm<sup>2</sup> - AWG 14
- 最大紧固力矩：0.4Nm

### 端子布置：



### 端子功能

端子	功能	电气特性
R1A R1B R1C	故障继电器 R1 带公共点的 C/O 触点 (R1C)	最低通断能力： <ul style="list-style-type: none"><li>• 对于直流 24 V 为 10mA</li></ul>
R2A R2C	R2 可编程继电器的 N/O 触点	对感性负载的最大通断能力 (cos $\phi$ 为 0.4, L/R 为 7ms): <ul style="list-style-type: none"><li>• 对于交流 250 V 和直流 30V 为 1.5 A</li></ul>
AO1	模拟电流输出	X-Y mA 模拟输出，其中 X 和 Y 可进行配置 出厂设定为 0-20mA 阻抗 500 $\Omega$
COM	逻辑和模拟输入公共点	
AI1	模拟电压输入	模拟输入 0 + 10 V 阻抗 30 k $\Omega$
+10	1 至 10 k $\Omega$ 给定电位器的电源	+10V (- 0, + 10%) 最大 10mA 短路和过载保护
AI2	模拟电流输入	X-Y mA 模拟输入，其中 X 和 Y 可进行配置 出厂设定为 4-20mA 阻抗 100 $\Omega$
LI1 LI2 LI3 LI4	逻辑输入	可编程逻辑输入 阻抗 3.5 k $\Omega$ + 24V 电源 (最高 30V) 如小于 5 V 为 0 状态，大于 11V 为 1 状态
+ 24	输入端电源	+ 24 V 防短路和过载保护，最低 18V，最高 30 V 最大电流 200mA




## 电磁兼容性 - 接线

### 配有 EMC 滤波器的 Altivar 38: ATV38HU18N4 至 HD79N4

#### 原则

- 变频器、电动机和电缆屏蔽层间的接地线必须为“高频”等电势。
- 使用屏蔽层接地的电缆，电机电缆、制动电阻（如果安装）和控制信号电缆屏蔽层两端均需接地。在连续性没有任何破坏的情况下，部分长度的屏蔽层可使用导管或金属导管。
- 应确保供电电缆（进线电源）与电机电缆间最大程度的隔离。

#### 安装图



- 1 变频器配套的钢制设备接地板，按图中所示安装。
- 2 Altivar 38。
- 3 无屏蔽电源线或电缆。
- 4 用于安全保护继电器触点输出的无屏蔽电缆。
- 5 将电缆 6、7 和 8 的屏蔽层尽可能靠近变频器固定并接地：
  - 剥开电缆露出屏蔽层
  - 用所给的夹头将拨开的屏蔽层部分固定在金属板 1 上
 屏蔽层必须被足够夹紧在金属板上以确保良好的接触。
- 6 电机连接的屏蔽电缆，屏蔽层两端均须接地。屏蔽层必须连续，且中间端子必须在 EMC 屏蔽的金属盒中。
- 7 连接控制 / 信号连线的屏蔽电缆。对于需要若干条导线的场合，应使用小横截面积 (0.5mm<sup>2</sup>) 的导线。屏蔽层两端均须进行接地。屏蔽层必须连续，且中间端子必须在 EMC 屏蔽的金属盒中。
- 8 连接制动电阻（如果安装）的屏蔽电缆。屏蔽层两端均须接地。屏蔽层必须连续，且中间端子必须放在 EMC 屏蔽的金属盒中。

#### 注意：

- 如果使用了附加的输入滤波器，则应安装在变频器后面并使用无屏蔽电缆直接连接至电源上。此时应使用滤波器输出电缆 3 连接到变频器上。
- 变频器、电机和电缆屏蔽层间有了高频等电势接地连接，但仍需在每一组件的适当端子上连接 PE 保护导线（绿 - 黄色）。

## 电磁兼容性 - 接线

### 无集成式 EMC 滤波器的 Altivar 38: ATV38HC10N4X 至 HC33N4X

如果进线电源的预期短路电流低于 22kA，则必须使用进线电抗器。电抗器可提供进线电源过电压保护，并减少变频器所产生电流的谐波失真。电抗器用于限制线电流。

#### 原则

- 变频器、电动机和电缆屏蔽层间的接地必须为“高频”等电势。
- 使用屏蔽层接地的电缆，电动机电缆、制动电阻（如果安装）和控制信号电缆屏蔽层两端均需接地。在连续性没有任何破坏的情况下，部分长度的屏蔽层可使用导管或金属导管。
- 应确保供电电缆（进线电源）与机电缆间最大程度的隔离。


#### 动力连线

动力连线应包含有 4 条导线的电缆或与 PE 电缆尽可能接近的单条电缆。注意应将电动机电缆远离供电电缆布设。供电电缆无屏蔽。如果使用无线电干扰滤波器，则滤波器和变频器使用的地线应使用低阻抗连接，以保证高频等电势（固定在进行过防腐蚀处理并带有金属接地线的没有油漆过的金属板上）。滤波器应与变频器尽可能靠近安装。

如果环境对辐射的无线电干扰较为敏感，则电动机电缆应被屏蔽。在变频器端，使用防锈夹头将屏蔽层固定并连接到设备地线上。电动机电缆屏蔽层的主要功能是限制其无线电频率段的辐射。因此，应按照高频连线的惯例连接电机 4 极电缆屏蔽层的每一端。保护材料（铜或钢）类型的重要性要低于两端的连接质量。另外也可以使用导电性好且连续无中断的金属电缆线槽。

注意：当使用能够实现 PE+ 屏蔽双重功能的带保护套（NYCY 类）的电缆时，必须将其正确连接在变频器和电机上（降低其辐射率）。

#### 控制接线



## 接线指南，使用

### 接线指南

#### 功率

遵守标准规定的电缆横截面积要求。

变频器必须接地，以使其符合有关高漏电电流（超过 3.5mA）的规范。考虑到可能由漏电流生成的直流成分，不要使用用于进线保护的残余电流设备。如果设备安装中在同一条线路上有若干台变频器，则必须对每台变频器进行单独接地。如有必要，应安装进线电抗器（参阅产品目录）。

动力电缆应与设备中弱电信号电路（检测器、PLC、测量装置、视频设备、电话）保持分隔。

#### 控制

控制电路应与动力电缆保持距离。对于控制和速度给定电路，我们建议使用节距在 25 到 50mm 之间的屏蔽双绞线对屏蔽层每端进行连接。

### 使用建议

带有进线接触器的功率切换：



- 避免频繁操作接触器 **KM1**（滤波器电容过早老化）。使用输入 **LI1** 到 **LI4** 控制变频器。
- 在以下工作循环中这些步骤是必需的：
  - 对于 **ATV38HU18N4** 至 **HD79N4 (X)**，低于 60 秒
  - 对于 **ATV38HC10N4X** 至 **ATV38HC33N4X**，低于 180 秒

如果安全标准要求对电动机进行隔离，则应在变频器输出端上安装接触器，并使用“出线接触器控制”功能（参阅编程手册）。

### 故障继电器，解锁

变频器通电且无故障时故障继电器通电。它带有使用公共端的 C/O 触点。

变频器在故障后通过以下方式进行解锁：

- 给变频器断电直至显示屏和指示灯熄灭为止，然后再次通电
- 自动或通过逻辑输入端远程控制：参阅编程手册



文中



- 可与 **Altivar** 配合使用的部件：见产品目录。

阴影部分应添加到各种不同安装图类型中。




**注意：**  
对靠近变频器或连接在同一电路上的所有感性电路，如继电器、接触器、电磁阀、荧光灯等，均应安装干扰抑制器。

## 接线图

使用出线接触器的接线图，适用于 **ATV38HD25N4 (X)** 至 **C33N4X**。

阴影部分应添加到 3 相供电安装图中。




通过继电器R2或逻辑输出LO (直流24V) 切换线圈与I/O扩展卡，使用“出线接触器控制”功能。参阅编程手册。

注意：

对靠近变频器或连接在同一电路上的的所有感性电路，如继电器、接触器、电磁阀、荧光灯等，均应安装干扰抑制器。


可与 **Altivar** 配合使用的部件：见产品目录。

**24V 外部电源，用于给逻辑输入端供电**



## 键盘操作

前面板



按键使用和显示意义

闪烁：  
显示所选定的旋转方向  
稳定：  
显示电动机旋转方向  
表示通过端子进行控制  
在设置和编程模式下出现  
闪烁：  
表示该值已被修改但未保存。

**LOC**  
**PROG**

4 字符显示屏：  
显示数字值和代码  
一行 16 字符：  
以普通文本显示信息

如果通过端子进行的控制有效：



滚动菜单或参数以及调整参数值。



改变旋转方向。



返回前一菜单或放弃当前调整并返回初始值。



起动机运行的命令。



选定菜单，确认并保存一个选项或调整。




停止电动机或复位故障的命令。该键的“STOP”（停机）功能可通过程序禁止。（“CONTROL（控制）”菜单）。



使用与 **ATV38** 一同发货的显示模块，或 **5.1** 版或更高版本的显示模块（见后视图上的标签）。

后视图



注意：

操作盘可在电源通电的情况下进行连接和断开。如果在通过操作盘进行的变频器控制有效时断开操作盘，则变频器将会锁定为 SLF 故障模式。

访问锁定开关：

- 位置： 不可调整和配置
- 位置： 可进行调整
- 位置： 可进行调整和配置

接头：

- 用于直接将操作盘连接到变频器上
- 用于远程操作，操作盘可通过 **VW3A58103** 套件中提供的电缆进行连接。

远程操作盘的安裝：

使用 **VW3A58103** 套件，其中包含 1 条带有接头的电缆、在机箱门上安装的套件以及安装指南。

## 访问菜单

可访问的菜单数取决于访问锁定开关的位置。  
每一菜单均由若干参数组成。

**Language (语言):** 法语、英语、德语、西班牙语、意大利语。

**Macro-Config (宏 - 配置):** 如果已重新定义了一个输入 / 输出端, 即为变力矩 (出厂设定)  
**C U S** 显示 Customised (定制)

**Identification (识别):** 显示变频器功率和电压

**Display (显示):** 显示电气值, 运行或故障

**Adjust (调整):** 电动机旋转时可以访问的参数配值

**Drive (变频器):** 电动机 - 变频器配置值

**Control (控制):** 变频器控制配置:  
端子板、操作盘、RS485

**I/O (输入 / 输出):** I/O 定义的配置


**Faults (故障):** 对出现故障时电动机变频器动作的配置, 以及保护设备

**Files (文件):** 保存和恢复配置或返回出厂设定值

仅当安装有 “**application (应用)**” 或 “**communication (通讯)**” 卡时才访问

初次通电

以后通电



注意: 如果已设定访问密码, 则某些菜单可能不能使用; 这些菜单甚至不可见。这种情况参见标题为 “FILES menu” (文件菜单) 的一节, 其中介绍了如何进入访问密码。




## 访问菜单 - 编程原则

### Language (语言):

此菜单不管访问开关位于何种位置均可以访问，而且可以在停机或运行模式中进行修改。

举例：




可能选项：英语（出厂设定），法语，德语，西班牙语，意大利语。

### 编程原则：

原则均相同，分为 1 个或 2 个等级：

- 1 级：见上述 “language” 举例
- 2 级：见下述 “acceleration ramp” 举例。






## 宏配置

此参数总可以显示，并指示是否已对一个输入/输出端进行了重定义。  
出厂宏配置 = Variable torque (变力矩)

### 定制配置：

可通过改变 I/O 菜单中的 I/O 定义对变频器配置进行定制，该菜单可在编程模式下访问（访问开关在  位置）。


此定制将修改显示的宏配置值：

显示为：



### 变力矩宏配置中的 I/O 定义

逻辑输入 LI1	正向	逻辑输入 LI5	斜坡切换
逻辑输入 LI2	反向	逻辑输入 LI6	未定义
逻辑输入 LI3	故障复位	逻辑输入 A13 或	求和给定
逻辑输入 LI4	未定义	输入 A、A+、B、B+	求和给定
模拟输入 AI1	电动机频率	逻辑输出 LO	达到高速
模拟输入 AI2	求和给定	模拟输出 AO	电动机电流
继电器 R1	变频器故障		
继电器 R2	变频器运行		
模拟输出 AO1	电动机频率		

 如果安装了 I/O 扩展卡，则出现灰色背景的定义。

## Display (显示) 菜单



### Display (显示) 菜单 (运行中显示的参数选项)

不管访问开关位于停机还是运行模式位置，以下参数均可以访问。

代码	功能	单位
<b>Drive State</b>		—
---	变频器状态：指示故障或电动机运行：	
rdY	rdY = 变频器准备就绪	
rUn	rUn = 电机处于稳定状态或有运行命令和零给定	
ACC	ACC = 正在加速	
dEC	dEC = 正在减速	
CLl	CLl = 电流限制	
dCb	dCb = 直流注入制动	
nSt	nSt = 自由停车控制	
Obr	Obr = 通过调整减速斜坡进行制动 (见 “drive” (变频器) 菜单)	
FrH	Freq. Ref.	Hz
	频率给定	
rFr	Output Freq.	Hz
	施加给电动机的输出频率	
SPd	Motor Speed	rpm
	变频器估算的电动机速度	
LCr	Motor Current	A
	电动机电流	
USP	Machine Spd.	—
	变频器估算的设备速度。它以系数 USC 正比于 rFr，该系数可以在调整菜单中进行调节。它将显示一个对应于应用情况的值 (例如米 / 秒)。注意，如果 USP 大于 9999，则显示值为除以 1000 之后的值。	
OPr	Output Power	%
	电动机提供的功率，由变频器估算。100% 对应与额定功率。	
ULn	Mains Voltage	V
	电源电压	
tHr	Motor Thermal	%
	热状态：100% 对应于电动机的额定热状态。在 118% 以上时，变频器将触发一个 OLF 故障 (电动机过载)。	
tHd	Drive Thermal	%
	变频器热状态：100% 对应于变频器的额定热状态。在 118% 以上时，变频器将触发一个 OHF 故障 (变频器过热)。可被复位至 70% 以下。	
Lft	Last Fault	—
	显示上次出现的故障。	
LFr	Freq. Ref.	Hz
	当通过操作盘的变频器控制激活时，此调整参数代替 FrH 参数出现：控制菜单中的 LCC 参数	
APH	Power Used	kWh 或 MWh
	能量消耗	
r t H	Run Time	hr
	连续运行时间 (电动机通电)，以小时为单位	

## Adjust ( 调整 ) 菜单



此菜单可在开关处于  和  位置时进行访问。调整参数可以在运行过程中或停止模式下进行修改。应确保运行过程中的任何改动都不具有危险性；改动最好在停机模式下进行。

调整参数的列表在出厂配置下、没有 I/O 扩展卡的情况下可以访问。

中文

代码	说明	调整范围	出厂设定
<b>LFr</b>	Freq. Ref. - Hz	LSP 至 HSP	—
	当通过终端的控制被激活时出现：控制菜单中的参数 <b>LCC</b>		
<b>ACC</b>	Acceleration - s	0.05 至 999.9	3 s
<b>DEC</b>	Deceleration - s	0.05 至 999.9	3 s
	加速和减速斜坡时间 (0 到电动机额定频率 (FrS))。		
<b>LSP</b>	Low Speed - Hz	0 至 HSP	0 Hz
	低速		
<b>HSP</b>	High Speed - Hz	LSP 至 tFr	50 Hz
	高速：确保该设定值适用于电动机和应用场合		
<b>FLG</b>	Gain - %	0 至 100	20
	频率环增益：用于根据动力学特性调整机器速度的响应。对于高阻力矩、高惯性或快速工作循环的机器，应逐步提高增益。		
<b>StA</b>	Stability - %	0 至 100	20
	用于根据机器的动力学特性对速度瞬变之后返回稳定状态的过程进行调整。逐步提高稳定性以避免任何过速。		
<b>tH</b>	ThermCurrent - A	0.25 至 1.1 In (1)	根据变频器额定值
	用于电动机热保护的电流。将 tH 设定为电动机铭牌上所示的额定电流。		
<b>tDC</b>	DC Inj. Time - s	0 至 30 s Cont	0.5 s
	直流注入制动时间。如果此时间增至 30s 以上，则将显示 “Cont”，即连续电流注入。注入电流将会在 30s 后等于 SdC。		
<b>FFt</b>	NST Threshld - Hz	0 至 HSP	0 Hz
	自由停车脱扣阈值：当有斜坡停车或快速停车要求时，激活所选择的停车类型，直至速度降落至该阈值以下。在此阈值以下时，自由停车激活。		
<b>JPF</b>	Jump Freq. - Hz	0 至 HSP	0 Hz
<b>JF2</b> <b>JF3</b>	跳频：禁止在 JPF±2.5Hz 频率范围内运行。此功能可以防止出现导致共振的某个关键速度。		
<b>USC</b>	Machine Coef	0.01 至 100	1
	适用于参数 rFr (施加给电动机的输出频率) 的系数，电动机参数通过参数 USP 进行显示：USP = rFr x USC		
<b>tLS</b>	LSP Time - s	0 至 999.9	0 (没有时间限定)
	低速运行时间。在 LSP 速度上运行一段给定的时间后，电动机自动停车。如果频率给定高于 LSP 或运行命令仍然存在，则电动机会重新启动。注意：0 值对应于无限长的时间段。		

(1) In 是在产品目录和铭牌上给出的变频器额定电流。

## Adjust (调整) 菜单

以下参数在标准产品中对 I/O 进行重定义、或对设定值进行修改后可以访问。


代码	说明	调整范围	出厂设定
<b>ACC2</b>	Accel. 2 - s	0.05 至 999.9	5 s
	第 2 加速斜坡时间		
<b>DEC2</b>	Decel. 2 - s	0.05 至 999.9	5 s
	第 2 减速斜坡时间。当斜坡切换阈值 (参数 Frt) 为 0Hz 以外的值, 或当某一逻辑输入端被定义为斜坡切换时这些参数可以访问。		
<b>SDC</b>	dc I at rest - A	0.1 至 1.1 In (1)	根据变频器额定值
	tdC = Cont 的 30s 之后的注入制动电流水平。  检查确认电动机能够耐受此电流而不会出现过热。		
<b>IDC</b>	DC Inj.Curr. - A	0.1 至 1.1 In (1)	根据变频器额定值
	直流注入制动电流水平。当某一逻辑输入端已被定义为直流注入制动时此参数可以访问。如果设定为较高的值, 在 30 秒之后注入电流会被限制在 0.5Ith。		
<b>PFL</b>	U/f Profile - %	0 至 100%	20%
	当节能功能被禁止时可用于调整电动机二次供电因数。		
<b>SP2</b>	Preset Sp.2 - Hz	LSP 至 HSP	10 Hz
	第 2 预置速度		
<b>SP3</b>	Preset Sp.3 - Hz	LSP 至 HSP	15 Hz
	第 3 预置速度		
<b>SP4</b>	Preset Sp.4 - Hz	LSP 至 HSP	20 Hz
	第 4 预置速度		
<b>SP5</b>	Preset Sp.5 - Hz	LSP 至 HSP	25 Hz
	第 5 预置速度		
<b>SP6</b>	Preset Sp.6 - Hz	LSP 至 HSP	30 Hz
	第 6 预置速度		
<b>SP7</b>	Preset Sp.7 - Hz	LSP 至 HSP	35 Hz
	第 7 预置速度		
<b>SP8</b>	Preset Sp.8 - Hz	LSP 至 HSP	50 Hz
	第 8 预置速度		
<b>UFR</b>	IR Compens. - %	0 至 800%	0%
	仅当变频器菜单中的 SPC 参数 (专用电机) 设定为 “yes” 时 <b>UFR</b> 才出现。用于在自学习过程中调整对应于 100% 的测量值。		
<b>JOG</b>	Jog Freq. - Hz	0 至 10 Hz	10 Hz
	寸动频率		
<b>JGT</b>	Jog Delay - s	0 至 2 s	0.5 s
	连续两次寸动操作之间的防重复延时		

(1) In 对应于产品目录和铭牌上给出的变频器额定电流。


## Adjust ( 调整 ) 菜单

代码	说明	调整范围	出厂设定
<b>dt5</b>	Tacho Coeff.	1 至 2	1
	与测速发电机功能相关的反馈乘积系数： $dtS = \frac{9}{\text{最大速度 HSP 时的测速发电机电压}}$		
<b>rPG</b>	PI Prop.Gain	0.01 至 100	1
	PI 调节器比例增益		
<b>rIG</b>	PI Int. Gain	0.01 至 100/s	1 /s
	PI 调节器积分增益		
<b>Fb5</b>	PI Coeff.	1 至 100	1
	PI 反馈乘积系数		
<b>PII</b>	PI Inversion	no - yes	no
	颠倒 PI 调节器的校正方向 no: 正常 yes: 反向		
<b>Ftd</b>	Freq.Lev.Att - Hz	LSP 至 HSP	50 Hz
	电动机频率阈值，在此之上逻辑输出变为 1		
<b>F2d</b>	Freq.2 Att - Hz	LSP 至 HSP	50 Hz
	频率 2 阈值：与 Ftd 功能相同，用于第 2 个频率值		
<b>Ctd</b>	Curr.Lev.Att - A	0 至 1.1 In (1)	1.1 In (1)
	电流阈值，在此之上逻辑输出或继电器变为 1		
<b>tkd</b>	ThermLev.Att - %	0 至 118%	100%
	电动机热状态阈值，在此之上逻辑输出或继电器变为 1		
<b>P5P</b>	PI Filter - s	0.0 至 10.0	0 s
	用于调整 PI 反馈的滤波器时间常数		
<b>PI2</b>	PI Preset 2 - %	0 至 100%	30 %
	当某一逻辑输入端被定义为 4 个预置 PI 给定功能时，为第 2 预置 PI 给定。 100% = 过程最大值 0% = 过程最小值		
<b>PI3</b>	PI Preset 3 - %	0 至 100%	60 %
	当某一逻辑输入端被定义为 4 个预置 PI 给定功能时，为第 3 预置 PI 给定。 100% = 过程最大值 0% = 过程最小值		
<b>dt d</b>	ATU th.fault	0 至 118%	105 %
	变频器热阈值，在此之上逻辑输出或继电器变为 1		

(1) In 对应于产品目录和铭牌上给出的变频器额定电流。

 如果安装了 I/O 扩展卡，则出现带有灰色背景的参数。

## Drive (传动) 菜单



此菜单在开关处于  位置时进行访问。  
参数仅在停机模式下变频器锁定时才能修改。

传动性能可通过以下方法优化：  
- 输入变频器菜单中铭牌上给出的值  
- 进行自学习运行 (标准异步电动机)

代码	说明	调整范围	出厂设定
<b>Un5</b>	Nom.Mot.Volt - V	200 至 480 V	400 V
	铭牌上标注的电动机额定电压。调整范围取决于变频器型号。		
<b>Fr5</b>	Nom.Mot.Freq - Hz	10 至 500 Hz	50 Hz
	铭牌上给出的电动机额定频率		
<b>nCr</b>	Nom.Mot.Curr - A	0.25 至 1.1 In (1)	根据变频器额定值
	铭牌上给出的电动机额定电流		
<b>nSP</b>	Nom.Mot.Speed - rpm	0 至 9999 rpm	根据变频器额定值
	铭牌上给出的电动机额定速度		
<b>CO5</b>	Mot. Cos Phi	0.5 至 1	根据变频器额定值
	铭牌上给出的电动机功率因数 Cos Phi		
<b>tUn</b>	Auto Tuning	no - yes	no
	此参数一旦设置为 “yes” 即自学习电动机控制。自学习一完成, 参数即自动返回 “done” (完成), 或在出现故障时返回 “no”。 注意: 自学习只有在没有任何命令激活时进行。如果 “freewheel stop” (自由停车) 或 “fast stop” (快速停车) 功能被定义到某一逻辑输入端, 则此输入必须被设定为 1 (0 时有效)。		
<b>tFr</b>	Max. Freq. - Hz	10 至 500 Hz	60 Hz
	最大输出频率。最大值取决于开关频率。见参数 SFR (传动菜单)		
<b>nLd</b>	Energy Eco	no - yes	yes
	优化电动机效率		
<b>Fdb</b>	I lim adapt.	no - yes	no
	将限制电流作为输出频率的函数进行调整 (负载曲线按照气体密度的函数规律变化的通风场合)		
<b>brA</b>	DecRampAdapt	no - yes	yes
	如果对于负载的惯性而言设定值过低, 则激活此功能将自动增加减速时间, 以此避免变频器出现 ObF 故障。此功能可能与在斜坡上定位以及制动电阻的使用不兼容。		
<b>Frt</b>	SwitchRamp2 - Hz	0 至 HSP	0 Hz
	斜坡切换频率。一旦输出频率超过了 Frt, 采用的斜坡时间即为 AC2 和 dE2。		

(1) In 对应于产品目录和铭牌上给出的变频器额定电流。

## Drive (传动) 菜单


代码	说明	调整范围	出厂设定
<b>Stt</b>	<b>Stop Type</b>	STN - FST - NST - DCI	STN
	停车类型。 在有停车要求时，停车类型根据 FFt 阈值（调整菜单）激活。在此阈值之下，采用自由停车。 STN: 沿斜坡 FST: 快速停车 NST: 自由停车 DCI: 直流注入停车		
<b>rPt</b>	<b>Ramp Type</b>	LIN - S - U	LIN
	确定加速和减速斜坡的形状。 LIN: 线性 S: S斜坡 U: U斜坡 <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>S 形斜坡</p>  </div> <div style="text-align: center;"> <p>U 形斜坡</p>  </div> </div> <p>圆整系数固定，其中 <math>t_2 = 0.6 \times t_1</math>，<math>t_1</math> = 设定的斜坡时间。</p> <p>圆整系数固定，其中 <math>t_2 = 0.5 \times t_1</math>，<math>t_1</math> = 设定的斜坡时间。</p>		
<b>dCF</b>	<b>DecRampCoeff</b>	1 至 10	4
	快速停车功能有效时的减速斜坡时间缩减系数。		
<b>CLl</b>	<b>Int. I Lim - A</b>	0 至 1.1 In (1)	1.1 In
	电流限制用于限制电动机过热。		
<b>AdC</b>	<b>Auto DC Inj.</b>	no - yes	yes
	用于在停机时使自动直流注入制动无效。		
<b>PCC</b>	<b>Motor P Coef.</b>	0.2 至 1	1
	当某一逻辑输入端已被定义为电动机切换功能时，用于确定变频器额定功率与低额定值电动机之间的关系。		




## Drive (传动) 菜单

代码	说明	调整范围	出厂设定																
SFt	Sw Freq.Type	LF-HF1-HF2	LF																
	用于选择低开关频率 (LF) 或高开关频率 (HF1 或 HF2)。HF1 切换设计用于低负载因数且变频器无降容的应用场合。如果变频器的热状态超过 95%，根据变频器额定值，频率将自动变为 2 或 4kHz。当变频器的热状态降回 70% 时，重新获得所选定的开关频率。HF2 切换设计用于高负载因数且变频器降容一级的应用场合：变频器参数自动缩放（力矩限制、热状态等） 修改此参数将会导致下列参数返回出厂设定：  <ul style="list-style-type: none"><li>• nCr、CLl、Sfr、nrd (Drive (传动) 菜单)</li><li>• ItH、IdC、Ctd (Adjust (调整) 菜单)</li></ul>																		
SFr	Sw Freq - kHz	0.5-1-2-4-8-12-16 kHz	根据变频器额定值																
	用于选择开关频率。调整范围取决于 SFt 参数。 如果 SFt= LF: 0.5 至 2 或 4kHz，根据变频器额定值 如果 SFt= HF1 或 HF2: 2 或 4 至 16kHz，根据变频器额定值 根据开关频率对最大工作频率 (tFr) 进行限制。  <table><tr><td>SFr (kHz)</td><td>0.5</td><td>1</td><td>2</td><td>4</td><td>8</td><td>12</td><td>16</td></tr><tr><td>tFr (Hz)</td><td>62</td><td>125</td><td>250</td><td>500</td><td>500</td><td>500</td><td>500</td></tr></table>			SFr (kHz)	0.5	1	2	4	8	12	16	tFr (Hz)	62	125	250	500	500	500	500
SFr (kHz)	0.5	1	2	4	8	12	16												
tFr (Hz)	62	125	250	500	500	500	500												
nrd	Noise Reduct	no - yes	(1)																
	此功能将对开关频率进行随机调制以降低电动机噪声。																		
SPC	Special Motor	no - yes - PSM	no																
	应用于符合 U/f 比恒定的电动机电源，通过 “Adjust”（调整）菜单中的 UFr 设置 IR 补偿 No: 通用电机 Yes: 专用电机 PSM: 小型电机。它禁止检测 “Uncontrolled loss downstream”（无控制的输出缺失）。为使其正常运行需在传动菜单中禁止 nLd 功能。  进行自学习																		
PGt	PG Type	INC-DET	DET																
	当安装有编码器反馈 I/O 卡时定义所使用的传感器类型： INC: 增量编码器 (A、A+、B、B+ 为硬连接) DET: 检测器（仅有 A 为硬接线）																		
PLS	Num. Pulses	1 至 1024	1024																
	定义传感器每转的脉冲数。																		

(1) 如果 SFt = LF 为 yes，SFt = HF1 或 HF2 为 no


 如果安装了 VW3 A58202 I/O 扩展卡，则出现带有灰色背景的参数。

## Control ( 控制 ) 菜单

此菜单可在开关处于  位置时进行访问。  
参数仅在停机模式下变频器锁定时才能修改。

代码	说明	调整范围	出厂设定
tcC	TermStripCon	2W- 3W (2 线 - 3 线)	2W

端子排控制的配置：2 线或 3 线控制。


 由于会导致逻辑输入端的重新定义，此参数的修改要求进行双重确认。由 2 线控制转为 3 线控制，逻辑输入定义由一个输入端进行转换。2 线控制中的 LI3 定义在 3 线控制中成为 LI4。在 3 线控制方式中，输入端 LI1 和 LI2 不能被重新定义。

宏 - 配置	变力矩
LI1	STOP 停车
LI2	RUN ( 正向 ) 运行
LI3	RUN ( 反向 ) 运行
LI4	故障复位
LI5	斜坡切换
LI6	未定义

如果安装了 I/O 扩展卡，则可以访问带有灰色背景的参数。


3 线控制（脉冲控制：一个脉冲足以对起动进行控制）。此选项将禁止 “automatic restart”（自动重新启动）功能。

接线举例：  
LI1：停车  
LI2：正向  
LIx：反向






The diagram shows a terminal block labeled "ATV38控制端子" with four terminals: 24 V, LI1, LI2, and LIx. Each terminal is connected to a switch. The 24 V terminal is connected to a switch that is normally closed. The LI1, LI2, and LIx terminals are each connected to a switch that is normally open.

此选项仅在配置了 2 线控制时出现。

代码	说明	调整范围	出厂设定
<b>tcE</b>	<b>Type 2 Wire</b>	LEL-TRN-PFo	LEL
<p>可按下述方式定义 2 线控制：</p> <ul style="list-style-type: none"><li>- 逻辑输入端的状态 (LEL: 2 线)</li><li>- 逻辑输入端状态的变化 (TRN: 2 线转换)</li><li>- 逻辑输入端的状态，正向总优先于反向 (PFo: 正向优先)</li></ul> <p>接线举例： LI1：正向 LIx：反向</p> 			
<b>rIn</b>	<b>RV Inhibit</b>	no - yes	no
<ul style="list-style-type: none"><li>• 禁止以逻辑输入端控制的相反方向运行，即使求和或过程控制功能要求颠倒方向也不可以。</li><li>• 如果在操作盘上用 FWD/REV 键进行控制，则会禁止反向运行。</li></ul>			

如果安装了 I/O 扩展卡，则出现带有灰色背景的参数。

## Control (控制) 菜单


代码	说明	调整范围	出厂设定
<b>b5P</b>	deadb./Pedst	no BNS: 消隐 BLS: 死区	no
	低速运行管理： F: 电动机频率 		
<b>CrL</b> <b>CrH</b>	AI2 min Ref. - mA AI2 Max Ref. - mA	0 至 20 mA 4 至 20 mA	4 mA 20 mA
	输入端 AI2 上信号的最小和最大值。 这两个参数用于定义发送至 AI2 的信号。有若干种配置可能，其中一种是将输入端配置为 0-20mA、4-20mA、20-4mA 等信号。 频率 		
<b>AOL</b> <b>AOH</b>	Min. Val AO - mA Max. Val AO - mA	0 至 20 mA 0 至 20 mA	0 mA 20 mA
	参数  输出端 AO 和 AO1 (1) 上信号的最小和最大值。 这两个参数用于定义 AO 和 AO1 上的输出信号。例如：0-20mA、4-20mA、20-4mA 等		

(1) 如果安装了 I/O 扩展卡，则可以使用 AO 输出端。

## Control (控制) 菜单

代码	说明	调整范围	出厂设定
<b>Slr</b>	Save Ref.	NO-RAM-EEP	NO
	此功能与 +/- 速度功能相关, 用于保存给定值: 当运行命令消失 (保存在 RAM 中) 或进线电源消失时 (保存在 EEROM 中)。在下次启动时, 速度给定为上一次所保存的值。		
<b>LCC</b>	KeyPad Comm.	No - Yes	No
	用于通过操作盘激活变频器控制。STOP/RESET、RUN 和 FWD/REV 键有效。速度给定由参数 LFr 给出。在端子上仅有自由停车、快速停车、直流注入停车命令以及外部故障保持有效。如果变频器和操作盘的连接被切断, 变频器将锁定在 SLF 故障模式。  如果 LIX=FTK, 此功能不再能够通过键盘进行访问。		
<b>PSt</b>	STOP Priorit	No - Yes	Yes
	此功能将赋予 STOP 键优先权, 而不管控制方式如何 (操作盘或现场总线)。 将 PSt 参数变为 “no”: 1 - 显示 “no” 2 - 按 “ENT” 键 3 - 变频器显示 “See manual” (参见手册) 4 - 按▲和▼然后 “ENT” 对于连续运行的场合, 建议将按键配置为无效 (设置为 “no”)。		
<b>Rdd</b>	DriveAddress	0 至 3	0
	通过接头端口控制时的变频器地址 (拆除操作盘和编程终端)。		
<b>tbr</b>	BdRate RS485	9600-19200	19200
	通过 RS485 串口的传输速度 (在下次启动时有效) 9600 bps 19200 bps  如果 tbr ≠ 19200, 终端不再能够使用。要重新激活操作盘, 应通过串口将 tbr 重新配置为 19200, 或者返回出厂设定 (见 52 页)。		
<b>rPr</b>	Reset cnts	No-APH-RTH	No
	复位 kWh 或运行时间。 No APH: 将 kWh 复位为 0 RTH: 将运行时间复位为 0 复位命令必须使用 “ENT” 进行确认。 APH 和 RTH 会立即生效。此后参数自动返回 No		

## I/O (输入 / 输出) 菜单

此菜单可在开关处于  位置时进行访问。  
参数仅在停机模式下变频器锁定时才能修改。

代码	功能
L I2	LI2 Assign.
	见汇总表和功能说明。

菜单中可使用的输入和输出与变频器中安装的 I/O 卡 (如果有) 有关, 以及先前在控制菜单中所作的选择。

逻辑输入端定义汇总表 (2 线 / 3 线选件除外)

I/O 扩展选件卡		2 个逻辑输入 LI5-LI6
变频器无选件		3 个逻辑输入 LI2 - LI4
NO: Not assigned	(未定义)	X
RV: Reverse	(反向)	X
RP2: Switch ramp2	(斜坡切换)	X
JOG	(寸动运行)	X
+SP: + Speed	(+ 速度)	X
-SP: - Speed	(- 速度)	X
PS2:2 Preset Speed	(2 个预置速度)	X
PS4:4 Preset Speeds	(4 个预置速度)	X
PS8:8 Preset Speeds	(8 个预置速度)	X
NST: Freewhl Stop	(自由停车)	X
DCI: DC inject.	(直流注入停车)	X
FST: Fast stop	(快速停车)	X
CHP: Multi. Motor	(电动机切换)	X
FLO: Forced Local	(强制本机模式)	X
RST: Fault Reset	(故障复位)	X
RFC: Auto/Manu	(给定切换)	X
ATN: Auto Tuning	(自动调整)	X
PAU: PI Auto/Man	(PI 自动 / 手动) 若一个 AI = PIF	X
PR2: PI 2 Preset	(2 个预置 PI 给定) 若一个 AI = PIF	X
PR4: PI 4 Preset	(4 个预置 PI 给定) 若一个 AI = PIF	X
EDD: Ext flt.	(外部故障)	X
FTK: Forc.KeyP.	(强制为键盘)	X



注意: 如果某一逻辑输入被定义为“Freewheel stop”(自由停车)或“Fast stop”(快速停车), 则只能通过将此输入连接在 +24V 上进行起动, 因为这些停车功能在输入为 0 状态时有效。

## I/O (输入 / 输出) 菜单

编码器和模拟输入定义汇总表

I/O 扩展选项卡			模拟输入 AI3	编码器输入 A+, A-, B+, B- (1)
变频器无选项		模拟输入 AI2		
NO: Not assigned	(未定义)	X	X	X
FR2: Speed Ref2	(速度给定 2)	X	X	
SRI: Summed Ref.	(求和给定)	X	X	X
PIF: PI Regulator	(PI 调节器反馈)	X	X	
PIM: PI Man.ref.	(手动 PI 速度给定) 如果一个 AI = PIF		X	
SFB: Tacho feedbk	(测速发电机)		X	
PTC: Therm.Sensor	(PTC 传感器)		X	
RGI: PG feedbk	(编码器或检测器反馈)			X

(1) 注：定义编码器输入 A+、A-、B+、B- 称为 “Assign AI3”

逻辑输出定义汇总表

I/O 扩展选项卡			逻辑输出 LO
变频器无选项		继电器 R2	
NO: Not assigned	(未定义)	X	X
RUN: DriveRunning	(变频器运行)	X	X
OCC: Output Cont.	(出线接触器控制)	X	X
FTA: Freq Attain.	(达到频率阈值)	X	X
FLA: HSP Attained	(达到 HSP)	X	X
CTA: I Attained	(达到电流阈值)	X	X
SRA: FRH Attained	(达到频率给定值)	X	X
TSA: MtrTherm Lvl	(达到电动机热阈值)	X	X
APL: LossFollower	(4/20mA 信号缺失)	X	X
F2A: Freq.2 Att.	(达到频率 2 阈值)	X	X
tAd: ATU th.alarm	(达到变频器热阈值)	X	X

## I/O (输入 / 输出) 菜单

模拟输出定义汇总表

I/O 扩展选件卡		模拟输出 AO
变频器无选件		模拟输出 AO1
NO: Not assigned	(未定义)	X
OCR: Motor Curr.	(电动机电流)	X
QFR: Motor Freq	(电动机速度)	X
QRP: OutPut ramp	(斜坡输出)	X
QRS: Signed ramp	(有符号斜坡输出)	X
QPS: PI ref.	(PI 给定输出), 如果某一 AI = PIF	X
QPF: PI Feedback	(PI 反馈输出), 如果某一 AI = PIF	X
QPE: PI Error	(PI 误差输出), 如果某一 AI = PIF	X
QPI: PI Integral	(PI 积分输出), 如果某一 AI = PIF	X
QPR: OutPut Power	(电动机功率)	X
THR: MotorThermal	(电动机热状态)	X
THD: DriveThermal	(变频器热状态)	X

一旦 I/O 被重新定义后, 与此功能相关的参数将自动出现在菜单中, 并且宏配置将提示 “CUS: Customised”。某些重定义会产生新的调整参数, 用户不要忘记在调整菜单中对其进行配置:

I/O	定义	需设定的参数
LI	RP2 斜坡切换	RC2 DE2
LI	JOG 寸动运行	JOG JOt
LI	PS2 2 个预置速度	SP2
LI	PS4 4 个预置速度	SP2 - SP3 - SP4
LI	PS8 8 个预置速度	SP5 - SP6 - SP7 - SP8
LI	DCI 直流注入制动	IdC
LI	PR4 4 个预置 PI 给定	P12 - P13
AI	PIF PI 调节器反馈	rPG - rIG - P1C - PSP
AI	SFB 测速发电机	dtS
LO/R2	FTA 达到频率阈值	Ftd
LO/R2	CTA 达到电流阈值	Ctd
LO/R2	TSA 达到电动机热阈值	tdt
LO/R2	F2A 达到频率 2 阈值	F2d
LO/R2	TAD 达到变频器热阈值	dttd



## I/O (输入 / 输出) 菜单

某些重定义会产生新的调整参数，用户不要忘记在控制、传动或故障菜单中对其进行配置：

I/O	定义		需设定的参数
LI	-SP	- 速度	<i>S t r</i> (控制菜单)
LI	FST	快速停车	<i>d C F</i> (变频器菜单)
LI	RST	故障复位	<i>r S t</i> (故障菜单)
LI	CHP	电动机切换	<i>P C C</i> (变频器菜单)
AI	SFB	测速发电机	<i>S d d</i> (故障菜单)
A+, A-, B+, B-	SAI	求和给定	<i>P G t</i> , <i>P L S</i> (变频器菜单)
A+, A-, B+, B-	RGI	PG 反馈	<i>P G t</i> , <i>P L S</i> (变频器菜单)



## 可配置 I/O 的应用功能

### 功能兼容性表

应用功能选择可能受到某些功能间互不兼容的限制。未在此表中列出的功能为完全兼容。

	直流注入制动	求和输入	PI 调节器	+/- 速度	给定切换	自由停车	快速停车	寸动运行	预置速度	使用测速发电机或编码器的速度调节
直流注入制动						↑				
求和输入					●					
PI 调节器								●	●	●
+/- 速度					●			↑	●	
给定切换		●		●					●	
自由停车	←						←			
快速停车						↑				
寸动运行			●	←					←	
预置速度			●	●	●			↑		
使用测速发电机或编码器的速度调节			●							

●	不兼容功能
	兼容功能
	不适用
优先功能（不能同时有效的功能）：	
←	↑
箭头指示的功能较其他功能优先。	

停车功能优先于运行命令。  
通过逻辑命令的速度给定优先于模拟给定。



## 可配置 I/O 的应用功能

### 逻辑输入应用功能

运行方向：正向 / 反向

对于要求电动机仅单方向运转的场合，反向运行无效。

#### 2 线控制

运行 (正向或反向) 由同一个逻辑输入控制，以其 1 (运行) 或 0 (停车) 状态或状态改变表示 (见 2 线控制菜单)。

#### 3 线控制

运行 (正向或反向) 和停车由 2 个不同的逻辑输入进行控制。

L1 总是定义为停车功能。当这个端口处于开路状态 (0) 时，也就是停止命令。

运行输入端的脉冲存储至停车输入端开路时为止。

在通电或手动及自动故障复位时，仅在对 “forward” (正向)、 “reverse” (反向) 和 “injection stop” (直流注入停车) 命令进行复位之后才能通电。

斜坡切换：第 1 斜坡：ACC、dEC；第 2 斜坡：AC2、dE2

可以有两种类型的激活方式：

- 激活某个逻辑输入 Llx
- 检测可调整的频率阈值

如果某一逻辑输入端定义为此功能，则斜坡切换只能由该输入端进行。

单步运行 **JOG** (寸动)：低速运行脉冲

如果 JOG 触点闭合后运行方向触点被激励，则不管 ACC、dEC、AC2、dE2 的设置如何，斜坡均为 0.1s。如果方向触点闭合，然后 JOG 触点被激励，则使用配置的斜坡。

可在调整菜单中访问的参数：

- JOG (寸动) 速度
- 防重复延时 (2 个 “JOG” (寸动) 命令间的最小时间)



## 可配置 I/O 的应用功能

+/- 速度：有 2 种操作方式。

1. 使用单动作按钮：除运行方向之外还需增加两个逻辑输入。

定义为“+ speed”（速度）命令的输入提高速度，定义为“-speed”（速度）命令的输入降低速度。

此功能将访问 Control（控制）菜单中的 STr 保存给定值。

2. 使用双动作按钮：只需要一个定义为 + 速度的逻辑输入端。

使用双动作按钮 + 速度 +/- 速度：



说明： 对每个旋转方向两次按下 1 个按键。

每次动作闭合一个无电压触点。

	释放 (- 速度)	按第 1 次 (保持原速度)	按第 2 次 (+ 速度)
正向按钮	-	a	a 和 b
反向按钮	-	c	c 和 d

接线举例：

LI1: 正向  
LIx: 反向  
LIy: + 速度



+/- 速度的类型与 3 线控制不兼容。在这种情况下，- 速度功能自动定义为编号最高的逻辑输入端（例如：LI3（+ 速度），LI4（- 速度））。

在上述两种情况下，最大速度均由施用于模拟输入端的给定给出。例如，将 AI1 与 +10V 相连。

## 可配置 I/O 的应用功能

### 预置速度

可预置 2 个、4 个或 8 个速度，相应分别需要 1 个、2 个或 3 个逻辑输入端。

必须遵守以下的定义顺序：首先 PS2 (Llx)，其次是 PS4 (Lly)，最后为 PS8 (Llz)。

2 个预置速度		4 个预置速度			8 个预置速度			
定义：Llx 为 PS2		定义：Llx 为 PS2 然后 Lly 为 PS4			定义：Llx 为 PS2 然后 Lly 为 PS4，最后 Llz 为 PS8			
Llx	速度给定	Lly	Llx	速度给定	Llz	Lly	Llx	速度给定
0	LSP+ 给定	0	0	LSP+ 给定	0	0	0	LSP+ 给定
1	SP2	0	1	SP2	0	0	1	SP2
		1	0	SP3	0	1	0	SP3
		1	1	SP4	0	1	1	SP4
					1	0	0	SP5
					1	0	1	SP6
					1	1	0	SP7
					1	1	1	SP8

要解除对逻辑输入端的定义，必须按照以下的顺序：PS8 (Llz)，然后 PS4 (Lly)，最后 PS2 (Llx)。

### 给定切换


配置 AI1/AI2 给定切换：

- 确认 LI 没有配置为“RFC: Auto/Manu”（如已配置，则应将 LI 配置为“NO: Not assigned”）。
- 将一个 LI 配置为“RFC: Auto/Manu”。此时第 2 给定为 AI2。

配置 AI1/AI3 给定切换：

- 确认 LI 没有配置为“RFC: Auto/Manu”（如已配置，则应将 LI 配置为“NO: Not assigned”）。
- 将 AI3 配置为“FR2: Speed Ref2”。
- 将一个 LI 配置为“RFC: Auto/Manu”。此时第 2 给定为 AI3。

### 接线图



### 自由停车

仅靠阻力矩使电动机停车。电动机 电源被切断。

逻辑输入端开路 (0 状态) 时即可获得自由停车。

### 直流注入停车

逻辑输入端闭合 (1 状态) 时即可直流注入停车。

### 快速停车

制动停车，其减速斜坡时间按照变频器菜单中出现的缩减因数 dCF 进行缩减。

逻辑输入端开路 (0 状态) 时即可快速停车。

## 可配置 I/O 的应用功能

### 电动机切换

此功能允许两台额定值不同的电机使用同一台变频器顺序驱动，切换通过变频器输出端适当的时序完成。此切换必须在电动机停机且变频器锁定时进行。以下内部参数由逻辑命令自动切换：

- 电动机额定电流
- 注入电流

此功能将自动禁止第二个电机上的热保护。  
可访问参数：变频器菜单中的 PCC 电动机额定值比率。

### 故障复位

有两种类型的复位：部分复位或整体复位（“fault”（故障）菜单中的 rSt 参数）。

部分复位 (rSt = RSP):

用于在故障原因已经消失的情况下清除存储的故障状态，并对变频器进行复位。

部分清除所影响的故障状态：

- |           |             |         |
|-----------|-------------|---------|
| - 线路过电压   | - 通讯故障      | - 电动机过热 |
| - 直流母线过电压 | - 电动机过载     | - 串口故障  |
| - 电动机缺相   | - 4-20mA 缺失 | - 变频器过热 |
| - 正在检修    | - 外部故障      | - 过速    |

整体复位 (rSt = RSG):


在所定义的逻辑输入端闭合时它将禁止除 **SCF**（电机短路）外的所有故障状态（强制运行）。

### 强制本机模式

用于在线控模式（串口）和本机模式（通过端子板或端子控制）之间进行切换。

### 自动学习

当定义的逻辑输入端变为 1 时触发一个自学习操作，与“drive”（传动）菜单中的参数 tUn 相同方式。

 注意：自学习只能在没有激活任何命令的时候进行。如果“freewheel stop”（自由停车）或“fast stop”（快速停车）功能已定义为某一逻辑输入端，则此输入端必须被设为 1（0 时有效）。

应用：例如电动机切换。

预置 **PI** 自动 - 手动，**PI** 给定：见 **PI** 功能（第 44 页）

### 外部故障

当所定义的逻辑输入端变为 1 时，电动机停车（按照 Drive（变频器）菜单中 LSF Stop+flt 参数的配置），且变频器锁定在 EPF external fault 故障模式。

### 强制为键盘模式

允许 1 个 LI 用于选择本机控制：

如果 LIX=FTK 且 FTK=0：由控制端子进行操作

如果 LIX=FTK 且 FTK=1：由键盘进行控制



- 如果 LIX=FTK，则控制菜单中的 **LCC** 功能将不能再由键盘进行访问。继而将不能使用键盘控制变频器。
- 当 FTK 已被置为无效时，需要在控制菜单中使 **LCC** 功能重新有效。

## 可配置 I/O 的应用功能

### 模拟输入端应用功能

输入端 AI1 总是作为速度给定。

#### AI2 和 AI3 定义

求和速度给定：由 AI2 和 AI3 给出的频率 给定以进行求和，并将和值赋予 AI1。

使用测速发电机的速度调节：( 仅在使用带有模拟输入端的 I/O 扩展卡时定义为 AI3)：用于通过测速发电机进行的速度校正。

需要外部分压电桥对测速发电机的电压进行调整。最大电压必须在 5 到 9V 之间。此后通过在调整菜单中设定参数 dtS 完成精确的设定。

PTC 传感器保护：( 仅当使用带有模拟输入端的 I/O 扩展卡时 )。用于将电动机绕组中的 PTC 传感器与模拟输入端 AI3 相连，以此实现电动机的直接热保护。

PTC 传感器特性：

20°C 时传感器电路的总电阻 = 750 欧姆


PI 调节器：用给定和传感器给出的反馈进行过程调节。在 PI 模式中即使配置不同，斜坡也全部为线性。

使用 PI 调节器，可以：

- 通过 FbS 对反馈进行调整。
- 校正 PI 倒置。
- 调整比例和积分增益 (RPG 和 RIG)。
- 为 PI 给定、PI 反馈和 PI 误差定义一个模拟输出端。
- 若  $PSP > 0$  则在起动时施用一斜坡以确定 PI (AC2) 的动作。
- 若  $PSP = 0$  则有效斜坡为 ACC/dEC。dEC 斜坡总是在停车时使用。

电动机速度被限制在 LSP 和 HSP 之间。

注：如果某一 AI 输入端被定义为 PI 反馈，则 PI 调节器模式有效。这项 AI 定义只能在禁止所有与 PI 不兼容的功能之后才能进行 ( 见 39 页)。



- 自动 / 手动：此功能仅当 PI 功能有效时才能被访问，而且需要带有模拟输入端的 I/O 扩展卡
- 通过逻辑输入端 LI, LIx = 0 (AI3 的手动基准) 时它用于切换至速度调节操作, LIx = 1 (自动) 时为 PI 调节。

## 可配置 I/O 的应用功能

预置速度：

2 或 4 个预置速度分别要求使用 1 个或 2 个逻辑输入端：

2 个预置速度		4 个预置速度	
定义：Llx 为 Pr2		定义：Llx 为 Pr2，Lly 为 Pr4	
Llx	给定	Lly	Llx 给定
0	模拟给定	0	0 模拟给定
1	过程最大值 (= 10 V)	0	1 PI2 (可调节)
		1	0 PI3 (可调节)
		1	1 过程最大值 (= 10V)

中文

### 编码器输入应用功能

(仅针对带有编码器输入端的 I/O 扩展卡)

速度调节：用于通过增量编码器和检测器对速度进行校正 (参见随卡提供的文档)。

求和速度给定：由编码器输入端提供的给定求和赋予 AI1。(参见随卡提供的文档)。

应用场合：

- 若干变频器间的速度同步。“drive”(变频器)菜单中的参数 PLS 用于调整一台电机于其他电机之间的速度比。
- 通过编码器提供给定。

### 逻辑输出应用功能

继电器 R2、LO 固态输出 (使用 I/O 扩展卡)

出线接触器控制 (OCC): 可被定义在 R2 或 LO 端

允许变频器控制一个输出接触器 (位于变频器和电动机之间)。当出现运行命令时发出闭合接触器的要求。当没有供给电动机的电流时发出断开接触器的要求。



如果配置了直流注入制动功能，则不应在停机模式下运行过长时间，因为接触器只在制动过程未断开。

变频器运行 (RUN): 可被定义在 R2 或 LO 端

如果电动机电源由变频器提供 (有电流) 或有带零给定的运行命令，则逻辑输出端为 1 状态。

达到频率阈值 (FTA): 可被定义在 R2 或 LO 端

电动机频率大于或等于调整菜单中由 Ftd 设定的频率阈值时，逻辑输出端为 1 状态。

达到频率 2 阈值 (F2A): 可被定义在 R2 或 LO 端

电动机频率大于或等于调整菜单中由 F2d 设定的频率阈值时，逻辑输出端为 1 状态。

达到给定值 (SRA): 可被定义在 R2 或 LO 端

当电动机频率等于给定值时逻辑输出端为 1 状态。

## 可配置 I/O 的应用功能

**达到高速 (FLA):** 可被定义在 R2 或 LO 端  
电动机频率等于 HSP 时逻辑输出端为 1 状态。

**达到电流阈值 (CTA):** 可被定义在 R2 或 LO 端  
电动机电流大于或等于调整菜单中由 Ctd 设定的电流阈值时, 逻辑输出端为 1 状态。

**达到电动机热状态 (TSA):** 可被定义在 R2 或 LO 端  
电动机热状态大于或等于调整菜单中由 ttd 设定的电机热状态时, 逻辑输出端为 1 状态。

**达到变频器热状态 (TAD):** 可被定义在 R2 或 LO 端  
变频器热状态大于或等于调整菜单中由 dtd 设定的变频器热状态时, 逻辑输出端为 1 状态。

**信号丢失跟踪 (APL):** 可定义在 R2 或 LO 端  
4-20mA 输入端的信号低于 2mA 时逻辑输出为 1。

## 模拟输出端 AO 和 AO1 的应用功能

模拟输出端 AO 和 AO1 为电流输出端, 输出范围从 AOL (mA) 到 AOH (mA)。

- AOL 和 AOH 可以在 0 至 20mA 之间配置。

AOL 及 AOH 举例 :  
0 - 20mA  
4 - 20 mA  
20 - 4 mA

**电动机电流 (代码 OCR):** 电动机电流有效值的映像。

- AOH 对应于变频器额定电流的 2 倍。
- AOL 对应于零电流。

**电动机频率 (代码 OFR):** 由变频器估算的电动机频率。

- AOH 对应于最高频率 (参数 tFr)。
- AOL 对应于零频率。

**斜坡输出 (代码 ORP):** 斜坡输出频率的映像。

- AOH 对应于最高频率 (参数 tFr)。
- AOL 对应于零频率。

**有符号斜坡 (代码 ORS):** 斜坡输出频率和方向的映像。

- AOL 对应于反向运行中的最高频率 (参数 tFr)。
- AOH 对应于正向运行中的最高频率 (参数 tFr)。
- $\frac{AOH + AOL}{2}$  对应于零频率。


**PI 给定 (代码 OPS):** PI 调节器给定的映像。

- AOL 对应于最小给定。
- AOH 对应于最大给定。

**PI 反馈 (代码 OPF):** PI 调节器反馈的映像。

- AOL 对应于最小反馈。
- AOH 对应于最大反馈。





## 可配置 I/O 的应用功能



**PI 误差 (代码 OPE):** 作为传感器量程 (最大反馈 - 最小反馈) 百分比的 PI 调节器误差映像。

- AOL 对应于最大误差  $< 0$ 。
- AOH 对应于最大误差  $> 0$ 。
- $\frac{AOH + AOL}{2}$  对应于零误差 (OPE = 0)。

**PI 积分 (代码 OPI):** PI 调节器误差积分的映像。

- AOL 对应于零积分。
- AOH 对应于饱和积分。

**电动机功率 (代码 OPR):** 电动机功率消耗的映像。

- AOL 对应于电动机额定功率的 0%。
- AOH 对应于电动机额定功率的 200%。

**电动机热状态 (代码 THR):** 电动机热状态的映像，计算所得。


- AOL 对应于 0%。
- AOH 对应于 200%。

**变频器热状态 (代码 THD):** 变频器热状态的映像，计算所得。




- AOL 对应于 0%。
- AOH 对应于 200%。



## Fault (故障) 菜单

此菜单可在开关处于  位置时进行访问。  
参数仅在停机模式下变频器锁定时才能修改。


中文

代码	功能	出厂设定
<b>Alt r</b>	<b>Auto Restart</b> 此功能用于在故障消失后对变频器进行自动重启动 (Yes/No 选择)。 在下列故障后可进行自动重启动： - 线路过电压 - 直流母线过电压 - 外部故障 - 电动机缺相 - 串口故障 - 通讯故障 - 4-20mA 信号缺失 - 电动机过载 (条件：电动机热状态低于 100%) - 变频器过热 (条件：变频器热状态低于 70%) - 电动机过热 (条件：传感器电阻低于 1,500 欧姆) 当此功能被激活时，伴随一种或多种故障的出现，R1 继电器保持闭合：变频器每 30s 尝试启动一次。 变频器不能启动 (存在故障) 时最多可进行 6 次尝试。如果 6 次全部失败，则变频器将最终保持在锁定状态，故障继电器开路，直至通过变频器断电进行复位。  此功能要求保持相关的顺序。应确保意外的重启动不会对设备和人员造成任何危险。	No
<b>rSt</b>	<b>Reset Type</b> 如果某一逻辑输入端被定义为故障复位，则可以访问此功能。2 种可能的选项：部分复位 (RSP)，整体复位 (RSG) 部分复位所涉及的故障 (rSt = RSP) - 电源过电压 - 电动机过载 - 电动机过热 - 电动机缺相 - 串口故障 - 通讯故障 - 直流母线过电压 - 4-20mA 缺失 - 正在检修 - 变频器过热 - 外部故障 - 过速 整体复位所涉及的故障 (rSt = RSG): 所有故障。整体复位会禁止所有故障 (强制运行)。 要配置 rSt = RSG: 1 显示 RSG 2 按 “ENT” 键 3 变频器显示 “See manual” (见手册) 4 按  后按  然后按 “ENT”	RSP
<b>DPL</b>	<b>OutPhaseLoss</b> 电动机缺相故障 (如果在变频器与电机间使用了隔离器，则可去除此故障)。选择：Yes/No	Yes
<b>IPL</b>	<b>InPhaseLoss</b> 线路电压缺相故障 (如果有通过直流母线给出的直流电源，则可去除此故障)。选择：Yes/No	Yes


## Fault (故障) 菜单

代码	说明	出厂设定
<b>ThHt</b>	ThermProType	ACL
	确定由变频器提供的间接电动机热保护的类型。如果变频器上连接了 PTC 传感器，则此功能不可用。无热保护：NO：无保护自冷却电动机 (ACL)：变频器将根据转动频率计入所有降容因素。强制冷却电机 (FCL)：变频器不考虑旋转频率造成的降容。	
<b>LFL</b>	LossFollower	No
	用于允许 4-20mA 给定缺失故障。 只能在 AI2 最大最小给定参数 (CrL 和 CrH) 大于 3mA 或 CrL>CrH 时才能对此故障进行配置。 - No: 无故障 - Yes: 立即性故障 - Stt: 根据 Stt 参数停车，无故障，信号返回时重新启动 - LSF: 根据 Stt 参数停车，在停车结束时给出故障状态 - LFF: 强制为 LFF 参数设定的低效运行速度 - RLS: 在出现 4-20mA 信号缺失时维持所达到的速度，无故障，信号返回时重新启动。	
<b>LFF</b>	4-20 Flt Spd	0
	出现 4-20mA 信号缺失时的低效运行速度。 调整范围从 0 到 HSP。	
<b>FLr</b>	Catch On Fly	Yes
	用于在以下一种情况出现时实现平滑重启动： - 进线电源缺失或简单断电 - 故障复位或自动重启动 - 自由停车或使用逻辑输入端的直流注入制动 - 不可控制的变频器出线缺失 选择：Yes/No	
<b>StP</b>	Cont. Stop	No
	某一相线缺失时的可控停车。此功能仅在参数 IPL 设为 No 时才能使用。 如果 IPL 设置为 Yes，应让 StP 留在 No 位置。可能的选项： <b>No</b> : 进线电源缺失时锁定 <b>MMS</b> : Maintain Bus (保持母线)：变频器控制单元将由惯性力产生的动能继续驱动，直至出现 USF 故障 (欠压) <b>FRP</b> : Follow Ramp (跟踪斜坡)：沿编制好的 dEC 或 dE2 斜坡减速，直至停止或出现 USF (欠压) 故障	
<b>Sdd</b>	RampNotFall	Yes
	如果已对测速发电机或脉冲发电机反馈进行了编程，则可以访问此功能。当有效时，它用于在检测到速度误差 (定子频率与测得速度之间的差别) 时锁定变频器。 选项：Yes/No	
<b>EPL</b>	External fault	Yes
	定义出现外部故障时的停车类型： - Yes: 立即停车故障 - LSF Stop+flt: 根据 Stt 参数停车，然后在停机过程结束时给出故障提示	

## Files (文件) 菜单

此菜单可在开关处于  位置时进行访问。  
参数仅在停机模式下变频器锁定时才能修改。

操作盘用于存储 4 个包含变频器配置的文件。


中文	代码	说明	出厂设定
	F 15	File 1 State	FRE
	F 25	File 2 State	FRE
	F 35	File 3 State	FRE
	F 45	File 4 State	FRE
		用于显示相应文件的状态。 可能的状态: <b>FRE:</b> 空文件 (操作盘发货时的状态) <b>EnG:</b> 配置已存入此文件中	
	F 06	Operat. Type	NO
		用于选择要对文件进行的操作。 可能的操作: <b>NO:</b> 没有操作要求 (与变频器的每个新操作盘连接的缺省值) <b>STR:</b> 将变频器配置保存到操作盘上文件中的操作 <b>REC:</b> 将文件内容传送到变频器 <b>Ini:</b> 使变频器返回出厂设定   返回出厂设定将会取消所有的用户调整和配置。	

### 操作模式

选择 STR, REC 或 Ini 并按下 “ENT”

- 1 若 Operat.Type = STR:  
将显示文件号码。使用 ▲ 或 ▼ 选择文件, “ENT” 进行确认。
- 2 若 Operat.Type = REC:  
将显示文件号码。使用 ▲ 或 ▼ 选择文件, “ENT” 进行确认。


- 显示屏提示:



- 检查接线与文件配置是否一致。  
使用 “ESC” 取消或 “ENT” 确认。  
- 此时显示要求使用 “ENT” 或 “ESC” 进行第 2 次确认或取消。

- 3 若 Operat.Type = Ini  
- 使用 “ENT” 确认。

- 显示屏提示:



- 检查接线与出厂配置是否一致。  
使用 “ESC” 取消或 “ENT” 确认。  
- 此时显示要求使用 “ENT” 或 “ESC” 进行第 2 次确认或取消。

每次操作结束后显示屏将返回 “Operat.Type”, 参数设定为 “NO”。

## Files (文件) 菜单

### 文件菜单 (续)

代码	说明
C O d	Password
	密码

变频器配置可以使用密码进行保护 (COd)。

注意：此参数应谨慎使用。它将禁止对所有参数的访问。对这一参数的任何修改都必须进行仔细记录和保存。

代码值由 4 个数字给出，最后 1 位用于确定用户要求的访问级别。

8 8 8 8

此数字给出在没有正确密码的情况下所允许的访问级别。

根据操作盘后面访问锁定开关的位置，总是可以在密码的权限范围内实现对菜单的访问。

代码值 0000 (出厂设定) 不限制访问。

下表定义了根据代码中的最后数字对菜单的访问权。

菜单	代码中的最后数字		
	访问锁定	显示	修改
Adjustments (调整)	0 exc. 0000 和 9	1	2
2 级： Adjustments (调整)、Macro-config (宏配置)、 Drive (变频器)、Control (控制)、I/O (输入/输出)、 Faults (故障) Files (文件) (不包括代码)、 Communication (通讯) (如果有卡)	0 exc. 0000 和 9	3	4
Application (应用) (如果有卡)	0 exc. 0000 和 9	5	6
2 级和 Application (应用) (如果有卡)	0 exc. 0000 和 9	7	8

关于对 APPLICATION (应用) 菜单的访问，参见应用卡的文档。

使用 ▲ 和 ▼ 键对密码进行修改。

如果输入了错误的密码，访问将被拒绝并显示以下信息：




按下键盘上的 ENT 或 ESC 键之后，Code (密码) 参数显示的值将变为 0000，但访问权限级别不会改变。此操作应重复进行。

要访问使用访问密码保护的菜单，用户必须首先输入该密码，它在 Files (文件) 菜单中总可以访问。

## Communication and Application ( 通讯和应用菜单 ) / 返回出厂设.

中文

### 通讯和应用菜单


安装有通讯或应用卡才会显示此菜单。当开关处于  位置时可对其进行访问。仅在停机模式下变频器锁定时才能进行配置。

关于使用通讯或应用选件卡的情况，请参考随该卡提供的文档。

关于在变频器主机通过 RS485 串口进行的通讯，请参考随 RS485 连接套件提供的文档。

### 返回出厂设定

- 目的是仅使用键盘 ( 见 50 页 )
- 使用下述方法进行：




- 关闭变频器
- 开锁并打开 Altivar 外盖，选择控制卡上的 50/60Hz 开关 (1)。如果有选件卡，则可通过它接近选件开关。
- 改变控制卡上 50/60Hz 开关 (1) 的位置
- 开启变频器
- 关闭变频器
- 将控制卡上的 50/60Hz 开关 (1) 复位为其初始位置 (电动机额定频率)
- 开启变频器，变频器将返回其出厂配置。



## 运行 - 维护 - 备件及修理

### 运行

Altivar 前面板上的信号指示



绿色 POWER LED  
红色 FAULT LED



- 亮: Altivar 通电
- 亮: Altivar 故障
  - 闪烁: 按下操作盘上的“STOP”键, 或者改变配置后 Altivar 即被锁定。此时只能先对“forward”(正向)、“reverse”(反向)和“injection stop”(注流停车)命令进行复位后才能给电动机供电。

中文

### 操作盘显示屏的显示模式

显示预置频率给定, 或故障。

显示模式可以通过操作盘进行修改: 参阅编程手册。

### 维护

在对变频器进行任何操作之前, 应关闭电源, 确认绿色 LED 已熄灭, 等待电容器放电完毕 (根据变频器额定功率的不同为 3 到 10 分钟)。



根据电源电压的不同, 直流母线的 + 和 - 端子或 PA 和 PB 端子上的电压可能会达到 850V。

如果在设置或运行过程中出现问题, 应注意与环境、安装和连接相关的建议是否得到遵守。

#### 维护

Altivar 38 不需要预防性的维护工作。尽管如此我们仍建议您定期做以下工作:

- 检查连接情况和紧固程度
- 应确保部件周围的温度保持在可接受的水平, 并且通风有效 (风扇的平均使用寿命为 3 至 5 年, 取决于运行条件)
- 去除变频器中的所有灰尘

#### 维护帮助

首次检测到的故障被存储起来并显示在操作盘显示屏上: 变频器锁定, 红色 LED (FAULT) 亮, 且故障继电器 R1 脱扣。

#### 清除故障

- 出现不可复位的故障时应切断变频器的电源。
- 找出故障的原因以便将其消除。
- 重新连接电源: 如果故障已经消失则将其清除。
- 如果定制了自动重启功能, 则在某些情况下一旦故障消失后设备会自动重启。

### 备件和修理

如需 Altivar 38 变频器备件或对其进行修理, 请咨询施耐德集团的产品支持部门。

## 故障 - 原因 - 处理办法

显示的故障	可能原因	规程, 处理办法
<i>P H F</i> Mains Phase Loss	<ul style="list-style-type: none"> <li>变频器电源不正确或熔丝烧毁</li> <li>某一相瞬间故障</li> <li>变频器由直流母线供电</li> </ul>	<ul style="list-style-type: none"> <li>检查动力线连接和熔丝</li> <li>复位</li> <li>将在 FAULT (故障) 菜单中的 “InPhaseLoss” (缺相) 故障 (代码 IPL) 配置为 “No”</li> </ul>
<i>U S F</i> Undervoltage	<ul style="list-style-type: none"> <li>电源电压过低</li> <li>瞬时电压下降</li> <li>负载电阻损坏</li> </ul>	<ul style="list-style-type: none"> <li>检查进线电压</li> <li>更换负载电阻</li> </ul>
<i>O S F</i> Overvoltage	<ul style="list-style-type: none"> <li>电源电压过高</li> </ul>	<ul style="list-style-type: none"> <li>检查进线电压</li> </ul>
<i>O H F</i> Drive Overheated	<ul style="list-style-type: none"> <li>散热器温度过高 (<math>t_{Hd} &gt; 118\%</math>)</li> </ul>	<ul style="list-style-type: none"> <li>监测电动机负载、变频器通风, 并等待变频器冷却后再进行重新启动。</li> </ul>
<i>O L F</i> Mot Overload	<ul style="list-style-type: none"> <li>长时间过载引起热脱扣 (<math>t_{Hr} &gt; 118\%</math>)</li> </ul>	<ul style="list-style-type: none"> <li>检查热保护设定, 检测电动机负载</li> <li>在大约 7 分钟之后可进行复位</li> </ul>
<i>O b F</i> Overbraking	<ul style="list-style-type: none"> <li>制动过猛或驱动负载过大</li> <li>运行过程中进线电源过电压</li> </ul>	<ul style="list-style-type: none"> <li>增加减速时间, 如有必要可加装一个制动电阻</li> <li>检查是否有进线过电压</li> </ul>
<i>O P F</i> Motor Phase Loss	<ul style="list-style-type: none"> <li>变频器输出端某一相开路</li> </ul>	<ul style="list-style-type: none"> <li>检查电动机连接情况, 出线接触器是否闭合 (如果有)</li> <li>如果在宏配置中使用了电动机起动器, 应检查 R2 继电器是否被配置为出线接触器</li> </ul>
<i>L F F</i> LossFollower	<ul style="list-style-type: none"> <li>输入端 AI2 的 4-20mA 信号缺失</li> </ul>	<ul style="list-style-type: none"> <li>检查给定电路的连接</li> </ul>
<i>O C F</i> Overcurrent	<ul style="list-style-type: none"> <li>斜坡过短</li> <li>惯性或负载过高</li> <li>机械锁定</li> </ul>	<ul style="list-style-type: none"> <li>检查设定</li> <li>检查电动机、变频器和负载的大小</li> <li>检查机构的状态</li> </ul>
<i>S C F</i> Short Circuit	<ul style="list-style-type: none"> <li>变频器输出端短路或接地</li> </ul>	<ul style="list-style-type: none"> <li>在断开变频器的情况下检查连接电缆以及电动机的绝缘。</li> <li>检查变频器晶体管电桥</li> </ul>
<i>C r F</i> Precharge Fault	<ul style="list-style-type: none"> <li>负载继电器控制故障</li> <li>负载电阻损坏</li> </ul>	<ul style="list-style-type: none"> <li>检查变频器的接头和负载电阻</li> </ul>
<i>S L F</i> RS485 Flt	<ul style="list-style-type: none"> <li>变频器接头端口上的连接错误</li> </ul>	<ul style="list-style-type: none"> <li>检查变频器接头端口的连接</li> </ul>
<i>O t F</i> Motor Overheated	<ul style="list-style-type: none"> <li>电动机温度过高 (PTC 传感器)</li> </ul>	<ul style="list-style-type: none"> <li>检查电动机通风和环境温度, 并检测电动机负载</li> <li>检查所使用的传感器类型</li> </ul>
<i>t S F</i> PTC Probe Fault	<ul style="list-style-type: none"> <li>传感器连接至变频器错误</li> </ul>	<ul style="list-style-type: none"> <li>检查传感器与变频器的连接</li> <li>检查传感器</li> </ul>



## 故障 - 原因 - 处理办法

显示的故障	可能原因	规程, 处理办法
EEF EEPROM Fault	<ul style="list-style-type: none"> <li>EEPROM 中存有错误</li> </ul>	<ul style="list-style-type: none"> <li>切断变频器电源并复位</li> </ul>
INF Internal Fault	<ul style="list-style-type: none"> <li>内部故障</li> <li>连接端子故障</li> </ul>	<ul style="list-style-type: none"> <li>检查变频器的连接端子</li> </ul>
EPF External Fault	<ul style="list-style-type: none"> <li>由外部设备触发的故障</li> </ul>	<ul style="list-style-type: none"> <li>检查导致故障的设备并复位</li> </ul>
S PF SP. Feedbk. Loss	<ul style="list-style-type: none"> <li>无速度反馈</li> </ul>	<ul style="list-style-type: none"> <li>检查速度传感器的连接和机械耦合</li> </ul>
RF Load Veer. Flt	<ul style="list-style-type: none"> <li>不跟踪斜坡</li> <li>与给定相反的速度</li> </ul>	<ul style="list-style-type: none"> <li>检查速度反馈设定和接线</li> <li>检查负载设定是否适合</li> <li>检查电动机 - 变频器的大小以及是否需要制动电阻</li> </ul>
S OF Overspeed	<ul style="list-style-type: none"> <li>不稳定</li> <li>驱动负载过高</li> </ul>	<ul style="list-style-type: none"> <li>检查设定和参数</li> <li>加装制动电阻</li> </ul> <p>检查电动机、变频器和负载的大小</p>
LF Network Fault	<ul style="list-style-type: none"> <li>现场总线通讯故障</li> </ul>	<ul style="list-style-type: none"> <li>检查变频器的网络连接</li> <li>检查超时</li> </ul>
ILF Int. Comm. Flt	<ul style="list-style-type: none"> <li>选件卡和控制卡间通讯故障</li> </ul>	<ul style="list-style-type: none"> <li>检查选件卡与控制卡间的连接</li> </ul>
FFF Rating Fault-ENT Option Fault-ENT  Opt. Missing-ENT CKS Fault - ENT	<p>选件卡的改动可能导致错误:</p> <ul style="list-style-type: none"> <li>改变功率卡的额定值</li> <li>在没有选件卡或宏配置为 CUS 时改变选件卡的类型或安装选件卡</li> <li>拆除选件卡</li> <li>保存了不一致的配置</li> </ul> <p>按 ENT 产生如下信息: Fact.Set ENT/ESC</p>	<ul style="list-style-type: none"> <li>检查变频器硬件配置 (功率卡, 其他)</li> <li>切断变频器电源然后复位</li> <li>在操作盘中将配置保存在文件中</li> <li>按 ENT 返回出厂设定</li> </ul>
CFI Config. Fault	<ul style="list-style-type: none"> <li>通过串口发送的配置不一致</li> </ul>	<ul style="list-style-type: none"> <li>检查先前发送的配置</li> <li>发送一致的配置</li> </ul>



## 故障 - 原因 - 处理办法

中文

没有故障显示的功能失灵

显示	可能原因	规程, 处理办法
无代码, LED 不亮	<ul style="list-style-type: none"><li>无电源</li></ul>	<ul style="list-style-type: none"><li>检查变频器电源</li></ul>
无代码, 绿色 LED 亮, 红色 LED 亮或不亮	<ul style="list-style-type: none"><li>控制盘失效</li></ul>	<ul style="list-style-type: none"><li>检查控制盘</li></ul>
故障代码 绿色 LED 亮	<ul style="list-style-type: none"><li>变频器处于运行模式, 使用通讯卡或 RS 485 套件</li><li>一个 LI 输入端被定义为 “Freewheel stop” (自由停车) 或 “Fast stop” (快速停车), 且此输入端未通电。停车由输入缺失进行控制</li></ul>	<ul style="list-style-type: none"><li>设定参数 LI4 为强制本机模式, 然后使用 LI4 对此模式进行确认</li><li>将输入端连接到 24V 上以禁止停车</li></ul>

## 配置和调整记录

变频器型号 ATV38 ..... 显示屏型号: .....

用户识别号码 (如适用): .....

选件卡: 无 ☐ 有 ☐: 型号 .....访问密码: 无 ☐ 有 ☐: .....

操作盘上的配置文件号 .....

宏 - 配置: .....

对于 **CUS: customised** 配置, 应对 I/O 进行如下定义:

	ALTIVAR	选件卡
逻辑输入	LI 1: LI 2: LI 3: LI 4:	LI 5: LI 6:
模拟输入	AI 1: AI 2:	AI 3:
编码器输入		AI3:
继电器	R2:	
逻辑输出		LO:
模拟输出	AO1:	AO:

调整参数:

代码	出厂设定	用户设定 (1)	代码	出厂设定	用户设定 (1)
<b>RLC</b>	3 s	s	<b>SP5</b>	25 Hz	Hz
<b>dEC</b>	3 s	s	<b>SP6</b>	30 Hz	Hz
<b>LSP</b>	0 Hz	Hz	<b>SP7</b>	35 Hz	Hz
<b>HSP</b>	50 Hz	Hz	<b>SP8</b>	50 Hz	Hz
<b>FLG</b>	20 %	%	<b>JOG</b>	10 Hz	Hz
<b>StA</b>	20 %	%	<b>JGt</b>	0,5 s	s
<b>ltH</b>	根据型号确定	A	<b>FFt</b>	0 Hz	Hz
<b>ldC</b>	根据型号确定	A	<b>bIP</b>	no	
<b>EdC</b>	0,5 s	s	<b>rPG</b>	1	
<b>SDC</b>	0,5 ltH	A	<b>rIG</b>	1 / s	/s
<b>RL2</b>	5 s	s	<b>Fb5</b>	1	
<b>dE2</b>	5 s	s	<b>PIC</b>	no	
<b>JPF</b>	0 Hz	Hz	<b>dt5</b>	1	
<b>JF2</b>	0 Hz	Hz	<b>CLd</b>	1,1 In	A
<b>JF3</b>	0 Hz	Hz	<b>tdt</b>	100 %	%
<b>EL5</b>	0	s	<b>P5P</b>	0 s	s
<b>USC</b>	1		<b>P12</b>	30 %	%
<b>UFr</b>	100 %	%	<b>P13</b>	60 %	%
<b>PFL</b>	20 %	%	<b>dt d</b>	105 %	%
<b>SP2</b>	10 Hz	Hz	<b>Ftd</b>	50 Hz	Hz
<b>SP3</b>	15 Hz	Hz	<b>F2d</b>	50 Hz	Hz
<b>SP4</b>	20 Hz	Hz			

(1) 参数丢失时为空白。



## 配置和调整记录

### 变频器菜单参数

代码	出厂设定	用户设定 (1)	代码	出厂设定	用户设定 (1)
<b>Un5</b>	根据型号确定	V	<b>rPt</b>	LIN	
<b>Fr5</b>	50 Hz	Hz	<b>dLf</b>	4	
<b>nCr</b>	根据型号确定	A	<b>CLl</b>	1,1 In	A
<b>nSP</b>	根据型号确定	rpm	<b>RdC</b>	yes	
<b>CD5</b>	根据型号确定		<b>PLC</b>	1	
<b>tUn</b>	no		<b>SFe</b>	LF	
<b>tFr</b>	60 Hz	Hz	<b>SFr</b>	根据型号确定	kHz
<b>nLd</b>	yes		<b>nrd</b>	yes	
<b>Fdb</b>	no		<b>SPC</b>	no	
<b>brA</b>	yes		<b>PGE</b>	DET	
<b>FrE</b>	0 Hz		<b>PL5</b>	1024	
<b>StE</b>	STN				

(1) 参数缺失时保留空格

代码	出厂设定	用户设定 (1)	代码	出厂设定	用户设定 (1)
<b>tCC</b>	2 W		<b>RQH</b>	20 mA	mA
<b>tCt</b>	LEL		<b>StE</b>	No	
<b>rIn</b>	no		<b>LCC</b>	no	
<b>bSP</b>	no		<b>PSt</b>	yes	
<b>CrL</b>	4 mA	mA	<b>Rdd</b>	0	
<b>CrH</b>	20 mA	mA	<b>tbr</b>	19200	
<b>RDL</b>	0 mA	mA	<b>rPr</b>	No	

(1) 参数缺失时保留空格

### 故障菜单参数：

代码	出厂设定	用户设定 (1)	代码	出厂设定	用户设定 (1)
<b>Rtr</b>	no		<b>LFf</b>	0 Hz	Hz
<b>rSt</b>	RSP		<b>FLr</b>	yes	
<b>DPL</b>	yes		<b>StP</b>	no	
<b>IPL</b>	yes		<b>Sdd</b>	yes	
<b>tHt</b>	ACL		<b>EPL</b>	yes	
<b>LFL</b>	no				

(1) 参数丢失时保留空格。

## 菜单汇总

### LANGUAGE (语言) 菜单

名称	代码
English	<i>L n G</i>
Français	<i>L n G</i>
Deutsch	<i>L n G</i>
Español	<i>L n G</i>
Italiano	<i>L n G</i>

### MACRO-CONFIG (宏配置) 菜单

名称	代码
QT:Var. Torque	<i>C F</i>

### 1 - DISPLAY (显示) 菜单

名称	代码
Drive State	<i>- - - -</i>
Freq. Ref.	<i>F r H</i>
OutPut Freq.	<i>r F r</i>
Motor Speed	<i>S P d</i>
Motor Current	<i>L C r</i>
Mach. Speed	<i>U S P</i>
OutPut Power	<i>O P r</i>
Mains voltage	<i>U L n</i>
Motor Thermal	<i>t H r</i>
Drive Thermal	<i>t H d</i>
Last Fault	<i>L F t</i>
Freq. Ref.	<i>L F r</i>
Power Used	<i>A P H</i>
Run time	<i>r t H</i>

### 2 - ADJUST (调整) 菜单

名称	代码
Freq. Ref. - Hz	<i>L F r</i>
Acceleration - s	<i>A C C</i>
Deceleration - s	<i>d E C</i>
Accél. 2 - s	<i>A C 2</i>
Décél. 2 - s	<i>d E 2</i>
Low Speed - Hz	<i>L S P</i>
High Speed - Hz	<i>H S P</i>
Gain - %	<i>F L G</i>
Stabilité - %	<i>S t A</i>
ThermCurrent - A	<i>I t H</i>
DC Inj. Time - s	<i>t d C</i>
dc I at rest - A	<i>S d C</i>
Jump Freq. - Hz	<i>J P F</i>
Jump2 Freq. - Hz	<i>J F 2</i>
Jump3 Freq. - Hz	<i>J F 3</i>

### 2 - ADJUST (调整) 菜单 (续)

名称	代码
Machine Coef.	<i>U S C</i>
IR Compens	<i>U F r</i>
LSP Time - s	<i>t L S</i>
DC Inj. Curr. - A	<i>I d C</i>
V/f Profile - %	<i>P F L</i>
Preset Sp.2 - Hz	<i>S P 2</i>
Preset Sp.3 - Hz	<i>S P 3</i>
Preset Sp.4 - Hz	<i>S P 4</i>
Preset Sp.5 - Hz	<i>S P 5</i>
Preset Sp.6 - Hz	<i>S P 6</i>
Preset Sp.7 - Hz	<i>S P 7</i>
Preset Sp.8 - Hz	<i>S P 8</i>
Jog Freq. - Hz	<i>J O G</i>
Jog Delay - s	<i>J G t</i>
NST Threshold - Hz	<i>F F t</i>
Tacho Coeff.	<i>d t S</i>
PI Prop.Gain	<i>r P G</i>
PI Int.Gain - /s	<i>r I G</i>
PI Coeff.	<i>F b S</i>
PI Inversion	<i>P I C</i>
Freq.Lev.Att - Hz	<i>F t d</i>
Freq.2 Att - Hz	<i>F 2 d</i>
Curr.Lev.Att - A	<i>C t d</i>
PI Filter - s	<i>P S P</i>
PI Preset 2 - %	<i>P I 2</i>
PI Preset 3 - %	<i>P I 3</i>
ATU th.fault	<i>d t d</i>

### 3 - DRIVE (变频器) 菜单

名称	代码
Nom.Mot.Volt - V	<i>U n S</i>
Nom.Mot.Freq - Hz	<i>F r S</i>
Nom.Mot.Curr - A	<i>n C r</i>
Nom.MotSpeed - rpm	<i>n S P</i>
Mot.Cos Phi	<i>C O S</i>
Auto Tuning	<i>t U n</i>
Max Freq. - Hz	<i>t F r</i>
Energy Eco	<i>n L d</i>
I lim adapt.	<i>F d b</i>
DecRampAdapt	<i>b r A</i>
SwitchRamp2 - Hz	<i>F r t</i>
Stop Type	<i>S t t</i>
Ramp Type	<i>r P t</i>

## 菜单汇总

中文

### 3 - DRIVE (变频器) 菜单 (续)

名称	代码
DecRampCoeff	dCC
Int. I Lim - A	CL I
Auto DC INj.	AdC
Motor P Coef	PCC
Sw Freq. Type	SFt
Sw Freq - Hz	SFr
Noise Reduct	nrd
Special Motor	SPC
PG Type	PGt
Num. Pulsess	PLS

### 4 - CONTROL (控制) 菜单

名称	代码
TermStrip Con	tCC
Type 2 Wire	tCt
RV inhibit	rIn
deadb/edst	bSP
AI2 min Ref. - mA	CrL
AI2 max Ref. - mA	CrH
Min Val. AO - mA	ADL
Max Val. AO - mA	ADH
Save Ref	Str
Keypad Comm.	LCC
STOP Priorit	PSt
DriveAddress	Add
BdRate RS485	tbr
Reset cnts	rPr

### 5 - I/O (输入/输出) 菜单

名称	代码
LI2 Assign.	L I2
LI3 Assign.	L I3
LI4 Assign.	L I4
LI5 Assign.	L I5
LI6 Assign.	L I6
NO: Not assigned	
RV: Reverse	
RP2:Switch ramp2	
JOG	
+SP:+ Speed	
-SP:- Speed	
PS2:2 Prsest Speeds	
PS4:4 Prsest Speeds	
PS8:8 Prsest Speeds	

### 5 - I/O (输入/输出) 菜单

名称	代码
NST:Freewhl Stop	
DCI:DC inject.	
FST:Fast stop	
CHP:Multi. Motor	
FLO:Forced Local	
RST:Fult Reset	
RFC:Auto/Manu	
ATN:Auto Tuning	
PAU:PI Auto/Man	
PR2:PI 2 Preset	
PR4:PI 4 Preset	
EDD:External flt	
FTK:Forc.KeyP.	
R2 Assign	r 2
LO assign	L O
NO:Not assigned	
RUN:Drive Running	
OCC:OutPut Cont.	
FTA:Freq Attain.	
FLA:HSP Attained	
CTA:I Attained	
SRA:FRH Attained	
TSA:MtrTherm Lvl	
APL:LossFollower	
F2A:Freq 2 Attain.	
tAd:ATV th.alarm	
AI2 assian	A I2
AI3 assian	A I3
NO:Not assigned	
FR2:Speed Ref2	
SAI:Summed Ref.	
PIF:PI Regulator	
PIM:PI Man.ref.	
SFB:Tacho feedbk	
PTC:Therm.Sensor	
AI3 assign.(encoder)	A I3
NO:Not assigned	
SAI:Summed Ref.	
RGI:Retour GI	
AO assign.	A O
NO:Not assigned	

## 菜单汇总

### 5 - I/O (输入 / 输出) 菜单 (续)

名称	代码
OCR:Motor Curr.	
OFR:Motor Freq	
ORP:Outpur ramp	
ORS:Signed ramp	
OPS:PI ref.	
OPF:PI Feedback	
OPE:PI Error	
OPI:PI Integral	
OPr:OutPut Power	
tHr:Motorthermal	
tHd:DriveThermal	

### 6 - FAULT (故障) 菜单

名称	代码
Auto Restart	<i>Rt r</i>
Reset Type	<i>rSt</i>
OutPhaseLoss	<i>DPL</i>
InPhaseLoss	<i>IPL</i>
Cont. Stop	<i>StP</i>
ThermProType	<i>tHt</i>
LossFollower	<i>LFL</i>
4-20 Flt Spd	<i>LFF</i>
Catch On Fly	<i>FLr</i>
RampNotFoll	<i>Sdd</i>
External fault	<i>EPL</i>

### 7 - FILES (文件) 菜单

名称	代码
File 1 State	<i>F1S</i>
File 2 State	<i>F2S</i>
File 3 State	<i>F3S</i>
File 4 State	<i>F4S</i>
Operat.Type	<i>F0t</i>
Password	<i>C0d</i>

### 8 - COMMUNICATION (通讯) 菜单

参见通讯卡附带的文档。

### 9 - APPLICATION (应用) 菜单

参见应用卡附带的文档。




## 索引

功能	菜单	页码
加速	ADJUST - DRIVE	26-30
加速斜坡自适应	DRIVE	29
串口地址	CONTROL	34
可控停车	I/O - FAULT	35-49
自学习	DRIVE - I/O	29-35-43
编码器速度环	DRIVE - I/O	31-36-37-45
测速发电机速度环	ADJUST - I/O	28-36-37-44
密码	FILES	51
2/3 线控制	CONTROL	32-40
电动机切换	DRIVE - I/O	30-35-43
斜坡切换	ADJUST - DRIVE - I/O	27-29-35-37-40
给定切换	I/O	35-42
出线接触器	I/O	36-45
减速	ADJUST - DRIVE	26-30
外部故障	I/O	43
节能	DRIVE	29
模拟输入 AI2	CONTROL	33
可配置输入端	I/O	35-36-37
强制为键盘	CONTROL - I/O	35-43
强制本机模式	CONTROL - I/O	35-43
注入制动	ADJUST - DRIVE	26-27-30
开关频率	DRIVE	31
跳频	ADJUST	26
电流限制	DRIVE	26-27
低速限制时间	ADJUST	26
保存给定	CONTROL	34
单步运行 (寸动)	ADJUST - I/O	27-35-37-40
4-20mA 缺失	FAULT	46
+/- 速度	I/O	35-38-41
停车优先	CONTROL	34
电动机热保护	ADJUST - I/O - FAULT	26-28-36-37-49
自动获取速度 (飞车启动)	FAULT	49
自动重起动	FAULT	48
出厂设定 / 保存	FILES	50
PI 调节器	ADJUST - I/O	28-36-37-44
故障复位	I/O - FAULT	35-38-43-48
PTC 传感器	I/O	36-44
可配置输出端	CONTROL - I/O	33-36-37-45-46
预置速度	ADJUST - I/O	27-35-36-42





## This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.





When the drive is powered up, the power components and some of the control components are connected to the line supply. It is extremely dangerous to touch them. The drive cover must be kept closed.

After the ALTIVAR has been switched off and the green LED has gone out, wait for 3 to 10 minutes before working on the equipment. This is the time required for the capacitors to discharge.

The motor can be stopped during operation by inhibiting run commands or the speed reference while the drive remains powered up. If personnel safety requires prevention of sudden restarts, this electronic locking system is not sufficient: fit a cut-off on the power circuit.

The drive is fitted with safety devices which, in the event of a fault, can shut down the drive and consequently the motor. The motor itself may be stopped by a mechanical blockage. Finally, voltage variations, especially line supply failures, can also cause shutdowns.

If the cause of the shutdown disappears, there is a risk of restarting which may endanger certain machines or installations, especially those which must conform to safety regulations.

In this case the user must take precautions against the possibility of restarts, in particular by using a low speed detector to cut off power to the drive if the motor performs an unprogrammed shutdown.

Equipment should be designed in accordance with the specifications laid down in the IEC standards.

As a rule, the drive power supply must be disconnected before any operation on either the electrical or mechanical parts of the installation or machine.

The products and equipment described in this document may be changed or modified at any time, either from a technical point of view or in the way they are operated. Their description can in no way be considered contractual.

The Altivar 38 must be considered as a component: it is neither a machine nor a device ready for use in accordance with European directives (machinery directive and electromagnetic compatibility directive). It is the responsibility of the end user to ensure that the machine meets these standards.

The drive must be installed and set up in accordance with both international and national standards. Bringing the device into conformity is the responsibility of the systems integrator who must observe the EMC directive among others within the European Union.

The specifications contained in this document must be applied in order to comply with the essential requirements of the EMC directive.

## Contents

Preliminary Recommendations .....	66
Selecting a Drive with Heatsink .....	67
Available Torque .....	68
Technical Specifications .....	69
Dimensions - Fan output .....	71
Mounting and Temperature Conditions .....	72
Removing the IP 41 Protective Blanking Cover .....	74
Mounting in a Wall-fixing or Floor-standing Enclosure .....	75
Access to Terminals - Power Terminals .....	76
Control Terminals .....	78
Electromagnetic Compatibility - Wiring .....	79
Wiring Recommendations, Use .....	81
Connection Diagrams .....	82
Keypad operation .....	85
Access to Menus .....	86
Access to Menus - Programming Principle .....	87
Macro-Configurations .....	88
Display Menu .....	89
Adjust Menu .....	90
Drive Menu .....	93
Control Menu .....	96
I/O Menu .....	99
Configurable I/O Application Functions .....	103
Fault Menu .....	112
Files Menu .....	114
Communication and Application Menus / Return to factory settings .....	116
Operation - Maintenance - Spares and Repairs .....	117
Faults - causes - remedies .....	118
Record of configuration and adjustments .....	121
Summary of menus .....	123
Index .....	126



## Preliminary Recommendations

### Acceptance

Check that the drive reference printed on the label is the same as that on the delivery note corresponding to the purchase order.

Remove the Altivar 38 from its packaging and check that it has not been damaged in transit.

### Handling and storage

To ensure the drive is protected before installation, handle and store the device in its packaging.


### Handling on installation

The Altivar 38 range comprises 9 sizes of device, with various weights and dimensions.

Small drives can be removed from their packaging and installed without a handling device.

A hoist must be used with large drives; for this reason they are supplied with 4 handling "lugs". The precautions described below must be observed:

ENGLISH



## Selecting a Drive with Heatsink

### Three-phase supply voltage: 380...460 V 50/60 Hz

Line current at 400 V	Isc prospective line	Motor power (2)	Nominal current (In)	Max. transient current (3)	Power dissipated at nominal load (4)	Reference (5)	Weight
A	kA	kW	A	A	W		kg
3.1	5	0.75	2.1	2.3	55	ATV38HU18N4	3.8
5.4	5	1.5	3.7	4.1	65	ATV38HU29N4	3.8
7.3	5	2.2	5.4	6	105	ATV38HU41N4	3.8
10	5	3	7.1	7.8	145	ATV38HU54N4	6.9
12.3	5	4	9.5	10.5	180	ATV38HU72N4	6.9
16.3	5	5.5	11.8	13	220	ATV38HU90N4	6.9
24.3	22	7.5	16	17.6	230	ATV38HD12N4	13
33.5	22	11	22	24.2	340	ATV38HD16N4	13
43.2	22	15	30	33	410	ATV38HD23N4	15
42	22	18.5	37	41	670	ATV38HD25N4(X)	34
49	22	22	44	49	750	ATV38HD28N4(X)	34
65	22	30	60	66	925	ATV38HD33N4(X)	34
79	22	37	72	80	1040	ATV38HD46N4(X)	34
95	22	45	85	94	1045	ATV38HD54N4(X)	57
118	22	55	105	116	1265	ATV38HD64N4(X)	57
158	22	75	138	152	1730	ATV38HD79N4(X)	57
156 (1)	22	90	173	190	2250	ATV38HC10N4X	49
191 (1)	22	110	211	232	2750	ATV38HC13N4X	75
229 (1)	22	132	253	278	3300	ATV38HC15N4X	77
279 (1)	22	160	300	330	4000	ATV38HC19N4X	77
347 (1)	22	200	370	407	5000	ATV38HC23N4X	159
384 (1)	22	220	407	448	5500	ATV38HC25N4X	166
433 (1)	22	250	450	495	6250	ATV38HC28N4X	168
485 (1)	22	280	503	553	7000	ATV38HC31N4X	168
536 (1)	22	315	564	620	7875	ATV38HC33N4X	168

(1) Current values given with an additional line choke.

(2) These power levels are for a maximum switching frequency of 2 or 4 kHz, depending on the rating, and continuous operation. Switching frequencies are detailed in the section on "Technical Specifications".

Using the ATV38 with a higher switching frequency:

• For continuous operation derate by one power rating, for example:

ATV38HU18N4 for 0.37 kW – ATV38HD12N4 for 5.5 kW.

• If no power derating is applied, do not exceed the following operating conditions:

Cumulative running time 36 s maximum per 60 s cycle (load factor 60%).

(3) For 60 seconds.

(4) These power levels are given for the maximum permissible switching frequency in continuous operation (2 or 4 kHz, depending on the rating).

(5) For ATV38HU18N4 to D79N4: the Altivar 38 is fitted with an integral EMC filter.

For ATV38HD25N4(X) to D79N4(X): add X to the reference to receive an Altivar 38 without integral EMC filter.


For ATV38HC10N4X to C33N4X: the Altivar 38 is not fitted with an integral EMC filter. Optional external filters are available.



## Available Torque

### Torque characteristics:

- Variable torque applications:



ENGLISH

- 1 Self-cooled motor: permanent useful torque
- 2 Force-cooled motor: permanent useful torque
- 3 Transient overtorque for max. 60 seconds.
- 4 Torque at overspeed with constant power

### Available overtorque:

Variable torque applications:

- 110% of the nominal motor torque for 60 seconds.

## Continuous operation

For self-cooled motors, cooling is linked to the motor speed. Derating therefore occurs at speeds of less than half the nominal speed.

## Overspeed operation

As the voltage can no longer change with the frequency, induction in the motor is reduced which results in a reduction in torque. Check with the manufacturer that the motor can operate at overspeed.

**Note:** With a special motor, the nominal and maximum frequencies can be adjusted between 10 and 500 Hz using the operator terminal or PowerSuite tools.

## Technical Specifications

### Environment

	ATV38 HU18N4 to ATV38HD23N4	ATV38 HD25N4(X) to ATV38HC33N4X
Degree of protection	IP21 and IP41 on upper part (conforming to EN 50178)	ATV38HD25N4(X) to ATV38HD79N4(X) drives: IP21 and IP41 on upper part (conforming to EN 50178)  ATV38HC10N4X to ATV38HC33N4X drives: - IP00 on underside (requires addition of protection against direct contact by personnel) - IP20 on other sides
Vibration resistance	Conforming to IEC 68-2-6: 1.5 mm peak from 2 to 13 Hz 1 gn from 13 to 200 Hz	ATV38HD25N4(X) to ATV38HD79N4(X) drives: Conforming to IEC 68-2-6: 1.5 mm peak from 2 to 13 Hz 1 gn from 13 to 200 Hz  ATV38HC10N4X to ATV38HC33N4X drives: 0.6 gn from 10 to 55 Hz
Maximum ambient pollution	ATV38HU18N4 to ATV38 HD23N4 drives: Degree 2 conforming to IEC 664-1 and EN 50718	ATV38HD25N4(X) to ATV38HD79N4(X) drives: - Degree 3 conforming to UL508C ATV38HC10N4X to ATV38 HC33N4X drives: Degree 2 conforming to IEC 664-1 and EN 50718
Maximum relative humidity	93% without condensation or dripping water, conforming to IEC 68-2-3	
Ambient temperature around the unit	Storage: -25 °C to +65 °C  Operation: ATV38HU18N4 to ATV38HU90N4 drives: • -10 °C to +50 °C without derating • up to +60 °C with current derating of 2.2% per °C above 50 °C  ATV38HD12N4 to ATV38HD23N4 drives: • -10 °C to +40 °C without derating • up to +50 °C with current derating of 2.2% per °C above 40 °C	Storage: -25 °C to +65 °C  Operation: ATV38HD25N4(X) to ATV38HD79N4(X) drives: • -10 °C to +40 °C without derating • up to +60 °C with the ventilation kit with current derating of 2.2% per °C above 40 °C  ATV38HC10N4X to ATV38HC33N4X drives: • -10 °C to +40 °C without derating • up to +50 °C with current derating of 2.2% per °C above 40 °C
Maximum operating altitude	1000 m without derating (above this, derate the current by 1% per additional 100 m)	
Operating position	Vertical	

ENGLISH

## Technical Specifications

### Electrical characteristics


Power supply	Voltage	• 380 V - 10% to 460 V + 10% 3-phase
	Frequency	• 50/60 Hz $\pm$ 5%
Output voltage	Maximum voltage equal to line supply voltage	
Electrical isolation	Electrical isolation between power and control (inputs, outputs, power supplies)	
Output frequency range	0.1 to 500 Hz	
Switching frequency	Configurable: <ul style="list-style-type: none"> <li>without derating:               <ul style="list-style-type: none"> <li>0.5 - 1 - 2 - 4 kHz for ATV38HU18N4 to D46N4(X) drives</li> <li>0.5 - 1 - 2 kHz for ATV38HD54N4(X) to C33N4X drives</li> </ul> </li> <li>without derating with intermittent operating cycle or with derating by one power rating in continuous operation:               <ul style="list-style-type: none"> <li>8 - 12 - 16 kHz for ATV38HU18N4 to D23N4 drives</li> <li>8 - 12 kHz for ATV38HD25N4(X) to D46N4(X) drives</li> <li>4 - 8 kHz for ATV38HD54N4(X) to D79N4(X) drives</li> <li>4 kHz for ATV38HC10N4X to C33N4X drives</li> </ul> </li> </ul>	
Speed range	1 to 10	
Braking torque	30% of nominal motor torque without braking resistor (typical value) for low power ratings	
Transient overtorque	110% of nominal motor torque (typical values to $\pm$ 10%) for 60 seconds	
Protection and safety features of drive	<ul style="list-style-type: none"> <li>Short-circuit protection:               <ul style="list-style-type: none"> <li>between output phases</li> <li>between output phases and earth</li> <li>on internal supply outputs</li> </ul> </li> <li>Thermal protection against overheating and overcurrents</li> <li>Supply undervoltage and overvoltage safety circuits</li> <li>Loss of input phase safety circuit (avoids single-phase operation, on all 3-phase drives)</li> </ul>	
Motor protection	<ul style="list-style-type: none"> <li>Thermal protection integrated in drive via continuous calculation of <math>I^2t</math> taking speed into account Motor thermal state saved when the drive is switched off. This function can be modified (via the operator terminal or programming terminal or via the PC software), depending on the type of motor cooling</li> <li>Protection against motor phase breaks</li> <li>Protection via PTC probes with option card</li> </ul>	

ENGLISH



## Dimensions - Fan output

### Dimensions



The EMC mounting plate is supplied with clamps for ATV38HU18N4 to D79N4(X) drives. Fix the EMC equipotentiality mounting plate to the holes in the ATV38 heatsink using the screws supplied, as shown in the drawings above.

							EMC mounting plate	
ATV38H	a	b	c	G	H	Ø1	Δ b	Ø2
U18N4, U29N4, U41N4	150	230	184	133	210	5	64.5	4
U54N4, U72N4, U90N4	175	286	184	155	270	5.5	64.5	4
D12N4, D16N4	230	325	210	200	310	5.5	76	4
D23N4	230	415	210	200	400	5.5	76	4
D25N4(X), D28N4(X), D33N4(X), D46N4(X)	240	550	283	205	530	7	80	5
D54N4(X), D64N4(X), D79N4(X)	350	650	304	300	619	9	110	5
C10N4X	370	630	360	317.5	609	12		
C13N4X, C15N4X, C19N4X	480	680	400	426	652	12		
C23N4X, C25N4X, C28N4X, C31N4X, C33N4X	660	950	440	598	920	15		


### Fan output

ATV38HU18N4	not cooled
ATV38HU29N4, U41N4, U54N4	36 m <sup>3</sup> /hour
ATV38HU72N4, U90N4, D12N4, D16N4, D23N4	72 m <sup>3</sup> /hour
ATV38HD25N4(X), HD28N4(X), D33N4(X), D46N4(X)	292 m <sup>3</sup> /hour
ATV38HD54N4(X), D64N4(X), D79N4(X)	492 m <sup>3</sup> /hour
ATV38HC10N4X	600 m <sup>3</sup> /hour
ATV38HC13N4X, C15N4X, C19N4X	900 m <sup>3</sup> /hour
ATV38HC23N4X, C25N4X, C28N4X, C31N4X, C33N4X	900 m <sup>3</sup> /hour

## Mounting and Temperature Conditions

Install the unit vertically to within  $\pm 10^\circ$ .  
Do not place it close to heating elements.  
Leave sufficient free space to ensure that the air required for cooling purposes can circulate from the bottom to the top of the unit.

### ATV38HU18N4 to D23N4



Free space in front of unit: 10 mm minimum.

### ATV38HU18N4 to U90N4:

From  $-10^\circ\text{C}$  to  $40^\circ\text{C}$ :  $d \geq 50$  mm: no special precautions.

$d = 0$ : remove the protective blanking cover from the top of the drive as shown overleaf (the degree of protection is then IP 20).

From  $40^\circ\text{C}$  to  $50^\circ\text{C}$ :  $d \geq 50$  mm: remove the protective blanking cover from the top of the drive as shown overleaf (the degree of protection is then IP 20).

$d = 0$ : add control ventilation kit VW3A5882• (see ATV38 catalogue).

From  $50^\circ\text{C}$  to  $60^\circ\text{C}$ :  $d \geq 50$  mm: add control ventilation kit VW3A5882• (see ATV38 catalogue).  
Derate the operating current by 2.2% per  $^\circ\text{C}$  over  $50^\circ\text{C}$ .

### ATV38HD12N4 to D23N4:

From  $-10^\circ\text{C}$  to  $40^\circ\text{C}$ :  $d \geq 50$  mm: no special precautions.


$d = 0$ : remove the protective blanking cover from the top of the drive as shown overleaf (the degree of protection is then IP 20).

From  $40^\circ\text{C}$  to  $50^\circ\text{C}$ :  $d \geq 50$  mm: remove the protective blanking cover from the top of the drive as shown overleaf (the degree of protection is then IP 20).  
Derate the current by 2.2% per  $^\circ\text{C}$  over  $40^\circ\text{C}$ .

$d = 0$ : add control ventilation kit VW3A5882 (see ATV38 catalogue). Derate the current by 2.2% per  $^\circ\text{C}$  over  $40^\circ\text{C}$ .

## Mounting and Temperature Conditions


### ATV38HD25N4(X) to D79N4(X)



- Free space in front of unit: 50 mm minimum.
- From - 10 °C to 40 °C: no special precautions.
- From 40 °C to 60 °C: add control ventilation kit VW3A588... (see ATV38 catalogue). Derate the current by 2.2% per °C over 40 °C.

ENGLISH

### ATV38HC10N4X to C23N4X




- Free space in front of unit: 50 mm minimum.
- From - 10 °C to 40 °C: no special precautions.
- Up to 50 °C, derating the operating current by 2.2% for each °C above 40 °C.




## Removing the IP 41 Protective Blanking Cover

ATV38HU18N4 to U90N4




ENGLISH

ATV38HD12N4 to D23N4



ATV38HD25N4(X) to D79N4(X)






## Mounting in a Wall-fixing or Floor-standing Enclosure

Observe the mounting recommendations on the previous page.

To ensure proper air circulation in the drive:

- Fit ventilation grilles
- Ensure that ventilation is adequate: if not, install forced ventilation with a filter
- Use special IP 54 filters



### Dust and damp proof metal wall-fixing or floor-standing enclosure (IP 54 degree of protection)

The drive must be mounted in a dust and damp proof casing in certain environmental conditions: dust, corrosive gases, high humidity with risk of condensation and dripping water, splashing liquid, etc.

To avoid hot spots in the drive, add a fan to circulate the air inside the enclosure, reference VW3A5882• (see ATV38 catalogue).

This enables the drive to be used in an enclosure where the maximum internal temperature can reach 60 °C.

### Calculating the size of the enclosure

Maximum thermal resistance  $R_{th}$  (°C/W) :

$$R_{th} = \frac{\theta^\circ - \theta^\circ e}{P}$$

$\theta^\circ$  = maximum temperature inside enclosure in °C  
 $\theta^\circ e$  = maximum external temperature in °C  
 $P$  = total power dissipated in the enclosure in W

Power dissipated by the drive: see section Selecting a drive.  
 Add the power dissipated by the other equipment components.

Useful heat dissipation surface of enclosure  $S$  (m<sup>2</sup>):  
 (sides + top + front panel if wall-mounted)

$$S = \frac{K}{R_{th}} \quad K = \text{enclosure thermal resistance per m}^2$$

For metal enclosure:  $K = 0.12$  with internal fan  
 $K = 0.15$  without fan

**Caution:** Do not use insulated enclosures, as they have a poor level of conductivity.

ENGLISH

## Access to Terminals - Power Terminals


### Access to terminals

Switch off the drive.

ATV38HU18N4 to ATV38HD79N4(X):

- control terminals: unlock and open the hinged cover
- power terminals: accessible on the underside of the Altivar 38

**Location of terminals:** on the underside of the Altivar.



- 1 Control
- 2 Power
- 3 Terminal for connection of a protective conductor, 10 mm<sup>2</sup> cross-section conforming to EN50178 (earth leakage current)

ENGLISH

ATV38HC10N4X to HC33N4X:





- the control and power terminals can be accessed by removing the front cover

### Power terminals

#### Terminal characteristics

Altivar ATV38H	Terminals	Maximum connection capacity		Tightening torque in Nm
		AWG	mm <sup>2</sup>	
U18N4, U29N4, U41N4	all terminals	AWG 8	6	0.75
U54N4, U72N4, U90N4	all terminals	AWG 8	6	0.75
D12N4, D16N4, D23N4	all terminals	AWG 6	10	2
D25N4(X), D28N4(X)	L1, L2, L3, U, V, W, ⏏	AWG 4	16	3
D33N4(X), D46N4(X)	L1, L2, L3, U, V, W, ⏏	AWG 2	35	4
D54N4(X), D64N4(X), D79N4(X)	L1, L2, L3, U, V, W, ⏏	AWG 2/0	70	10
C10N4X	⏏	AWG 3/0	60	8
	other terminals	AWG 3/0	100	16
C13N4X	⏏	AWG 4/0	60	16
	other terminals	AWG 4/0	100	16
C15N4X	⏏	AWG 1/0 x 2	60	16
	other terminals	AWG 1/0 x 2	100	16
C19N4X	⏏	AWG 3/0 x 2	100	16
	other terminals	AWG 3/0 x 2	150	16
C23N4X	⏏	AWG 4/0 x 2	100	32
	other terminals	AWG 4/0 x 2	200	32



## Power Terminals

Altivar ATV38H	Terminals	Maximum connection capacity		Tightening torque in Nm
		AWG	mm <sup>2</sup>	
C25N4X		AWG 2/0 x 3 - AWG 300 x 2	100	32
	other terminals	AWG 2/0 x 3 - AWG 300 x 2	200	32
C28N4X		AWG 3/0 x 3 - AWG 350 x 2	150	32
	other terminals	AWG 3/0 x 3 - AWG 350 x 2	150 x 2	32
C31N4X,		AWG 4/0 x 3 - AWG 400 x 2	150	32
	other terminals	AWG 4/0 x 3 - AWG 400 x 2	150 x 2	32
C33N4X		AWG 250 x 3 - AWG 500 x 2	150	32
	other terminals	AWG 250 x 3 - AWG 500 x 2	150 x 2	32



### Terminal layout

	L1	L2	L3	PA	PB	U	V	W	
---	----	----	----	----	----	---	---	---	---

ATV38HU18N4 to D23N4

	L1	L2	L3	+	-	PA	PB	U	V	W	
---	----	----	----	---	---	----	----	---	---	---	---



ATV38HD25N4(X) and D79N4(X)

				+	+	-	
	L1	L2	L3	U	V	W	


ATV38HC10N4X

L1	L2	L3				
+		-			U	V W


ATV38HC13N4X to C19N4X

L1	L2	L3				
-			+	+	U	V W

ATV38HC23N4X to C33N4X

 Do not use

### Terminal functions

Terminals	Function	For Altivar ATV38H
	Altivar ground terminal	All ratings
L1 L2 L3	Power supply	All ratings
+	DC bus outputs	All ratings except HU18N4 to HD23N4
-		
PA PB	Not used	ATV38HU18N4 to HD79N4(X)
U V W	Outputs to motor	All ratings


ENGLISH

## Control Terminals

### Terminal characteristics:

- Shielding connection terminal: for metal clamp or tag connector
- 2 removable terminals, one for the relay contacts, the other for the low-level I/O
- Maximum connection capacity : 1.5 mm<sup>2</sup> - AWG 14
- Max. tightening torque: 0.4 Nm

### Terminal layout:



### Terminal functions

Terminal	Function	Electrical characteristics
R1A R1B R1C	Common point C/O contact (R1C) of R1 fault relay	Min. switching capacity • 10 mA for 24 V <sub>DC</sub> Max. switching capacity on inductive load (cos φ 0.4 and L/R 7 ms): • 1.5 A for 250 V <sub>AC</sub> and 30 V <sub>DC</sub>
R2A R2C	N/O contact of R2 programmable relay	
AO1	Analog current output	X-Y mA analog output, where X and Y can be configured Factory setting 0 - 20 mA impedance 500 Ω
COM	Common for logic and analog inputs	
AI1	Analog voltage input	Analog input 0 + 10 V impedance 30 kΩ
+10	Power supply for reference potentiometer 1 to 10 kΩ	+10 V (- 0, + 10%) 10 mA max. short-circuit and overload protection
AI2	Analog current input	X-Y mA analog input, where X and Y can be configured Factory setting 4 - 20 mA impedance 100 Ω
LI1 LI2 LI3 LI4	Logic inputs	Programmable logic inputs impedance 3.5 kΩ + 24 V power supply (max. 30 V) State 0 if < 5 V, state 1 if > 11 V
+ 24	Power supply for inputs	+ 24 V protected against short-circuits and overloads, min. 18 V, max. 30 V Max. current 200 mA




## Electromagnetic Compatibility - Wiring

### Altivar 38 with integral EMC filter ATV38HU18N4 to HD79N4

#### Principle

- Grounds between drive, motor and cable shielding must have "high frequency" equipotentiality.
- Use shielded cables with shielding connected to the ground at both ends of the motor cable, braking resistor (if fitted) and control-signalling cables. Conduit or metal ducting can be used for part of the shielding length provided that there is no break in continuity.
- Ensure maximum separation between the power supply cable (line supply) and the motor cable.

#### Installation diagram



- 1 Sheet steel machine ground supplied with the drive, to be fitted as indicated on the diagram.
- 2 Altivar 38.
- 3 Non-shielded power supply wires or cable.
- 4 Non-shielded wires for the output of the safety relay contacts.
- 5 Fix and ground the shielding of cables 6, 7 and 8 as close as possible to the drive:
  - strip the cable to expose the shielding
  - use the clamps supplied to fix the stripped part of the shielding to the metal plate 1
 The shielding must be clamped tightly enough to the metal plate to ensure good contact.
- 6 Shielded cable for motor connection with shielding connected to ground at both ends. The shielding must be continuous and intermediate terminals must be in EMC shielded metal boxes.
- 7 Shielded cable for connecting the control/signalling wiring. For applications requiring several conductors, use small cross-sections ( $0.5 \text{ mm}^2$ ). The shielding must be connected to ground at both ends. The shielding must be continuous and intermediate terminals must be in EMC shielded metal boxes.
- 8 Shielded cable for connecting braking resistor (if fitted). The shielding must be connected to ground at both ends. The shielding must be continuous and intermediate terminals must be in EMC shielded metal boxes.

#### Note:

- If using an additional input filter, it should be mounted behind the drive and connected directly to the line supply via an unshielded cable. Link 3 to the drive is then via the filter output cable.
- The HF equipotential ground connection between the drive, motor and cable shielding does not remove the need to connect the PE protective conductors (green-yellow) to the appropriate terminals on each unit.

ENGLISH

## Electromagnetic Compatibility - Wiring

### Altivar 38 without integral EMC filter ATV38HC10N4X to HC33N4X

Line chokes are compulsory if the line supply prospective short-circuit current is less than 22 kA. These chokes can be used to provide improved protection against overvoltages on the line supply and to reduce harmonic distortion of the current produced by the drive. The chokes are used to limit the line current.

#### Principle

- Grounds between drive, motor and cable shielding must have "high frequency" equipotentiality.
- Use shielded cables with shielding connected to the ground at both ends of the motor cable, and control-signalling cables. Conduit or metal ducting can be used for part of the shielding length provided that there is no break in continuity.
- Ensure maximum separation between the power supply cable (line supply) and the motor cable.

ENGLISH

#### Power wiring


The power wiring should consist of cables with 4 conductors or individual cables maintained as close as possible to the PE cable. Take care to route the motor cables well away from the power supply cables.

The power supply cables are not shielded. If a radio interference filter is used, the grounds for the filter and the drive should be at the same potential with low-impedance links at high frequency (fixed to unpainted metal plate with anti-corrosion treatment/machine ground wiring). The filter should be fitted as close as possible to the drive.

If the environment is sensitive to radiated radio interference, the motor cables should be shielded. On the drive side, fix and connect the shielding to the machine ground with rustproof clamps. The main function of the motor cable shielding is to limit their radio frequency radiation. Therefore, use 4-pole cables for the motor, connecting each end of the shielding in accordance with established practice for High Frequency wiring. The type of protective material (copper or steel) is less important than the quality of the connection at both ends. An alternative is to use a metal cable duct with good conductivity and no break in continuity.

**Note:** when using a cable with a protective sleeve (NYCY type) which fulfils the dual function of PE + screen, it must be connected correctly to both the drive and the motor (its radiation efficiency is reduced).

#### Control wiring



## Wiring Recommendations, Use

### Wiring recommendations

#### Power

Observe the cable cross-sectional areas recommended in the standards.

The drive must be earthed to conform with the regulations concerning high leakage currents (over 3.5 mA). Do not use a residual current device for upstream protection on account of the DC elements which may be generated by leakage currents. If the installation involves several drives on the same line, each drive must be earthed separately. If necessary, fit a line choke (consult the catalogue).

Keep the power cables separate from circuits in the installation with low-level signals (detectors, PLCs, measuring apparatus, video, telephone).

#### Control

Keep the control circuits away from the power cables. For control and speed reference circuits, we recommend using shielded twisted cables with a pitch of between 25 and 50 mm connecting the shielding to each end.

### Recommendations for use

With power switching via line contactor:



- **Avoid operating contactor KM1 frequently** (premature ageing of the filter capacitors). **Use inputs LI1 to LI4 to control the drive**

- **these steps are essential in the event of cycles:**  
 of less than 60 seconds for ATV38HU18N4 to HD79N4(X)  
 of less than 180 seconds for ATV38HC10N4X to ATV38HC33N4X

If safety standards necessitate isolation of the motor, fit a contactor on the drive output and use the "downstream contactor control" function (consult the programming manual).

### Fault relay, unlocking


The fault relay is energized when the drive is powered up and is not faulty. It has one C/O contact at the common point.

The drive is unlocked after a fault by:

- powering down the drive until both the display and indicator lamps go out, then powering up again
- automatically or remotely via logic input: **consult the programming manual**

## Connection Diagrams

### 3-phase power supply



- (1) ATV38HC10N4X to C33N4X: Line choke compulsory.  
ATV38HU18N4 to D23N4: Line choke if necessary.
- (2) Fault relay contacts for remote signalling of drive status.
- (3) Internal + 24 V. If an external + 24 V supply is used, connect the 0 V from that source to the COM terminal, do not use the + 24 terminal on the drive, and connect the common of the LI inputs to the + 24 V of the external supply.
- (4) R2 reassignable relay.

**Note:**


Fit interference suppressors to all inductive circuits near the drive or connected in the same circuit, such as relays, contactors, solenoid valves, fluorescent lighting, etc.

**Components which can be used in association with the Altivar:** see catalogue.

## Connection diagrams

### Diagram with downstream contactor for ATV38HU18N4 to D23N4.

The shaded part should be added to the various diagram types.



Use the "downstream contactor control" function with relay R2, or logic output LO ( $\approx 24$  V) with the addition of an I/O extension card. Consult the programming manual.

#### Note:

Fit interference suppressors to all inductive circuits near the drive or connected in the same circuit, such as relays, contactors, solenoid valves, fluorescent lighting, etc.


**Components which can be used in association with the Altivar:** see catalogue.

ENGLISH

## Connection Diagrams

### Diagram with downstream contactor for ATV38HD25N4(X) to C33N4X.

The shaded part should be added to the 3-phase power supply diagram.




Use the "downstream contactor control" function with relay R2, or logic output LO ( $\sim$ 24V) switching the coil using an I/O extension card. Consult the programming manual.

**Note:** Fit interference suppressors to all inductive circuits near the drive or connected in the same circuit, such as relays, contactors, solenoid valves, fluorescent lighting, etc.


**Components which can be used in association with the Altivar:** see catalogue.

### 24 V external supply for supplying logic inputs



## Keypad operation

### Front panel



### Use of keys and meaning of displays

- Flashing: indicates the selected direction of rotation
  - Steady: indicates the direction of motor rotation
- LOC Indicates control via the terminal
- PROG Appears in setup and programming mode
- Flashing: indicates that a value has been modified but not saved
- 4-character display: displays numeric values and codes
- One line of 16 characters: displays messages in plain text


### If control via the terminal is active:

- Scroll through menus or parameters and adjust a value.
- Return to the previous menu or abort the current adjustment and return to the original value.
- Select a menu, confirm and save a selection or adjustment.
- Reverses the direction of rotation.
- Command to start the motor running.
- Command to stop the motor or reset the fault. The key's "STOP" function can be inhibited via the program ("CONTROL" menu).



**Use the display module delivered with the ATV38 or a version 5.1 or above display module (see label on the rear view).**

### Rear view



### Notes:

The operator terminal may be connected and disconnected with the power on. If the terminal is disconnected when control of the drive via the terminal is enabled, the drive locks in fault mode SLF.

### Access locking switch:

- position : Adjustment and configuration not accessible
- position : Adjustment accessible
- position : Adjustment and configuration accessible

### Connector:

- for direct connection of the terminal to the drive
- for remote operation, the terminal can be connected via a cable provided in the VW3A58103 kit

### Remote mounting of the terminal:

Use the kit, reference VW3A58103, comprising 1 cable with connectors, the kit for mounting on an enclosure door and the installation guide.

## Access to Menus

The number of menus which can be accessed depends on the position of the access locking switch. Each menu is made up of a number of parameters.

ENGLISH

**Language:** French, English, German, Spanish, Italian

**Macro-config:** variable torque (factory setting)  
If an input/output has been reassigned, **C u 5**: Customised is displayed

**Identification:** display of the drive power and voltage

**Display:** display of electrical values, operation or fault

**Adjust:** configuration of parameters which can be accessed while the motor is rotating

**Drive:** motor-drive configuration


**Control:** configuration of drive control: terminal strip, operator terminal, RS485

**I/O:** configuration of the I/O assignment

**Faults:** configuration of the behaviour of the motor-drive in the event of a fault, and the protection devices

**Files:** saving and restoring the configuration or return to factory settings

Only accessible if the "application" or "communication" card is installed



**CAUTION:** If an access code has already been programmed, it may be impossible to modify some menus; these may not even be visible. In this case, see the section entitled "FILES menu" explaining how to enter the access code.




## Access to Menus - Programming Principle

### Language:

This menu can be accessed whatever position the access switch is in, and can be modified in stop or run mode.

Example :




Possible selections: English (factory setting), French, German, Spanish, Italian.

### Programming principle:

The principle is always the same, with 1 or 2 levels:

- 1 level: see the "language" example above.
- 2 levels: see the "acceleration ramp" example below.






## Macro-Configurations

This parameter can always be displayed and indicates whether an input/output has been reassigned.  
Factory macro-configuration = Variable torque

### Customizing the configuration:

The drive configuration can be customized by changing the I/O assignment in the I/O menu which can be accessed in programming mode (access switch in position ).

This customization modifies the displayed macro-configuration value:


display of



ENGLISH

### I/O assignment in variable torque macro-configuration

Logic input LI1	forward	Logic input LI5	ramp switching
Logic input LI2	reverse	Logic input LI6	Not assigned
Logic input LI3	Fault reset	Analog input AI3 or	summed ref.
Logic input LI4	Not assigned	Inputs A, A+, B, B+	summed ref.
Analog input AI1	motor frequency	Logic output LO	high speed reached
Analog input AI2	summed ref.	Analog output AO	motor current
Relay R1	drive fault		
Relay R2	drive running		
Analog output AO1	motor frequency		

 The assignments with a grey background appear if an I/O extension card has been installed.



## Display Menu



### Display menu (selection of parameter displayed during operation)

The following parameters can be accessed whatever position the access switch is in, stop or run mode.

Code	Function	Unit
	<b>Drive State</b>	—
---	State of the drive: indicates a fault or the motor operation:	
rdY	rdY = drive ready	
rUn	rUn = motor in steady state or run command present and zero reference	
ACC	ACC = accelerating	
dEC	dEC = decelerating	
CLl	CLl = current limit	
dCb	dCb = injection braking	
nSt	nSt = freewheel stop control	
Obr	Obr = braking by adapting the deceleration ramp (see the "drive" menu)	
FrH	FrEq. Ref.	Hz
	Frequency reference	
rFr	Output FrEq.	Hz
	Output frequency applied to the motor	
SPd	Motor Speed	rpm
	Motor speed estimated by the drive	
LCr	MotorCurrent	A
	Motor current	
USP	Machine Spd.	—
	Machine speed estimated by the drive. This is proportional to rFr, according to a coefficient USC which can be regulated in the adjust menu. Displays a value corresponding to the application (metres/second, for example). Caution, if USP becomes greater than 9999 the display is divided by 1000.	
OPr	Output Power	%
	Power supplied by the motor, estimated by the drive. 100% corresponds to nominal power.	
ULn	MainsVoltage	V
	Line voltage	
tHr	MotorThermal	%
	Thermal state: 100% corresponds to the nominal thermal state of the motor. Above 118%, the drive triggers an OLF fault (motor overload)	
tHd	DriveThermal	%
	Thermal state of the drive: 100% corresponds to the nominal thermal state of the drive. Above 118%, the drive triggers an OHF fault (drive overheating). It can be reset below 70%.	
LFt	Last Fault	—
	Displays the last fault which occurred.	
LFr	FrEq. Ref.	Hz
	This adjustment parameter appears instead of the FrH parameter when drive control via the terminal is activated: LCC parameter in the control menu	
RPH	Power Used	kWh or MWh
	Energy consumption	
rEtH	Run Time	hr
	Continuous operating time (motor powered up), in hours	

## Adjust Menu



This menu can be accessed when the switch  and  . Adjustment parameters can be modified in stop mode OR during operation. Ensure that any changes made during operation are not dangerous; changes should preferably be made in stop mode.


List of adjustment parameters which can be accessed in the factory configuration, without an I/O extension card present.

Code	Description	Adjustment range	Factory setting
<b>L F r</b>	Freq. Ref. - Hz	LSP to HSP	–
	Appears when control via the terminal is activated: parameter <b>L C C</b> in the control menu		
<b>A C C</b>	Acceleration - s	0.05 to 999.9	3 s
<b>d E C</b>	Deceleration - s	0.05 to 999.9	3 s
	Acceleration and deceleration ramp times (0 to nominal motor frequency (FrS)).		
<b>L S P</b>	Low Speed - Hz	0 to HSP	0 Hz
	Low speed		
<b>H S P</b>	High Speed - Hz	LSP to tFr	50 Hz
	High speed: ensure that this setting is suitable for the motor and the application.		
<b>F L G</b>	Gain - %	0 to 100	20
	Frequency loop gain: used to adapt the response of the machine speed according to the dynamics. For high resistive torque, high inertia or fast cycle machines, increase the gain gradually.		
<b>S t A</b>	Stability - %	0 to 100	20
	Used to adapt the return to steady state after a speed transient, according to the dynamics of the machine. Gradually increase the stability to avoid any overspeed.		
<b>I t H</b>	ThermCurrent - A	0.25 to 1.1 In (1)	According to drive rating
	Current used for the motor thermal protection. Set ItH to the nominal current on the motor rating plate.		
<b>t d C</b>	DC Inj. Time - s	0 to 30 s Cont	0.5 s
	DC injection braking time. If this is increased to more than 30 s, "Cont" is displayed, Continuous current injection. The injection current will equal SdC after 30 s.		
<b>F F t</b>	NST Threshold - Hz	0 to HSP	0 Hz
	Freewheel stop trip threshold: on a stop on ramp or fast stop request, the selected type of stop is activated until the speed drops below this threshold. Below this threshold, freewheel stopping is activated.		
<b>J P F</b>	Jump Freq. - Hz	0 to HSP	0 Hz
<b>J F 2</b> <b>J F 3</b>	Jump frequency: prohibits prolonged operation over a frequency range of +/-2.5 Hz around JPF. This function prevents a critical speed which leads to resonance.		
<b>U S C</b>	Machine Coef	0.01 to 100	1
	Coefficient applied to parameter rFr (output frequency applied to the motor), the machine speed is displayed via parameter USP: USP = rFr x USC		
<b>t L S</b>	LSP Time - s	0 to 999.9	0 (no time limit)
	Low speed operating time. After operating at LSP for a given time, the motor is stopped automatically. The motor restarts if the frequency reference is greater than LSP and if a run command is still present. Caution : value 0 corresponds to an unlimited period		

(1) In is the drive nominal current shown in the catalogue and on the rating plate.

## Adjust Menu

The following parameters may be accessible following reassignment of the I/O in the standard product or modification of the settings.

Code	Description	Adjustment range	Factory setting
<b>ACC2</b>	Accel. 2 - s 2 <sup>nd</sup> acceleration ramp time	0.05 to 999.9	5 s
<b>DEC2</b>	Decel. 2 - s 2 <sup>nd</sup> deceleration ramp time. These parameters can be accessed if the ramp switching threshold (Frt parameter) is other than 0 Hz or if a logic input has been assigned to ramp switching.	0.05 to 999.9	5 s
<b>IdC</b>	dc I at rest - A Level of injection braking current applied after 30 seconds if tdC = Cont.  Check that the motor will withstand this current without overheating.	0.1 to 1.1 In (1)	According to drive rating
<b>IdC</b>	DC Inj.Curr. - A Level of DC injection braking current This parameter can be accessed if a logic input has been assigned to current injection braking. After 30 seconds the injection current is limited to 0.5 Ith if set to a higher value.	0.1 to 1.1 In (1)	According to drive rating
<b>PFL</b>	U/f Profile - % Can be used to adjust the motor quadratic power supply ratio when the energy-saving function has been inhibited.	0 to 100%	20%
<b>SP2</b>	Preset SP.2 - Hz 2 <sup>nd</sup> preset speed	LSP to HSP	10 Hz
<b>SP3</b>	Preset SP.3 - Hz 3 <sup>rd</sup> preset speed	LSP to HSP	15 Hz
<b>SP4</b>	Preset SP.4 - Hz 4 <sup>th</sup> preset speed	LSP to HSP	20 Hz
<b>SP5</b>	Preset SP.5 - Hz 5 <sup>th</sup> preset speed	LSP to HSP	25 Hz
<b>SP6</b>	Preset SP.6 - Hz 6 <sup>th</sup> preset speed	LSP to HSP	30 Hz
<b>SP7</b>	Preset SP.7 - Hz 7 <sup>th</sup> preset speed	LSP to HSP	35 Hz
<b>SP8</b>	Preset SP.8 - Hz 8 <sup>th</sup> preset speed	LSP to HSP	50 Hz
<b>UFr</b>	IR Compens. - % UFr only appears if the SPC parameter (special motor) of the drive menu is set to "yes". Used to adjust the value measured during auto-tuning that corresponds to 100%.	0 to 800%	0%
<b>JOG</b>	Jog Freq. - Hz Jog frequency	0 to 10 Hz	10 Hz
<b>JGt</b>	Jog Delay - s Anti-repeat delay between two consecutive jog operations	0 to 2 s	0.5 s

(1) In corresponds to the drive nominal current indicated in the catalogue and on the drive rating plate.

## Adjust Menu


ENGLISH

Code	Description	Adjustment range	Factory setting
<b>dt5</b>	Tacho Coeff.	1 to 2	1
	Multiplication coefficient of the feedback associated with the tachogenerator function: $dtS = \frac{9}{\text{tachogenerator voltage at max. speed HSP}}$		
<b>rPG</b>	PI Prop.Gain	0.01 to 100	1
	PI regulator proportional gain		
<b>rIG</b>	PI Int. Gain	0.01 to 100/s	1/s
	PI regulator integral gain		
<b>Fb5</b>	PI Coeff.	1 to 100	1
	PI feedback multiplication coefficient		
<b>PII</b>	PI Inversion	no - yes	no
	Reversal of the direction of correction of the PI regulator no: normal yes: reverse		
<b>Ftd</b>	Freq.Lev.Att - Hz	LSP to HSP	50 Hz
	Motor frequency threshold above which the logic output changes to 1		
<b>F2d</b>	Freq.2 Att - Hz	LSP to HSP	50 Hz
	Frequency 2 threshold: same function as Ftd, for a 2nd frequency value		
<b>Ctd</b>	Curr.Lev.Att - A	0 to 1.1 In (1)	1.1 In (1)
	Current threshold above which the logic output or the relay changes to 1		
<b>ttd</b>	ThermLev.Att - %	0 to 118%	100%
	Motor thermal state threshold above which the logic output or the relay changes to 1		
<b>P5P</b>	PI Filter - s	0.0 to 10.0	0 s
	Used to adjust the filter time constant on the PI feedback		
<b>P12</b>	PI Preset 2 - %	0 to 100%	30%
	2 <sup>nd</sup> preset PI reference, when a logic input has been assigned to the 4 preset PI references function. 100% = process max 0% = process min		
<b>P13</b>	PI Preset 3 - %	0 to 100%	60%
	3 <sup>rd</sup> preset PI reference, when a logic input has been assigned to the 4 preset PI references function. 100% = process max 0% = process min		
<b>dt d</b>	ATV th.fault	0 to 118%	105%
	Drive thermal threshold above which the logic output or the relay changes to 1		

(1) In corresponds to the drive nominal current indicated in the catalogue and on the drive rating plate.

The parameters with a grey background appear if an I/O extension card has been installed.

## Drive Menu

This menu can be accessed when the switch is in position .  
The parameters can only be modified in stop mode with the drive locked.

Drive performance can be optimized by:

- entering the values given on the rating plate in the drive menu
- performing an auto-tune operation (on a standard asynchronous motor)

Code	Description	Adjustment range	Factory setting
<b>Un5</b>	Nom.Mot.Volt - V	200 to 480 V	400 V
	Nominal motor voltage marked on the rating plate. The adjustment range depends on the drive model.		
<b>Fr5</b>	Nom.Mot.Freq - Hz	10 to 500 Hz	50 Hz
	Nominal motor frequency given on the rating plate		
<b>nCr</b>	Nom.Mot.Curr - A	0.25 to 1.1 In (1)	according to drive rating
	Nominal motor current given on the rating plate		
<b>nSP</b>	Nom.Mot.Speed - rpm	0 to 9999 rpm	according to drive rating
	Nominal motor speed given on the rating plate		
<b>CD5</b>	Mot. Cos Phi	0.5 to 1	according to drive rating
	Motor Cos Phi given on the rating plate		
<b>tUn</b>	Auto Tuning	no - yes	no
	Used to auto-tune motor control once this parameter has been set to "yes". Once auto-tuning is complete, the parameter automatically returns to "done" or "no" in the event of a fault. Caution: Auto-tuning will only be performed if no command has been activated. If a "freewheel stop" or "fast stop" function has been assigned to a logic input, this input must be set to 1 (active at 0).		
<b>tFr</b>	Max. Freq. - Hz	10 to 500 Hz	60 Hz
	Maximum output frequency. The maximum value depends on the switching frequency. See SFR parameter (drive menu)		
<b>nLd</b>	Energy Eco	no - yes	yes
	Optimizes motor efficiency		
<b>Fdb</b>	I lim adapt.	no - yes	no
	Adaptation of the limit current as a function of the output frequency (ventilation applications where the load curve changes as a function of the gas density).		
<b>brA</b>	DecRampAdapt	no - yes	yes
	Activating this function automatically increases the deceleration time, if this has been set at too low a value for the inertia of the load, thus avoiding the drive going into ObF fault. This function may be incompatible with positioning on a ramp and with the use of a braking resistor.		
<b>Frt</b>	SwitchRamp2 - Hz	0 to HSP	0 Hz
	Ramp switching frequency Once the output frequency exceeds Frt, the ramp times taken into account are AC2 and dE2.		

(1) In is the drive nominal current shown in the catalogue and on the rating plate.



## Drive Menu

ENGLISH


Code	Description	Adjustment range	Factory setting
<b>Stt</b>	<b>Stop Type</b>	STN - FST - NST - DCI	STN
	Type of stop. On a stop request, the type of stop is activated up to the FFt threshold (adjust menu). Below the threshold, freewheel stopping occurs. STN: follow ramp FST: fast stop NST: freewheel stop DCI: DC injection stop		
<b>rPt</b>	<b>Ramp Type</b>	LIN - S - U	LIN
	Defines the shape of the acceleration and deceleration ramps. LIN: linear S: S ramp U: U ramp		
	<div> <p><b>S-shape ramps</b></p> <p>The rounding coefficient is fixed, where <math>t_2 = 0.6 \times t_1</math> and <math>t_1 = \text{set ramp time}</math>.</p> </div> <div> <p><b>U-shape ramps</b></p> <p>The rounding coefficient is fixed, where <math>t_2 = 0.5 \times t_1</math> and <math>t_1 = \text{set ramp time}</math>.</p> </div>		
<b>dCf</b>	<b>DecRAMPCoeff</b>	1 to 10	4
	Deceleration ramp time reduction coefficient when the fast stop function is active.		
<b>CLl</b>	<b>Int. I Lim - A</b>	0 to 1.1 In (1)	1.1 In
	The current limit is used to limit motor overheating.		
<b>AdC</b>	<b>Auto DC Inj.</b>	no - yes	yes
	Used to deactivate automatic DC injection braking on stopping.		
<b>PCC</b>	<b>Motor P Coef.</b>	0.2 to 1	1
	Defines the relationship between the drive nominal power and the lowest-rated motor when a logic input has been assigned to the motor switching function.		




## Drive Menu



Code	Description	Adjustment range	Factory setting					
S F t	Sw Freq. Type	LF-HF1-HF2	LF					
	Used to select a low switching frequency (LF) or a high switching frequency (HF1 or HF2). HF1 switching is designed for applications with a low load factor without derating the drive. If the thermal state of the drive exceeds 95%, the frequency automatically changes to 2 or 4 kHz depending on the drive rating. When the thermal state of the drive drops back to 70%, the selected switching frequency is re-established. HF2 switching is designed for applications with a high load factor with derating of the drive by one rating: the drive parameters are scaled automatically (torque limit, thermal current, etc).							
	 <b>Modifying this parameter results in the following parameters returning to factory settings :</b> <ul style="list-style-type: none"><li>• nCr, CLi, Sfr, nrd (Drive menu)</li><li>• ItH, IdC, Ctd (Adjust menu)</li></ul>							
S F r	Sw Freq. - kHz	0.5-1-2-4 -8-12-16 kHz	According to drive rating					
	Used to select the switching frequency. The adjustment range depends on the SFt parameter. If SFt = LF: 0.5 to 2 or 4 kHz according to the drive rating If SFt = HF1 or HF2: 2 or 4 to 16 kHz according to the drive rating The maximum operating frequency (tFr) is limited according to the switching frequency:							
	SFr(kHz)	0.5	1	2	4	8	12	16
	tFr (Hz)	62	125	250	500	500	500	500
n r d	Noise Reduct	no - yes	(1)					
	This function modulates the switching frequency randomly to reduce motor noise.							
S P C	Special Motor	no - yes - PSM	no					
	It should be used for a motor supply in U/f ratio with the IR compensation set via the U F r parameter in the "Adjust" menu. No: normal motor Yes: special motor PSM: small motor. It inhibits detection of "Uncontrolled loss downstream". Deactivate the function nLd in the Drive menu for this to operate correctly.							
	 <b>Perform an auto-tune</b>							
P G t	PG Type	INC-DET	DET					
	Defines the type of sensor used when an encoder feedback I/O card is installed: INC: incremental encoder (A, A+, B, B+ are hard-wired) DET: detector (only A is hard-wired)							
P L S	Num. Pulses	1 to 1024	1024					
	Defines the number of pulses per sensor revolution.							

(1) yes if **SFt** = **LF**, no if **SFt** = **HF1** or **HF2**


 The parameters with a grey background appear if a VW3 A58202 I/O extension card has been installed.


## Control Menu

This menu can be accessed when the switch is in position . The parameters can only be modified in stop mode with the drive locked.

Code	Description	Adjustment range	Factory setting														
ELC	TermStripCon	2W- 3W (2-wire - 3-wire)	2W														
<p>Configuration of terminal strip control: 2-wire or 3-wire control.</p> <p> Modification of this parameter requires double confirmation as it results in reassignment of the logic inputs. By changing from 2-wire control to 3-wire control, the logic input assignments are shifted by one input. The LI3 assignment in 2-wire control becomes the LI4 assignment in 3-wire control. In 3-wire control, inputs LI1 and LI2 cannot be reassigned.</p> <table><thead><tr><th>Macro-configuration</th><th>Variable torque</th></tr></thead><tbody><tr><td>LI1</td><td>STOP</td></tr><tr><td>LI2</td><td>RUN forward</td></tr><tr><td>LI3</td><td>RUN reverse</td></tr><tr><td>LI4</td><td>Fault reset</td></tr><tr><td>LI5</td><td>ramp switching</td></tr><tr><td>LI6</td><td>not assigned</td></tr></tbody></table> <p>The I/O with a grey background can be accessed if an I/O extension card has been installed.</p> <p>3-wire control (Pulse control: one pulse is sufficient to control start-up). This option inhibits the “automatic restart” function.</p> <p>Wiring example:</p> 				Macro-configuration	Variable torque	LI1	STOP	LI2	RUN forward	LI3	RUN reverse	LI4	Fault reset	LI5	ramp switching	LI6	not assigned
Macro-configuration	Variable torque																
LI1	STOP																
LI2	RUN forward																
LI3	RUN reverse																
LI4	Fault reset																
LI5	ramp switching																
LI6	not assigned																

This option only appears if 2-wire control is configured.

Code	Description	Adjustment range	Factory setting
<b>ELT</b>	<b>Type 2 Wire</b>	LEL-TRN-PFo	LEL
	<p>Defines 2-wire control:</p> <ul style="list-style-type: none"> <li>- according to the state of the logic inputs (LEL: 2 wire)</li> <li>- according to a change in state of the logic inputs (TRN: 2 wire trans)</li> <li>- according to the state of the logic inputs with forward always having priority over reverse (PFo: Priorit. FW)</li> </ul> <p>Wiring example:</p>  <p>LI1: forward LIx: reverse</p>		
<b>rIn</b>	<b>RV Inhibit</b>	no - yes	no
	<ul style="list-style-type: none"> <li>• Inhibition of operation in the opposite direction to that controlled by the logic inputs, even if this reversal is required by a summing or loop control function.</li> <li>• Inhibition of reverse operation if it is controlled by the FWD/REV key on the terminal.</li> </ul>		

 The parameters with a grey background appear if an I/O extension card has been installed.



# Control Menu

Code	Description	Adjustment range	Factory setting
<b>b 5 P</b>	<b>deadb./Pedst.</b>	no BNS: pedestal BLS: deadband	no
<p>Management of operation at low speed:</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>F : motor frequency</p> <p>No</p> </div> <div style="text-align: center;"> <p>F : motor frequency</p> <p>Pedestal (BNS)</p> </div> <div style="text-align: center;"> <p>F : motor frequency</p> <p>Deadband (BLS)</p> </div> </div>			
<b>CrL</b>	AI2 min Ref. - mA	0 to 20 mA	4 mA
<b>CrH</b>	AI2 Max Ref. - mA	4 to 20 mA	20 mA
<p>Minimum and maximum values of the signal on input AI2. These two parameters are used to define the signal sent to AI2. There are several configuration possibilities, one of which is to configure the input for a 0-20 mA, 4-20 mA, 20-4 mA, etc signal.</p> <div style="text-align: center;"> <p>Frequency</p> <p>CrL CrH 20 AI 2 (mA)</p> </div>			
<b>AO L</b>	Min. Val AO - mA	0 to 20 mA	0 mA
<b>AO H</b>	Max. Val AO - mA	0 to 20 mA	20 mA
<p>Parameter</p> <div style="display: flex; justify-content: space-between;"> <div style="text-align: center;"> <p>Max.</p> <p>0 AOH 20 AO (mA)</p> </div> <div> <p>Minimum and maximum values of the signal on outputs AO and AO1 (1) These two parameters are used to define the output signal on AO and AO1. Eg: 0-20 mA, 4-20 mA, 20-4 mA, etc</p> </div> </div>			


(1) The AO output is available if an I/O extension card has been installed.

## Control Menu

ENGLISH

Code	Description	Adjustment range	Factory setting
<b>5 t r</b>	Save Ref.	NO-RAM-EEP	NO
	Associated with the + speed/- speed function, this function is used to save the reference: when run commands disappear (saved in RAM) or when the line supply disappears (saved in EEPROM). On the next start-up, the speed reference is the last reference saved.		
<b>L C C</b>	Keypad Comm.	No - Yes	No
	Used to activate drive control via the terminal. The STOP/RESET, RUN and FWD/REV keys are active. The speed reference is given by parameter LFr. Only the freewheel stop, fast stop, DC injection stop commands and external fault remain active at the terminals. If the drive/terminal connection is cut, the drive locks in SLF fault mode.   <b>This function is no longer accessible by the keypad if LIX=FTK.</b>		
<b>P S t</b>	STOP Priorit	No - Yes	Yes
	This function gives priority to the STOP key irrespective of the control channel (terminals or fieldbus). To change the PSt parameter to "no": 1 - Display "no" 2 - Press the "ENT" key 3 - The drive displays "See manual" 4 - Press ▲ then ▼ then "ENT" For applications with continuous processes, it is advisable to configure the key as inactive (set to "no").		
<b>R d d</b>	DriveAddress	0 to 31	0
	Drive address when it is controlled via the connector port (with the operator terminal and programming terminal removed).		
<b>t b r</b>	BdRate RS485	9600-19200	19200
	Transmission speed via the RS485 serial link (effective on the next power-up) 9600 bps 19200 bps   <b>If t b r ≠ 19200, the terminal can no longer be used. To reactivate the terminal, reconfigure t b r as 19200 via the serial link or revert to factory settings (see page 118).</b>		
<b>r P r</b>	Reset cnts	No-APH-RTH	No
	Reset kWh or the operating time. No APH: Reset kWh to zero RTH: Reset operating time to zero The reset command must be confirmed with "ENT" APH and RTH take effect immediately. The parameter then automatically reverts to No		

## I/O Menu

This menu can be accessed when the switch is in position .  
The assignments can only be modified in stop mode with the drive locked.

Code	Function
<b>L I2</b>	LI2 Assign.
	See the summary table and description of the functions.

The inputs and outputs available in the menu depend on the I/O cards installed (if any) in the drive, as well as the selections made previously in the control menu.

### Summary table of the logic input assignments (exc. 2-wire / 3-wire option)

I/O extension option cards		2 logic inputs LI5-LI6
Drive without option		3 logic inputs LI2 to LI4
NO :Not assigned	(Not assigned)	X
RV :Reverse	(Reverse)	X
RP2:Switch ramp2	(Ramp switching)	X
JOG	(Jog operation)	X
+SP: + Speed	(+ speed)	X
-SP: - Speed	(- speed)	X
PS2: 2 Preset Speeds	(2 preset speeds)	X
PS4 : 4 Preset Speeds	(4 preset speeds)	X
PS8 : 8 Preset Speeds	(8 preset speeds)	X
NST:Freewhl Stop	(Freewheel stop)	X
DCI:DC inject.	(Injection stop)	X
FST:Fast stop	(Fast stop)	X
CHP:Multi. Motor	(Motor switching)	X
FLO:Forced Local	(Forced local mode)	X
RST:Fault Reset	(Fault reset)	X
RFC:Auto/Manu	(Reference switching)	X
ATN:Auto Tuning	(Auto-tuning)	X
PAU:PI Auto/Man	(PI Auto/Man) If one AI = PIF	X
PR2:PI 2 Preset	(2 preset PI references) If one AI = PIF	X
PR4:PI 4 Preset	(4 preset PI references) If one AI = PIF	X
EDD:Ext flt.	(external fault)	X
FTK: Forc.KeyP.	(Force to keypad)	X



**CAUTION:** If a logic input is assigned to "Freewheel stop" or "Fast stop", start-up can only be performed by linking this input to the +24V, as these stop functions are active when the inputs are at state 0.

## I/O Menu

**Summary table of the encoder and analog input assignments**

I/O extension option cards			Analog input AI3	Encoder input A+, A-, B+, B- (1)
Drive without option		Analog input AI2		
NO :Not assigned	(Not assigned)	X	X	X
FR2:Speed Ref2	(Speed reference 2)	X	X	
SAI:Summed Ref.	(Summed reference)	X	X	X
PIF:PI Regulator	(PI regulator feedback)	X	X	
PIM:PI Man.ref.	(Manual PI speed reference) If one AI = PIF		X	
SFB:Tacho feedbk	(Tachogenerator)		X	
PTC:Therm.Sensor	(PTC probes)		X	
RGI:PG feedbk	(Encoder or detector feedback)			X

(1) NB: The menu for assigning encoder input A+, A-, B+, B- is called "Assign AI3".

**Summary table for logic output assignments**

I/O extension option card			Logic output LO
Drive without option		Relay R2	
NO :Not assigned	(Not assigned)	X	X
RUN:DriveRunning	(Drive running)	X	X
OCC:Output Cont.	(Downstream contactor control)	X	X
FTA:Freq Attain.	(Frequency threshold reached)	X	X
FLA:HSP Attained	(HSP reached)	X	X
CTA:I Attained	(Current threshold reached)	X	X
SRA:FRH Attained	(Frequency reference reached)	X	X
TSA:MtrTherm Lvl	(Motor thermal threshold reached)	X	X
APL:LossFollower	(Loss of 4/20 mA signal)	X	X
F2A:Freq.2 Att.	(Frequency 2 threshold reached)	X	X
tAd:ATV th.alarm	(Drive thermal threshold reached)	X	X

## I/O Menu

**Summary table for the analog output assignments**

I/O extension option card		Analog output AO
Drive without option		Analog output AO1
NO :Not assigned	(Not assigned)	X
OCR:Motor Curr.	(Motor current)	X
QFR:Motor Freq	(Motor speed)	X
ORP:OutPut ramp	(Ramp output)	X
ORS:Signed ramp	(Signed ramp output)	X
OPS:PI ref.	(PI reference output) If one AI = PIF	X
OPF:PI Feedback	(PI feedback output) If one AI = PIF	X
OPE:PI Error	(PI error output) If one AI = PIF	X
OPI:PI Integral	(PI integral output) If one AI = PIF	X
OPR:OutPut Power	(Motor power)	X
THR:MotorThermal	(Motor thermal state)	X
THD:DriveThermal	(Drive thermal state)	X

ENGLISH

Once the I/O have been reassigned, the parameters related to the function automatically appear in the menus, and the macro-configuration indicates "CUS: Customised". Some reassignments result in new adjustment parameters which the user must not forget to configure in the adjust menu:

I/O	Assignments	Parameters to set
LI	RP2 Ramp switching	<b>RL2 dE2</b>
LI	JOG Jog operation	<b>JOG JGt</b>
LI	PS2 2 preset speeds	<b>SP2</b>
LI	PS4 4 preset speeds	<b>SP2 - SP3 - SP4</b>
LI	PS8 8 preset speeds	<b>SP5 - SP6 - SP7 - SP8</b>
LI	DCI Injection stop	<b>IdC</b>
LI	PR4 4 preset PI references	<b>P12 - P13</b>
AI	PIF PI regulator feedback	<b>rPG - rIG - P1C - P5P</b>
AI	SFB Tachogenerator	<b>dE5</b>
LO/R2	FTA Frequency threshold reached	<b>Ftd</b>
LO/R2	CTA Current threshold reached	<b>Ctd</b>
LO/R2	TSA Motor thermal threshold reached	<b>tdt</b>
LO/R2	F2A Frequency 2 threshold reached	<b>F2d</b>
LO/R2	TAD Drive thermal threshold reached	<b>dt d</b>



## I/O Menu



Some reassignments result in new adjustment parameters which the user must not forget to configure in the control, drive or fault menu:

I/O	Assignments		Parameters to set
LI	-SP	- speed	<b>5 t r</b> (control menu)
LI	FST	Fast stop	<b>d L F</b> (drive menu)
LI	RST	Fault reset	<b>r 5 t</b> (fault menu)
LI	CHP	Motor switching	<b>P L L</b> (drive menu)
AI	SFB	Tachogenerator	<b>5 d d</b> (fault menu)
A+, A-, B+, B-	SAI	Summed reference	<b>P G t</b> , <b>P L 5</b> (drive menu)
A+, A-, B+, B-	RGI	PG feedback	<b>P G t</b> , <b>P L 5</b> (drive menu)

ENGLISH





## Configurable I/O Application Functions

### Function compatibility table

The choice of application functions may be limited by incompatibility between certain functions. Functions which are not listed in this table are fully compatible.

	DC injection braking	Summed inputs	PI regulator	+/- speed	Reference switching	Freewheel stop	Fast stop	Jog operation	Preset speeds	Speed regulation with tachogenerator or encoder
DC injection braking						↑				
Summed inputs					●					
PI regulator								●	●	●
+/- speed					●			↑	●	
Reference switching		●		●					●	
Freewheel stop	↑						↑			
Fast stop						↑				
Jog operation			●	←					↑	
Preset speeds			●	●	●			↑		
Speed regulation with tachogenerator or encoder			●							



Incompatible functions




Compatible functions



Not applicable

Priority functions (functions which cannot be active simultaneously):



The function indicated by the arrow has priority over the other.

Stop functions have priority over run commands.

Speed references via logic command have priority over analog references.



## Configurable I/O Application Functions

### Logic input application functions

#### Operating direction: forward/reverse

Reverse operation can be disabled for applications requiring only a single direction of motor rotation.

#### 2-wire control

Run (forward or reverse) and stop are controlled by the same logic input, for which state 1 (run) or 0 (stop), or a change in state is taken into account (see the 2-wire control menu).

#### 3-wire control

Run (forward or reverse) and stop are controlled by 2 different logic inputs.

LI1 is always assigned to the stop function. A stop is obtained on opening (state 0).

The pulse on the run input is stored until the stop input opens.

During power-up or a manual or automatic fault reset, the motor can only be supplied with power after prior resetting of the "forward", "reverse", and "injection stop" commands.

#### Ramp switching : 1<sup>st</sup> ramp: ACC, dEC; 2<sup>nd</sup> ramp: AC2, dE2

Two types of activation are possible:

- activation of a logic input LIx
- detection of an adjustable frequency threshold

If a logic input is assigned to the function, ramp switching can only be performed by this input.

#### Step by step operation (JOG): Low speed operation pulse

If the JOG contact is closed and then the operating direction contact is actuated, the ramp is 0.1 s irrespective of the ACC, dEC, AC2, dE2 settings. If the direction contact is closed and the JOG contact is then actuated, the configured ramps are used.

Parameters which can be accessed in the adjust menu:

- JOG speed
- anti-repeat delay (minimum time between 2 "JOG" commands)

ENGLISH

## Configurable I/O Application Functions

**+/- speed:** Two types of operation are available.

- 1 Use of single action buttons: two logic inputs are required in addition to the operating direction(s).  
The input assigned to the "+ speed" command increases the speed, the input assigned to the "- speed" command decreases the speed.

This function accesses the STr save reference parameter in the Control menu.

- 2 Use of double action buttons: only one logic input assigned to + speed is required.

+ speed/- speed with double action buttons:



Description: 1 button pressed twice for each direction of rotation.

Each action closes a volt-free contact.

	Released (- speed)	Press 1 (speed maintained)	Press 2 (+ speed)
forward button	—	a	a and b
reverse button	—	c	c and d

Wiring example:

LI1: forward  
LIx: reverse  
LIy: + speed



This type of +/- speed is incompatible with 3-wire control. In this case, the - speed function is automatically assigned to the logic input with the highest number (for example: LI3 (+ speed), LI4 (- speed)).

**In both cases, the maximum speed is given by the references applied to the analog inputs. For example, connect AI1 to the +10V.**

## Configurable I/O Application Functions

### Preset speeds

2, 4 or 8 speeds can be preset, requiring 1, 2 or 3 logic inputs respectively.  
The following assignment order must be observed : PS2 (Llx), then PS4 (Lly), then PS8 (Llz).

2 preset speeds		4 preset speeds			8 preset speeds			
Assign: Llx to PS2		Assign: Llx to PS2 then Lly to PS4			Assign: Llx to PS2 Lly to PS4, then Llz to PS8			
Llx	speed reference	Lly	Llx	speed reference	Llz	Lly	Llx	speed reference
0	LSP+reference	0	0	LSP+reference	0	0	0	LSP+reference
1	SP2	0	1	SP2	0	0	1	SP2
		1	0	SP3	0	1	0	SP3
		1	1	SP4	0	1	1	SP4
					1	0	0	SP5
					1	0	1	SP6
					1	1	0	SP7
					1	1	1	SP8

ENGLISH

To unassign the logic inputs, the following order must be observed: PS8 (Llz), then PS4 (Lly), then PS2 (Llx).

### Reference switching


To configure the AI1/AI2 reference switching:

- Verify that the LI is not configured to "RFC:Auto/Manu" (if so, configure the LI to "NO:Not assigned").
- Configure a LI to "RFC:Auto/Manu". The second reference is then AI2.

To configure the AI1/AI3 reference switching:

- Verify that the LI is not configured to "RFC:Auto/Manu" (if so, configure the LI to "NO:Not assigned").
- Configure AI3 to "FR2:Speed Ref2".
- Configure a LI to "RFC:Auto/Manu". The second reference is then AI3.

### Connection diagram



### Freewheel stop

Causes the motor to stop using the resistive torque only. The motor power supply is cut.  
A freewheel stop is obtained when the logic input opens (state 0).

### DC injection stop

An injection stop is obtained when the logic input closes (state 1).

### Fast stop

Braked stop with the deceleration ramp time reduced by a reduction factor dCF which appears in the drive menu.  
A fast stop is obtained when the logic input opens (state 0).

## Configurable I/O Application Functions

### Motor switching

This function enables two motors with different ratings to be powered by the same drive in succession, with switching performed by an appropriate sequence at the drive output. Switching must take place with the motor stopped, and the drive locked. The following internal parameters are switched automatically by the logic command:

- nominal motor current
- injection current

This function automatically disables thermal protection on the second motor.  
Accessible parameter: Ratio of PCC motor ratings in the drive menu.

### Fault reset

Two types of reset are available: partial or general (rSt parameter in the "fault" menu).

Partial reset (rSt = RSP):

Used to clear the stored fault and reset the drive if the cause of the fault has disappeared.

Faults affected by partial clearing:

- |                      |                       |                     |
|----------------------|-----------------------|---------------------|
| - line overvoltage   | - communication fault | - motor overheating |
| - DC bus overvoltage | - motor overload      | - serial link fault |
| - motor phase loss   | - loss of 4-20 mA     | - drive overheating |
| - overhauling        | - external fault      | - overspeed         |

General reset (rSt = RSG):

**This inhibits all faults (forced operation) except SCF (motor short circuit)** while the assigned logic input is closed.

### Forced local mode

Used to switch between line control mode (serial link) and local mode (controlled via the terminal strip or via the terminal).

### Auto-tuning

When the assigned logic input changes to 1 an auto-tuning operation is triggered, in the same way as parameter tUn in the "drive" menu.

**Caution:** Auto-tuning will only be performed if no command has been activated. If a "freewheel stop" or "fast stop" function has been assigned to a logic input, this input must be set to 1 (active at 0).  
Application: Motor switching for example.

**Preset PI auto-man, PI reference:** See PI function (page 110)

### External fault

When the assigned logic input changes to 1, the motor stops (according to the configuration of the L5F Stopflt parameter in the Drive menu), and the drive locks in EPF external fault fault mode.

### Force to keypad

Enables a LI to be used to select for local control:

If LIX=FTK and FTK=0: operation by the control terminals

If LIX=FTK and FTK=1: control by the keypad

- If LIX=FTK, the LCC function in the control menu is no longer accessible by the keypad. In consequence it is impossible to control the drive by the keypad.
- When FTK has been deactivated it is necessary to revalidate the function LCC again in the control menu.

## Configurable I/O Application Functions

### Analog input application functions

Input AI1 is always the speed reference.

#### Assignment of AI2 and AI3

**Summed speed reference:** The frequency references provided by AI2 and AI3 can be summed with AI1.

**Speed regulation with tachogenerator:** (Assignment to AI3 only with an I/O extension card with analog input): used for speed correction via tachogenerator feedback.

An external divider bridge is required to adapt the voltage of the tachogenerator. The maximum voltage must be between 5 and 9 V. A precise setting is then obtained by setting parameter dtS available in the adjust menu.

**PTC probe protection:** (only with an I/O extension card with analog input). Used for the direct thermal protection of the motor by connecting the PTC probes in the motor windings to analog input AI3.

PTC probe characteristics:

Total resistance of the probe circuit at 20 °C = 750 Ohms.

**PI regulator:** Used to regulate a process with a reference and a feedback given by a sensor. In PI mode the ramps are all linear, even if they are configured differently.


With the PI regulator, it is possible to:

- Adapt the feedback via FbS.
- Correct PI inversion.
- Adjust the proportional and integral gain (RPG and RIG).
- Assign an analog output for the PI reference, PI feedback and PI error.
- Apply a ramp to establish the action of the PI (AC2) on start-up if PSP > 0.

If PSP = 0 the active ramps are ACC/dEC. The dEC ramp is always used when stopping.

The motor speed is limited to between LSP and HSP.

**Note:** PI regulator mode is active if an AI input is assigned to PI feedback. This AI assignment can only be made after disabling any functions incompatible with PI (see page 105).



**Auto/Man:** This function can only be accessed when the PI function is active, and requires an I/O extension card with analog input

- Via logic input LI, this is used to switch operation to speed regulation if Llx = 0 (manual reference on AI3), and PI regulation if Llx = 1 (auto).

## Configurable I/O Application Functions

### Preset references:

2 or 4 preset references require the use of 1 or 2 logic inputs respectively:

2 preset references			4 preset references		
Assign: Llx to Pr2			Assign: Llx to Pr2, then Lly to Pr4		
Llx	Reference		Lly	Llx	Reference
0	Analog reference		0	0	Analog reference
1	Process max (= 10 V)		0	1	PI2 (adjustable)
			1	0	PI3 (adjustable)
			1	1	Process max (= 10 V)

### Encoder input application functions

(only with an I/O extension card with encoder input)

**Speed regulation:** Used to correct the speed via an incremental encoder or detector. (See documentation supplied with the card).

**Summed speed reference:** The reference provided by the encoder input is summed with AI1. (see documentation supplied with the card)

Applications:

- Synchronization of the speed of a number of drives. Parameter PLS on the "drive" menu is used to adjust the speed ratio of one motor in relation to that of another.
- Reference via encoder.

### Logic output application functions

Relay R2, LO solid state output (with I/O extension card)

**Downstream contactor control (OCC):** can be assigned to R2 or LO

Enables the drive to control an output contactor (located between the drive and the motor). The request to close the contactor is made when a run command appears. The request to open the contactor is made when there is no current to the motor.



If a DC injection braking function has been configured, it should not be left operating too long in stop mode, as the contactor only opens at the end of braking.

**Drive running (RUN):** can be assigned to R2 or LO

The logic output is at state 1 if the motor power supply is provided by the drive (current present) or if a run command is present with a zero reference.

**Frequency threshold reached (FTA):** can be assigned to R2 or LO

The logic output is at state 1 if the motor frequency is greater than or equal to the frequency threshold set by Ftd in the adjust menu.

**Frequency 2 threshold reached (F2A):** can be assigned to R2 or LO

The logic output is at state 1 if the motor frequency is greater than or equal to the frequency threshold set by F2d in the adjust menu.

**Reference reached (SRA):** can be assigned to R2 or LO

The logic output is at state 1 if the motor frequency is equal to the reference value.

## Configurable I/O Application Functions

**High speed reached (FLA):** can be assigned to R2 or LO  
The logic output is at state 1 if the motor frequency is equal to HSP.

**Current threshold reached (CTA):** can be assigned to R2 or LO  
The logic output is at state 1 if the motor current is greater than or equal to the current threshold set by Ctd in the adjust menu.

**Motor thermal state reached (TSA):** can be assigned to R2 or LO  
The logic output is at state 1 if the motor thermal state is greater than or equal to the thermal state threshold set by ttd in the adjust menu.

**Drive thermal state reached (TAD):** can be assigned to R2 or LO  
The logic output is at state 1 if the drive thermal state is greater than or equal to the thermal state threshold set by dtd in the adjust menu.

**Loss follower (APL):** can be assigned to R2 or LO  
The logic output is at 1 if the signal on the 4-20 mA input is below 2 mA.

## Analog output AO and AO1 application functions

Analog outputs AO and AO1 are current outputs, from AOL (mA) to AOH (mA),

- AOL and AOH can be configured between 0 and 20 mA.

Examples of AOL – AOH: 0 - 20 mA  
4 - 20 mA  
20 - 4 mA

**Motor current** (code OCR): the image of the motor rms current.

- AOH corresponds to twice the drive nominal current.
- AOL corresponds to zero current.

**Motor frequency** (code OFR): the motor frequency estimated by the drive.

- AOH corresponds to the maximum frequency (parameter tFr).
- AOL corresponds to zero frequency.

**Ramp output** (code ORP): the image of the ramp output frequency.

- AOH corresponds to the maximum frequency (parameter tFr).
- AOL corresponds to zero frequency.

**Signed ramp** (code ORS): the image of the ramp output frequency and direction.

- AOL corresponds to the maximum frequency (parameter tFr) in reverse direction.
- AOH corresponds to the maximum frequency (parameter tFr) in forward direction.
- $\frac{AOH + AOL}{2}$  corresponds to zero frequency.


**PI reference** (code OPS): the image of the PI regulator reference.

- AOL corresponds to the minimum reference.
- AOH corresponds to the maximum reference.

**PI feedback** (code OPF): the image of the PI regulator feedback.

- AOL corresponds to the minimum feedback.
- AOH corresponds to the maximum feedback.





## Configurable I/O Application Functions

---

**PI error** (code OPE): the image of the PI regulator error as a % of the sensor range (maximum feedback - minimum feedback).

- AOL corresponds to the maximum error  $< 0$ .
- AOH corresponds to the maximum error  $> 0$ .
- $\frac{AOH + AOL}{2}$  corresponds to a zero error (OPE = 0).

**PI integral** (code OPI): the image of the PI regulator error integral.

- AOL corresponds to a zero integral.
- AOH corresponds to a saturated integral.

**Motor power** (code OPR): the image of the motor power consumption.

- AOL corresponds to 0% of the nominal motor power.
- AOH corresponds to 200% of the nominal motor power.

**Motor thermal state** (code THR): the image of the motor thermal state, calculated.


- AOL corresponds to 0%.
- AOH corresponds to 200%.

**Drive thermal state** (code THD): the image of the drive thermal state, calculated.




- AOL corresponds to 0%.
- AOH corresponds to 200%.

ENGLISH

## Fault Menu

This menu can be accessed when the switch is in position .  
Modifications can only be made in stop mode with the drive locked.


ENGLISH

Code	Description	Factory setting
<b>Rt r</b>	<b>Auto Restart</b>	No
	<p>This function is used to restart the drive automatically if the fault has disappeared (Yes/No option). Automatic restarting is possible after the following faults:</p> <ul style="list-style-type: none"> <li>- line overvoltage</li> <li>- DC bus overvoltage</li> <li>- external fault</li> <li>- motor phase loss</li> <li>- serial link fault</li> <li>- communication fault</li> <li>- loss of 4-20 mA signal</li> <li>- motor overload (condition: motor thermal state less than 100%)</li> <li>- drive overheating (condition: drive thermal state less than 70%)</li> <li>- motor overheating (condition: resistance of probes less than 1,500 Ohms)</li> </ul> <p>When the function is activated, following appearance of one or more of these faults, the R1 relay stays closed: the drive attempts to start every 30 s. A maximum of 6 attempts are made with the drive unable to start (fault present). If all 6 fail, the drive remains locked definitively with the fault relay open, until it is reset by being switched off.</p> <p> This function requires the associated sequence to be maintained. <b>Ensure that accidental restarting will not pose any danger to either equipment or personnel.</b></p>	
<b>r St</b>	<b>Reset Type</b>	RSP
	<p>This function can be accessed if fault reset is assigned to a logic input. 2 possible options: partial reset (RSP), general reset (RSG)</p> <p>Faults affected by a partial reset (rSt = RSP)</p> <ul style="list-style-type: none"> <li>- line overvoltage</li> <li>- motor overload</li> <li>- motor overheating</li> <li>- motor phase loss</li> <li>- serial link fault</li> <li>- communication fault</li> <li>- DC bus overvoltage</li> <li>- loss of 4-20 mA</li> <li>- overhauling</li> <li>- drive overheating</li> <li>- external fault</li> <li>- overspeed</li> </ul> <p>Faults affected by a general reset (rSt = RSG): all faults. The general reset actually inhibits all faults (forced operation).</p> <p>To configure rSt = RSG:</p> <ol style="list-style-type: none"> <li>1 Display RSG</li> <li>2 Press the "ENT" key</li> <li>3 The drive displays "See manual"</li> <li>4 Press  then  then "ENT"</li> </ol>	
<b>DPL</b>	<b>OutPhaseLoss</b>	Yes
	<p>Used to enable the motor phase loss fault. (Fault is eliminated if an isolator is used between the drive and the motor). Choice Yes/No</p>	
<b>IPL</b>	<b>InPhaseLoss</b>	Yes
	<p>Used to enable the line phase loss fault (fault is eliminated if there is a direct power supply via a DC bus). Choice Yes/No</p>	


# Fault Menu

Code	Description	Factory setting
<b>ThE</b>	<b>ThermProType</b>	ACL
	<p>Defines the type of indirect motor thermal protection provided by the drive. If PTC probes are connected to the drive, this function is not available. No thermal protection: N0: No protection  Self-cooled motor (ACL): the drive takes account of any derating depending on the rotation frequency. Force-cooled motor (FCL): the drive does not take account of any derating depending on the rotation frequency.</p>	
<b>LFL</b>	<b>LossFollower</b>	No
	<p>Used to enable the loss of 4-20 mA reference fault.  This fault can only be configured if the AI2 min/max reference parameters (CrL and CrH) are greater than 3 mA or if CrL&gt;CrH.</p> <ul style="list-style-type: none"> <li>- No: no fault</li> <li>- Yes: immediate fault</li> <li>- Stt: stop according to the Stt parameter, without a fault, restart when the signal returns</li> <li>- LSF: stop according to the Stt parameter, then fault at the end of stopping</li> <li>- LFF: force to the fallback speed set by the LFF parameter</li> <li>- RLS: maintaining the speed reached on appearance of the loss of 4-20 mA signal, without a fault, restarting when the signal returns.</li> </ul>	
<b>LFF</b>	<b>4-20 Fllt Spd</b>	0
	<p>Fallback speed in the event of loss of 4-20 mA signal.  Adjustment from 0 to HSP.</p>	
<b>FLr</b>	<b>Catch On Fly</b>	Yes
	<p>Used to enable a smooth restart after one of the following events:</p> <ul style="list-style-type: none"> <li>- loss of line supply or simple power off</li> <li>- fault reset or automatic restart</li> <li>- freewheel stop or injection stop with logic input</li> <li>- uncontrolled loss downstream of the drive</li> </ul> <p>Choice Yes/No</p>	
<b>StP</b>	<b>Cont. Stop</b>	No
	<p>Controlled stop on a line phase loss. This function is only operational if parameter IPL is set to No. If IPL is set to Yes, leave StP in position No. Possible options:</p> <p><b>No</b>: locking on loss of line supply  <b>MMS</b>: Maintain Bus: the drive control unit continues to be powered by the kinetic energy generated by the inertia forces, until the USF fault (undervoltage) occurs  <b>FRP</b>: Follow Ramp: deceleration following the programmed dEC or dE2 ramp until a stop or until the USF fault (undervoltage) occurs</p>	
<b>Sdd</b>	<b>RampNotFoll</b>	Yes
	<p>This function can be accessed if a tachogenerator or pulse generator feedback has been programmed. When enabled, it is used to lock the drive if a speed error is detected (difference between the stator frequency and the measured speed).  Choice Yes/No</p>	
<b>EPL</b>	<b>External fault</b>	Yes
	<p>Defines the type of stop on external fault:</p> <ul style="list-style-type: none"> <li>- Yes: immediate fault</li> <li>- <b>LSF Stop+flt</b>: stop according to the Stt parameter, then fault at the end of stopping</li> </ul>	

## Files Menu







This menu can be accessed when the switch is in position .  
The operations are only possible in stop mode with the drive locked.

The terminal is used to store 4 files containing the drive configurations.

Code	Description	Factory setting
<b>F 15</b>	File 1 State	FRE
<b>F 25</b>	File 2 State	FRE
<b>F 35</b>	File 3 State	FRE
<b>F 45</b>	File 4 State	FRE
	Used to display the state of the corresponding file. Possible states: <b>FRE</b> : file free (state in which terminal is delivered) <b>EnG</b> : a configuration has already been saved to this file	
<b>F 06</b>	Operat. Type	NO
	Used to select the operation to be performed on the files. Possible operations: <b>NO</b> : no operation requested (default value on each new terminal connection to the drive) <b>STR</b> : operation to save the drive configuration to a file on the terminal <b>REC</b> : transfer the content of a file to the drive <b>Ini</b> : return the drive to factory settings  <b>A return to factory settings cancels all your adjustments and your configuration.</b>	

### Operating mode

Select STR, REC or Ini and press "ENT".

- If Operat.Type = STR:  
The file numbers are displayed. Select a file using  or  and confirm with "ENT".
- If Operat.Type = REC:  
The file numbers are displayed. Select a file using  or  and confirm with "ENT".
  - The display indicates:   
Check that the wiring is compatible with the file configuration.  
Cancel with "ESC" or confirm with "ENT".
  - The display then requests a second confirmation using "ENT" or cancellation using "ESC".
- If Operat.Type = Ini:  
  - Confirm with "ENT".
  - The display indicates:   
Check that the wiring is compatible with the factory configuration.  
Cancel with "ESC" or confirm with "ENT".
  - The display then requests a second confirmation using "ENT" or cancellation using "ESC".

At the end of each operation the display returns to the "Operat.Type" parameter set to "NO".

## Files Menu

### Files Menu (continued)

Code	Description
<b>C O d</b>	Password
	Confidential code

The drive configuration can be protected by a password (COd).

CAUTION: THIS PARAMETER SHOULD BE USED WITH CAUTION. IT MAY PREVENT ACCESS TO ALL PARAMETERS. ANY MODIFICATION TO THE VALUE OF THIS PARAMETER MUST BE CAREFULLY NOTED AND SAVED.

The code value is given by four figures, the last of which is used to define the level of accessibility required by the user.

8 8 8 8

This figure gives the level of access permitted, without the correct code.

Access to the menus according to the position of the access locking switch on the rear of the terminal is always operational, within the limits authorized by the code.  
The Code value 0000 (factory setting) does not restrict access.

The table below defines access to the menus according to the last figure in the code.

Menus	Last figure in the code		
	Access locked	Display	Modification
Adjustments	0 exc. 0000 and 9	1	2
Level 2: Adjustments, Macro-config, Drive, Control, I/O, Faults, Files (excluding code), Communication (if card present)	0 exc. 0000 and 9	3	4
Application (if card present)	0 exc. 0000 and 9	5	6
Level 2 and Application (if card present)	0 exc. 0000 and 9	7	8

For access to the APPLICATION menu, refer to the application card documentation.

The code is modified using the ▲ and ▼ keys.

If an incorrect code is entered, it is refused and the following message is displayed:

**C O d**  
Password fault


After pressing the ENT or ESC key on the keypad, the value displayed for the Code parameter changes to 0000: the level of accessibility does not change. The operation should be repeated.

To access menus protected by the access code, the user must first enter this code which can always be accessed in the Files menu.



## Communication and Application Menus / Return to factory settings

### Communication or Application menu

This menu is only displayed if a communication or application card is installed. It can be accessed when the switch is in position . Configuration is only possible in stop mode with the drive locked.


For use with a communication or application option card, refer to the document provided with this card.

For communication via the RS485 link on the base product, refer to the document provided with the RS485 connection kit.

### Return to factory settings

ENGLISH

- In order to use the keypad only (see page 116)
- Proceed using the following method:




- Switch off the drive
- Unlock and open the Altivar cover in order to access the 50/60 Hz switch (1) on the control card. If an option card is present, the selector switch can be accessed through it.
- Change the position of the 50/60 Hz switch (1) on the control card
- Switch on the drive
- Switch off the drive
- Reset the 50/60 Hz switch (1) on the control card to its initial position (nominal motor frequency)
- Switch on the drive, and it reverts to its factory configuration.



# Operation - Maintenance - Spares and Repairs

## Operation

### Signalling on the front panel of the Altivar



green POWER LED

red FAULT LED



on: Altivar powered up



• on: Altivar faulty

• flashing: Altivar locked once the "STOP" key has been pressed on the terminal or after a change to the configuration. The motor can then only be supplied with power after first resetting the "forward", "reverse", and "injection stop" commands.

### Display mode on terminal screen

Displays preset frequency reference, or fault.

The display mode can be modified via the terminal: consult the programming manual.

## Maintenance

Before performing any work on the drive, **switch off the power supply, check that the green LED has gone off, and wait for the capacitors to discharge** (3 to 10 minutes depending on the drive power rating).



**The DC voltage at the + and - terminals or PA and PB terminals may reach 850 V depending on the line supply voltage.**

If a problem arises during setup or operation, ensure that the recommendations relating to the environment, mounting and connections have been observed.

### Servicing

The Altivar 38 does not require preventative maintenance. We nevertheless advise you regularly to:

- Check the condition and tightness of connections
- Ensure that the temperature around the unit remains at an acceptable level and that ventilation is effective (average service life of fans: 3 to 5 years depending on operating conditions)
- Remove any dust from the drive

### Assistance with maintenance

The first fault detected is stored and displayed on the terminal display: the drive locks, the red LED (FAULT) illuminates, and fault relay R1 trips.

### Clearing the fault

- Cut the power supply to the drive in the event of a non-resettable fault.
- Locate the cause of the fault in order to eliminate it.
- Reconnect the power supply: this clears the fault if it has disappeared.
- In some cases there may be an automatic restart once the fault has disappeared if this function has been programmed.

## Spares and repairs

For spare parts and repairs to Altivar 38 drives, consult Schneider group product support.

## Faults - causes - remedies

ENGLISH

Fault displayed	Probable cause	Procedure, remedy
<b>PHF</b> Mains Phase Loss	<ul style="list-style-type: none"> <li>drive incorrectly supplied or fuses blown</li> <li>transient fault on one phase</li> <li>drive supplied by DC bus</li> </ul>	<ul style="list-style-type: none"> <li>check the power connection and the fuses</li> <li>reset</li> <li>configure the "InPhaseLoss" fault (code IPL) as "No", in the FAULT menu</li> </ul>
<b>USF</b> Undervoltage	<ul style="list-style-type: none"> <li>line supply too low</li> <li>transient voltage dip</li> <li>damaged load resistor</li> </ul>	<ul style="list-style-type: none"> <li>check the line voltage</li> <li>change the load resistor</li> </ul>
<b>OSF</b> Overvoltage	<ul style="list-style-type: none"> <li>line supply too high</li> </ul>	<ul style="list-style-type: none"> <li>check the line voltage</li> </ul>
<b>DHF</b> Drive Overheated	<ul style="list-style-type: none"> <li>heatsink temperature too high (<math>t_{Hd} &gt; 118\%</math>)</li> </ul>	<ul style="list-style-type: none"> <li>monitor the motor load, the drive ventilation and wait for the drive to cool down before resetting</li> </ul>
<b>OLF</b> Mot Overload	<ul style="list-style-type: none"> <li>thermal trip due to prolonged overload (<math>t_{Hr} &gt; 118\%</math>)</li> </ul>	<ul style="list-style-type: none"> <li>check the thermal protection setting, monitor the motor load</li> <li>a reset will be possible after approximately 7 minutes</li> </ul>
<b>ObF</b> Overbraking	<ul style="list-style-type: none"> <li>braking too sudden or driving load</li> <li>line supply overvoltage during operation</li> </ul>	<ul style="list-style-type: none"> <li>increase the deceleration time, add a braking resistor if necessary</li> <li>check for any line overvoltages</li> </ul>
<b>OPF</b> Motor Phase Loss	<ul style="list-style-type: none"> <li>one phase open-circuit at the drive output</li> </ul>	<ul style="list-style-type: none"> <li>check the motor connections and that the downstream contactor is closed (if it exists)</li> <li>if a motor starter is being used in a macro configuration, check that the R2 relay is configured as a downstream contactor</li> </ul>
<b>LF F</b> LossFollower	<ul style="list-style-type: none"> <li>loss of the 4-20 mA signal on input AI2</li> </ul>	<ul style="list-style-type: none"> <li>check the connection of the reference circuits</li> </ul>
<b>OCF</b> Overcurrent	<ul style="list-style-type: none"> <li>ramp too short</li> <li>inertia or load too high</li> <li>mechanical locking</li> </ul>	<ul style="list-style-type: none"> <li>check the settings</li> <li>check the size of the motor/drive/load</li> <li>check the state of the mechanism</li> </ul>
<b>SCF</b> Short Circuit	<ul style="list-style-type: none"> <li>short-circuit or grounding at the drive output</li> </ul>	<ul style="list-style-type: none"> <li>check the connection cables with the drive disconnected, and the motor insulation. Check the drive transistor bridge</li> </ul>
<b>Cr F</b> Precharge Fault	<ul style="list-style-type: none"> <li>load relay control fault</li> <li>damaged load resistor</li> </ul>	<ul style="list-style-type: none"> <li>check the connectors in the drive and the load resistor</li> </ul>
<b>SL F</b> RS485 Flt	<ul style="list-style-type: none"> <li>incorrect connection on the drive connector port</li> </ul>	<ul style="list-style-type: none"> <li>check the connection on the drive connector port</li> </ul>
<b>DE F</b> Motor Overheated	<ul style="list-style-type: none"> <li>motor temperature too high (PTC probes)</li> </ul>	<ul style="list-style-type: none"> <li>check the motor ventilation and the ambient temperature, monitor the motor load</li> <li>check the type of probes used</li> </ul>
<b>ES F</b> PTC Probe Fault	<ul style="list-style-type: none"> <li>incorrect connection of probes to the drive</li> </ul>	<ul style="list-style-type: none"> <li>check the connection of the probes to the drive</li> <li>check the probes</li> </ul>



## Faults - causes - remedies

Fault displayed	Probable cause	Procedure, remedy
<b>EEF</b> EEPROM Fault	<ul style="list-style-type: none"> <li>error saving in EEPROM</li> </ul>	<ul style="list-style-type: none"> <li>cut the power supply to the drive and reset</li> </ul>
<b>InF</b> Internal Fault	<ul style="list-style-type: none"> <li>internal fault</li> <li>connector fault</li> </ul>	<ul style="list-style-type: none"> <li>check the connectors in the drive</li> </ul>
<b>EPF</b> External Fault	<ul style="list-style-type: none"> <li>fault triggered by an external device</li> </ul>	<ul style="list-style-type: none"> <li>check the device which has caused the fault and reset</li> </ul>
<b>SPF</b> SP. Feedbk. Loss	<ul style="list-style-type: none"> <li>no speed feedback</li> </ul>	<ul style="list-style-type: none"> <li>check the connection and the mechanical coupling of the speed sensor</li> </ul>
<b>RnF</b> Load Veer. Flt	<ul style="list-style-type: none"> <li>non-following of ramp</li> <li>speed inverse to the reference</li> </ul>	<ul style="list-style-type: none"> <li>check the speed feedback settings and the wiring</li> <li>check the suitability of the settings for the load</li> <li>check the size of the motor-drive and the possible need for a braking resistor</li> </ul>
<b>SDF</b> OverSpeed	<ul style="list-style-type: none"> <li>instability</li> <li>driving load too high</li> </ul>	<ul style="list-style-type: none"> <li>check the settings and the parameters</li> <li>add a braking resistor</li> <li>check the size of the motor/drive/load</li> </ul>
<b>CnF</b> Network Fault	<ul style="list-style-type: none"> <li>communication fault on the fieldbus</li> </ul>	<ul style="list-style-type: none"> <li>check the network connection to the drive</li> <li>check the time-out</li> </ul>
<b>ILF</b> Int. Comm. Flt	<ul style="list-style-type: none"> <li>communication fault between the option card and the control card</li> </ul>	<ul style="list-style-type: none"> <li>check the connection of the option card to the control card</li> </ul>
<b>CFE</b> Rating Fault-ENT Option Fault-ENT Opt. Missing-ENT CKS Fault - ENT	<p>Error probably caused when changing the card:</p> <ul style="list-style-type: none"> <li>change of rating of the power card</li> <li>change of the type of option card or installation of an option card if there was not one already and if the macro-config is CUS</li> <li>option card removed</li> <li>inconsistent configuration saved</li> </ul> <p>Pressing ENT brings up the message: Fact.Set? ENT/ESC</p>	<ul style="list-style-type: none"> <li>check the drive hardware configuration (power card, others)</li> <li>cut the power supply to the drive then reset</li> <li>save the configuration in a file in the terminal</li> <li>press ENT to return to factory settings</li> </ul>
<b>CFI</b> Config. Fault	<ul style="list-style-type: none"> <li>inconsistent configuration sent to drive via serial link</li> </ul>	<ul style="list-style-type: none"> <li>check the configuration sent previously</li> <li>send a consistent configuration</li> </ul>

ENGLISH





## Faults - causes - remedies



Malfunction with no fault display

Display	Probable cause	Procedure, remedy
No code, LEDs not illuminated	<ul style="list-style-type: none"><li>No power supply</li></ul>	<ul style="list-style-type: none"><li>Check power supply to drive</li></ul>
No code, green LED illuminated, red LED illuminated or not illuminated	<ul style="list-style-type: none"><li>Terminal defective</li></ul>	<ul style="list-style-type: none"><li>Change the terminal</li></ul>
rdy green LED illuminated	<ul style="list-style-type: none"><li>Drive in line mode with communication card or RS 485 kit</li><li>An LI input is assigned to "Freewheel stop" or "Fast stop", and this input is not energized These stops are controlled by loss of the input</li></ul>	<ul style="list-style-type: none"><li>Set parameter LI4 to forced local mode then use LI4 to confirm this forced mode</li><li>Connect the input to 24 V to disable the stop</li></ul>

ENGLISH



## Record of configuration and adjustments

Drive reference ATV38 ..... Display rEF: .....  
 Customer identification number (if applicable): .....  
 Option card: no ☐ yes ☐ : reference .....

Access code: no ☐ yes ☐ : .....  
 Configuration in file no. .... on the operator terminal  
 Macro-configuration: .....

For a **CUS: customised** configuration, assign the I/O as follows:

	ALTIVAR	Option card
Logic inputs	LI 1: LI 2: LI 3: LI 4:	LI 5: LI 6:
Analog inputs	AI 1: AI 2:	AI 3:
Encoder input		AI3:
Relay	R2:	
Logic output		LO:
Analog output	AO1:	AO:

ENGLISH

### Adjustment parameters:

Code	Factory setting	Customer setting (1)	Code	Factory setting	Customer setting (1)
<b>RLC</b>	3 s	s	<b>SP5</b>	25 Hz	Hz
<b>dEC</b>	3 s	s	<b>SP6</b>	30 Hz	Hz
<b>LSP</b>	0 Hz	Hz	<b>SP7</b>	35 Hz	Hz
<b>HSP</b>	50 Hz	Hz	<b>SP8</b>	50 Hz	Hz
<b>FLG</b>	20%	%	<b>JOG</b>	10 Hz	Hz
<b>SLA</b>	20%	%	<b>JGt</b>	0.5 s	s
<b>lth</b>	According to model	A	<b>FFt</b>	0 Hz	Hz
<b>ldC</b>	According to model	A	<b>bIP</b>	no	
<b>tdC</b>	0.5 s	s	<b>rPG</b>	1	
<b>sdC</b>	0.5 lth	A	<b>rIG</b>	1/s	/s
<b>RL2</b>	5 s	s	<b>Fb5</b>	1	
<b>dE2</b>	5 s	s	<b>PIC</b>	no	
<b>JPF</b>	0 Hz	Hz	<b>dt5</b>	1	
<b>JF2</b>	0 Hz	Hz	<b>Ctd</b>	1.1 In	A
<b>JF3</b>	0 Hz	Hz	<b>tdt</b>	100%	%
<b>tl5</b>	0	s	<b>PSP</b>	0 s	s
<b>U5C</b>	1		<b>P12</b>	30%	%
<b>UFr</b>	100%	%	<b>P13</b>	60%	%
<b>PFL</b>	20%	%	<b>dttd</b>	105%	%
<b>SP2</b>	10 Hz	Hz	<b>Ftd</b>	50 Hz	Hz
<b>SP3</b>	15 Hz	Hz	<b>F2d</b>	50 Hz	Hz
<b>SP4</b>	20 Hz	Hz			

(1) leave blank when the parameter is missing



## Record of configuration and adjustments

### Drive menu parameters:

Code	Factory setting	Customer setting (1)	Code	Factory setting	Customer setting (1)
<i>U n 5</i>	according to model	V	<i>r P t</i>	LIN	
<i>F r 5</i>	50 Hz	Hz	<i>d C F</i>	4	
<i>n C r</i>	according to model	A	<i>C L I</i>	1.1 In	A
<i>n 5 P</i>	according to model	rpm	<i>R d C</i>	yes	
<i>C 0 5</i>	according to model		<i>P C C</i>	1	
<i>t U n</i>	no		<i>5 F t</i>	LF	
<i>t F r</i>	60 Hz	Hz	<i>5 F r</i>	according to model	kHz
<i>n L d</i>	yes		<i>n r d</i>	yes	
<i>F d b</i>	no		<i>5 P C</i>	no	
<i>b r R</i>	yes		<i>P G t</i>	DET	
<i>F r t</i>	0 Hz		<i>P L 5</i>	1024	
<i>5 t t</i>	STN				

(1) leave blank when the parameter is missing

### Control menu parameters:

Code	Factory setting	Customer setting (1)	Code	Factory setting	Customer setting (1)
<i>t C C</i>	2 W		<i>R Q H</i>	20 mA	mA
<i>t C t</i>	LEL		<i>5 t r</i>	No	
<i>r I n</i>	no		<i>L C C</i>	no	
<i>b 5 P</i>	no		<i>P 5 t</i>	yes	
<i>C r L</i>	4 mA	mA	<i>R d d</i>	0	
<i>C r H</i>	20 mA	mA	<i>t b r</i>	19200	
<i>R Q L</i>	0 mA	mA	<i>r P r</i>	No	

(1) leave blank when the parameter is missing

### Fault menu parameters:

Code	Factory setting	Customer setting (1)	Code	Factory setting	Customer setting (1)
<i>R t r</i>	no		<i>L F F</i>	0 Hz	Hz
<i>r 5 t</i>	RSP		<i>F L r</i>	yes	
<i>0 P L</i>	yes		<i>5 t P</i>	no	
<i>I P L</i>	yes		<i>5 d d</i>	yes	
<i>t H t</i>	ACL		<i>E P L</i>	yes	
<i>L F L</i>	no				

(1) leave blank when the parameter is missing

ENGLISH

## Summary of menus

### LANGUAGE menu

Name	Code
English	<i>L n G</i>
Français	<i>L n G</i>
Deutsch	<i>L n G</i>
Español	<i>L n G</i>
Italiano	<i>L n G</i>

### MACRO-CONFIG menu

Name	Code
UT: Var. Torque	<i>C F</i>

### 1 - DISPLAY menu

Name	Code
Drive State	<i>- - -</i>
Freq. Ref.	<i>F r H</i>
Output Freq.	<i>r F r</i>
Motor Speed	<i>S P d</i>
Motor Current	<i>L C r</i>
Mach. Speed	<i>U S P</i>
Output Power	<i>D P r</i>
Mains Voltage	<i>U L n</i>
Motor Thermal	<i>t H r</i>
Drive Thermal	<i>t H d</i>
Last Fault	<i>L F t</i>
Freq. Ref.	<i>L F r</i>
Power Used	<i>R P H</i>
Run time	<i>r t H</i>

### 2 - ADJUST menu

Name	Code
Freq. Ref. - Hz	<i>L F r</i>
Acceleration - s	<i>A C C</i>
Deceleration - s	<i>d E C</i>
Accel. 2 - s	<i>A C 2</i>
Decel. 2 - s	<i>d E 2</i>
Low Speed - Hz	<i>L S P</i>
High Speed - Hz	<i>H S P</i>
Gain - %	<i>F L G</i>
Stability - %	<i>S t A</i>
ThermCurrent - A	<i>I t H</i>
DC Inj. Time - s	<i>t d C</i>
dc I at rest - A	<i>S d C</i>
Jump Freq. - Hz	<i>J P F</i>
Jump2 Freq. - Hz	<i>J F 2</i>
Jump3 Freq. - Hz	<i>J F 3</i>

### 2 - ADJUST menu (continued)

Name	Code
Machine Coef.	<i>U S C</i>
IR Compens.	<i>U F r</i>
LSP Time - s	<i>t L S</i>
DC Inj.Curr. - A	<i>I d C</i>
U/f Profile - %	<i>P F L</i>
Preset Sp.2 - Hz	<i>S P 2</i>
Preset Sp.3 - Hz	<i>S P 3</i>
Preset Sp.4 - Hz	<i>S P 4</i>
Preset Sp.5 - Hz	<i>S P 5</i>
Preset Sp.6 - Hz	<i>S P 6</i>
Preset Sp.7 - Hz	<i>S P 7</i>
Preset Sp.8 - Hz	<i>S P 8</i>
Jo9 Freq. - Hz	<i>J O G</i>
Jo9 Delay - s	<i>J G t</i>
NST Threshold - Hz	<i>F F t</i>
Tacho Coeff.	<i>d t S</i>
PI Prop.Gain	<i>r P G</i>
PI Int.Gain - /s	<i>r I G</i>
PI Coeff.	<i>F b S</i>
PI Inversion	<i>P I C</i>
Freq.Lev.Att - Hz	<i>F t d</i>
Freq.2 Att - Hz	<i>F 2 d</i>
Curr.Lev.Att - A	<i>C t d</i>
PI Filter - s	<i>P S P</i>
PI Preset 2 - %	<i>P I 2</i>
PI Preset 3 - %	<i>P I 3</i>
ATV th.fault	<i>d t d</i>

### 3 - DRIVE menu

Name	Code
Nom.Mot.Volt -V	<i>U n S</i>
Nom.Mot.Freq - Hz	<i>F r S</i>
Nom. Mot.Curr - A	<i>n C r</i>
Nom.MotSpeed - rpm	<i>n S P</i>
Mot. Cos Phi	<i>C O S</i>
Auto Tuning	<i>t U n</i>
Max Freq. - Hz	<i>t F r</i>
Energy Eco	<i>n L d</i>
I lim adapt.	<i>F d b</i>
DecRampAdapt	<i>b r A</i>
SwitchRamp2 - Hz	<i>F r t</i>
Stop Type	<i>S t t</i>
Ramp Type	<i>r P t</i>

## Summary of menus

ENGLISH

### 3 - DRIVE menu (continued)

Name	Code
DecRAMPCoeff	<i>dCF</i>
Int. I Lim - A	<i>CL I</i>
Auto DC Inj.	<i>AdC</i>
Motor P Coef	<i>PCC</i>
Sw Freq. Type	<i>SFt</i>
Sw Freq - kHz	<i>SFr</i>
Noise Reduct	<i>nrd</i>
Special Motor	<i>SPC</i>
PG Type	<i>PGt</i>
Num. Pulses	<i>PLS</i>

### 4 - CONTROL menu

Name	Code
TermStrip Con	<i>tCC</i>
Type 2 Wire	<i>tCt</i>
RV inhibit	<i>rIn</i>
deadb/Pedst	<i>bSP</i>
AI2 min Ref. - mA	<i>CrL</i>
AI2 Max Ref. - mA	<i>CrH</i>
Min Val. AO - mA	<i>ADL</i>
Max Val. AO - mA	<i>ADH</i>
Save Ref.	<i>Stt</i>
Keypad Comm.	<i>LCC</i>
STOP Priorit	<i>PSt</i>
DriveAddress	<i>Add</i>
BdRate RS485	<i>tbr</i>
Reset cnts	<i>rPr</i>

### 5 - I/O menu

Name	Code
LI2 Assign.	<i>L 12</i>
LI3 Assign.	<i>L 13</i>
LI4 Assign.	<i>L 14</i>
LI5 Assign.	<i>L 15</i>
LI6 Assign.	<i>L 16</i>
NO :Not assigned	
RV :Reverse	
RP2:Switch ramp2	
JOG	
+SP: + Speed	
-SP: - Speed	
PS2: 2 Preset Speeds	
PS4 : 4 Preset Speeds	
PS8 : 8 Preset Speeds	

### 5 - I/O menu (continued)

Name	Code
NST:Freewhl Stop	
DCI:DC inject.	
FST:Fast stop	
CHP:Multi. Motor	
FLO:Forced Local	
RST:Fault Reset	
RFC:Auto/Manu	
ATN:Auto Tuning	
PAU:PI Auto/Man	
PR2:PI 2 Preset	
PR4:PI 4 Preset	
EDD:External flt	
FTK: Forc.KeyP.	
R2 Assign.	<i>r 2</i>
LO assign.	<i>LO</i>
NO :Not assigned	
RUN:Drive Running	
OCC:OutPut Cont.	
FTA:Freq Attain.	
FLA:HSP Attained	
CTA:I Attained	
SRA:FRH Attained	
TSA:MtrTherm Lvl	
APL:LossFollower	
F2A:Freq 2 Attain.	
tAd:ATV th.alarm	
AI2 assign.	<i>A 12</i>
AI3 Assign.	<i>A 13</i>
NO :Not assigned	
FR2:Speed Ref2	
SAI:Summed Ref.	
PIF:PI Regulator	
PIM:PI Man.ref.	
SFB:Tacho feedbk	
PTC:Therm.Sensor	
AI3 assign. (encoder)	<i>A 13</i>
NO :Not assigned	
SAI:Summed Ref.	
RGI:Retour GI	
AO assign.	<i>AO</i>
NO :Not assigned	

## Summary of menus

### 5 - I/O menu (continued)

Name	Code
OCR:Motor Curr.	
OFR:Motor Freq	
ORP:OutPut ramp	
ORS:Signed ramp	
OPS:PI ref.	
OPF:PI Feedback	
OPE:PI Error	
OPI:PI Integral	
OPr:OutPut Power	
tHr:MotorThermal	
tHd:DriveThermal	

### 6 - FAULT menu

Name	Code
Auto Restart	<i>Rtr</i>
Reset Type	<i>rSt</i>
OutPhaseLoss	<i>DPL</i>
InPhaseLoss	<i>IPL</i>
Cont. Stop	<i>StP</i>
ThermProType	<i>tHt</i>
LossFollower	<i>LFL</i>
4-20 Flt Smd	<i>LFF</i>
Catch On Fly	<i>FLr</i>
RampNotFoll	<i>Sdd</i>
External fault	<i>EPL</i>

### 7 - FILES menu

Name	Code
File 1 State	<i>F1S</i>
File 2 State	<i>F2S</i>
File 3 State	<i>F3S</i>
File 4 State	<i>F4S</i>
Operat.Type	<i>Fdt</i>
Password	<i>CDd</i>

### 8 - COMMUNICATION menu

Refer to the documentation provided with the communication card.

### 9 - APPLICATION menu



Refer to the documentation provided with the application card.

# Index

ENGLISH

Function	Menus	Pages
Acceleration	ADJUST - DRIVE	90-94
Automatic ramp adaptation	DRIVE	93
Serial link address	CONTROL	98
Controlled stop	I/O - FAULT	99-113
Auto Tuning	DRIVE - I/O	93-99-107
Speed loop with encoder	DRIVE - I/O	95-100-101-99
Speed loop with tachometer	ADJUST - I/O	92-100-101-108
Password	FILES	115
2/3-wire control	CONTROL	96-104
Motor switching	DRIVE - I/O	94-99-107
Ramp switching	ADJUST - DRIVE - I/O	91-93-99-101-104
Reference switching	I/O	99-106
Downstream contactor	I/O	100-109
Deceleration	ADJUST - DRIVE	90-94
External fault	I/O	107
Energy saving	DRIVE	93
Analog input AI2	CONTROL	97
Configurable inputs	I/O	99-100-101
Force to keypad	CONTROL - I/O	99-107
Forced local mode	CONTROL - I/O	99-107
Injection braking	ADJUST - DRIVE	90-91-94
Switching frequency	DRIVE	95
Jump frequencies	ADJUST	90
Current limit	DRIVE	93-94
Low speed limit time	ADJUST	90
Save reference	CONTROL	98
Step by step (JOG)	ADJUST - I/O	91-99-101-104
Loss of 4-20mA	FAULT	110
+/- speed	I/O	99-102-105
Stop priority	CONTROL	98
Motor thermal protection	ADJUST - I/O - FAULT	90-92-100-101-113
Auto catching (flying restart)	FAULT	113
Automatic restart	FAULT	112
Factory setting / Save	FILES	114
PI regulator	ADJUST - I/O	92-100-101-108
Fault reset	I/O - FAULT	99-102-107-112
PTC probes	I/O	100-108
Configurable outputs	CONTROL - I/O	97-100-101-109-110
Preset speeds	ADJUST - I/O	91-99-101-106



**ENGLISH**



## Note



ENGLISH





## 施耐德电气(中国)投资有限公司在中国联络地址:

- 北京总部
- 分销商
- ▲ 合资厂
- ★ 办事处



**施耐德电气(中国)  
投资有限公司总部**  
北京市朝阳区东三环北路8号  
亮马大厦17层  
邮编: 100004  
电话: (010) 6590 6907  
传真: (010) 6590 0013

**北京办事处**  
北京市朝阳区东三环北路8号  
亮马大厦21层  
邮编: 100004  
电话: (010) 6590 6907  
传真: (010) 6590 0986

**上海分公司**  
上海市仙霞路299号  
远东国际广场A幢9楼  
邮编: 200051  
电话: (021) 6235 1333  
传真: (021) 6235 1238

**西安办事处**  
西安市小寨东路196号  
西安国际贸易中心25层  
邮编: 710061  
电话: (029) 538 2880  
传真: (029) 538 2890

**乌鲁木齐办事处**  
乌鲁木齐市新华北路5号  
美丽华酒店1112室  
邮编: 830002  
电话: (0991) 282 5888-1112  
传真: (0991) 284 8188

**苏州办事处**  
苏州市干将东路636号  
丽景苑1幢303室  
邮编: 215005  
电话: (0512) 6522 1287  
传真: (0512) 6522 1287

**昆明办事处**  
昆明市东风西路123号  
三和南利写字楼14层D座  
邮编: 650032  
电话: (0871) 364 7549  
传真: (0871) 364 7552

**广州分公司**  
广州市环市东路403号  
广州国际电子大厦31楼  
邮编: 510095  
电话: (020) 8732 0138  
传真: (020) 8732 1929

**南京办事处**  
南京市黄埔路2号  
黄埔大厦17层A座  
邮编: 210016  
电话: (025) 481 4815  
传真: (025) 481 4816

**天津办事处**  
天津市河西区围堤道125-127号  
天信大厦1710-1711室  
邮编: 300074  
电话: (022) 2840 8408  
传真: (022) 2840 8410

**厦门办事处**  
厦门市湖滨北路19号  
大华银行大厦0601室  
邮编: 361012  
电话: (0592) 504 8393  
传真: (0592) 504 8208

**深圳办事处**  
深圳市深南东路  
深圳发展银行大厦17层  
邮编: 518001  
电话: (0755) 2584 1022  
传真: (0755) 8208 0250

**武汉分公司**  
武汉市武胜路泰合广场15层  
1502室  
邮编: 430033  
电话: (027) 8571 2588  
传真: (027) 8571 2688

**杭州办事处**  
杭州市凤起路78号  
浙金广场516号  
邮编: 310003  
电话: (0571) 8527 1304  
传真: (0571) 8527 1305

**青岛办事处**  
青岛市香港中路6号  
世界贸易中心A座2008室  
邮编: 266071  
电话: (0532) 591 9606  
传真: (0532) 591 9607

**福州办事处**  
福州市五四路218号  
温泉大酒店519室  
邮编: 350003  
电话: (0591) 781 3070  
传真: (0591) 781 2764

**香港办事处**  
香港湾仔港湾道30号  
新鸿基中心31楼  
3108-28室  
电话: (00852) 2565 0621  
传真: (00852) 2811 1029

**沈阳办事处**  
沈阳市沈河区青年大街219号  
新华国际大厦14层B、C座  
邮编: 110015  
电话: (024) 2396 4339  
传真: (024) 2396 4296

**成都办事处**  
成都顺城大街308号  
冠城广场27楼B、C、D座  
邮编: 610017  
电话: (028) 8652 8282  
传真: (028) 8652 8383

**济南办事处**  
济南市历源大街66号世贸中心  
银座大厦写字楼B座B区1107室  
邮编: 250063  
电话: (0531) 606 5156  
传真: (0531) 606 5016

**宁波办事处**  
宁波市江东北路1号  
中信宁波国际大酒店833室  
邮编: 315010  
电话: (0574) 8771 6067  
传真: (0574) 8772 4576

**施耐德电气-清华  
联合培训与研究中心**  
北京市海淀区黄庄知春路76号  
翠宫饭店写字楼12层  
邮编: 100086  
电话: (010) 6263 8210/11  
传真: (010) 6263 8212

**重庆办事处**  
重庆市渝中区邹容路68号  
大都会商厦1603室  
邮编: 400010  
电话: (023) 6383 9706  
传真: (023) 6383 9707

**大连办事处**  
大连市中山区人民路68号  
宏誉商业大厦2205室  
邮编: 116001  
电话: (0411) 282 2690  
传真: (0411) 282 2692

**合肥办事处**  
合肥市长江东路1104号  
古井假日酒店918房间  
邮编: 230011  
电话: (0551) 429 1993  
传真: (0551) 429 1166-918室

**长沙办事处**  
长沙市劳动西路386号  
佳程酒店1200室  
邮编: 410007  
电话: (0731) 511 5858  
传真: (0731) 511 7878

**施耐德电气-上海交通大学  
联合培训与研究中心**  
上海华山路1954号上海交通大学  
大学新上院(电力学院)二楼  
邮编: 200030  
电话: (021) 62831227  
传真: (021) 62811847

施耐德电气服务热线:



**800 810 1315**  
010 6788 8904



施耐德电气公司版权所有 VVED302071

施耐德电气公司  
Schneider Electric China  
[www.schneider-electric.com.cn](http://www.schneider-electric.com.cn)

北京市朝阳区东三环北路  
8号亮马大厦17层  
邮编: 100004  
电话: (010) 6590 6907  
传真: (010) 6590 0013

17/F, Landmark Building  
8 North Dongsanhuan Road  
Chaoyang District Beijing 100004  
Tel: (010) 6590 6907  
Fax: (010) 6590 0013

由于标准和材料的变更，文中所述特性和本资料中的图像只有经过我们的业务部门确认以后，才对我们有约束。



本手册采用生态纸印刷

SCDOC425-VVD

2003.11

